

# VRF (Variable Refrigerant Flow) Installation manual

---

**VWMC\*\*\*\*4-4P**

---

- Thank you for purchasing this Lennox Product.
- Before installing this unit, please read this installation manual carefully and retain it for future reference.



# Contents

---

<b>Safety Information</b>	<b>3</b>
Safety Information	3
<b>Installation Procedure</b>	<b>5</b>
Installation Procedure	5
Step 1 Checking and preparing accessories	5
Step 2 Selecting the installation location	5
Step 3 Installing the indoor unit	6
Step 4 Purging the unit	6
Step 5 Connecting the refrigerant pipe	7
Step 6 Cutting or flaring the pipes	8
Step 7 Performing leak test	9
Step 8 Wrapping the pipes with the insulation	9
Step 9 Installing the drain hose	10
Step 10 Optional: Changing direction of the drain hose	10
Step 11 Connecting the power and communication cables	11
Step 12 Setting an indoor unit address and installation option	15
Step 13 Performing the final check	33
Step 14 Providing information for user	33
Step 15 Charging additional refrigerant	33
<b>Appendix</b>	<b>32</b>
Troubleshooting	32

# Safety Information

California Proposition 65 Warning (US)



## WARNING:

Cancer and Reproductive Harm -  
www.P65Warnings.ca.gov.

Carefully follow the precautions listed below because they are essential to guarantee the safety of the equipment.



## WARNING

- Always disconnect the product from the power supply before servicing it or accessing its internal components.
- Verify that installation and testing operations are performed by qualified personnel.
- Verify that the product is not installed in an easily accessible area.

## General information

- Carefully read the content of this manual before installing the product and store the manual in a safe place in order to be able to use it as reference after installation.
- For maximum safety, installers should always carefully read the following warnings.
- Store the operation and installation manual in a safe location and remember to hand it over to the new owner if the product is sold or transferred.
- This manual explains how to install an indoor unit with a split system with two Lennox units. The use of other types of units with different control systems may damage the units and invalidate the warranty. The manufacturer shall not be responsible for damages arising from the use of non compliant units.
- The manufacturer shall not be responsible for damage originating from unauthorized changes or the improper connection of electric and hydraulic lines. Failure to comply with these instructions or to comply with the requirements set forth in the "Operating limits" table, included in the manual, shall immediately invalidate the warranty.
- The product should be used only for the applications for which it has been designed: the indoor unit is not suitable to be installed in areas used for laundry.
- Do not use the units if damaged. If problems occur, switch the unit off and disconnect it from the power supply.

- In order to prevent electric shocks, fires or injuries, always stop the unit, disable the protection switch and contact Lennox's technical support if the unit produces smoke, if the power cable is hot or damaged or if the unit is very noisy.
- Always remember to inspect the unit, electric connections, refrigerant tubes and protections regularly. These operations should be performed by qualified personnel only.
- The unit contains moving parts, which should always be kept out of the reach of children.
- Do not attempt to repair, move, alter or reinstall the unit. If performed by unauthorized personnel, these operations may cause electric shocks or fires.
- Do not place containers with liquids or other objects on the unit.
- All the materials used for the manufacture and packaging of the product are recyclable.
- The packing material and exhaust batteries of the remote control(optional) must be disposed of in accordance with current laws.
- The product contains a refrigerant that has to be disposed of as special waste. At the end of its life cycle, the product must be disposed of in authorized centers or returned to the retailer so that it can be disposed of correctly and safely.
- Wear protective equipment (such as safety gloves, goggles, and headgear) during installation and maintenance works. Installation/repair technicians may be injured if protective equipment is not properly equipped.

## Installing the unit

- **IMPORTANT:** When installing the unit, always remember to connect first the refrigerant tubes, then the electrical lines. Always disassemble the electric lines before the refrigerant tubes.
- Upon receipt, inspect the product to verify that it has not been damaged during transport. If the product appears damaged, DO NOT INSTALL it and immediately report the damage to the carrier or retailer (if the installer or the authorized technician has collected the material from the retailer.)
- After completing the installation, always carry out a functional test and provide the instructions on how to operate the product to the user.
- Do not use the product in environments with hazardous substances or close to equipment that release free flames to avoid the occurrence of fires, explosions or injuries.

# Safety Information


- Our units must be installed in compliance with the spaces indicated in the installation manual to ensure either accessibility from both sides or ability to perform routine maintenance and repairs. The units' components must be accessible and that can be disassembled in conditions of complete safety either for people or things. For this reason, where it is not observed as indicated into the Installation Manual, the cost necessary to reach and repair the unit (in safety, as required by current regulations in force) with slings, trucks, scaffolding or any other means of elevation won't be considered in-warranty and charged to end user.

## Power supply line, fuse or circuit breaker

- Always make sure that the power supply is compliant with current safety standards. Always install the product in compliance with current local safety standards.
- Always verify that a suitable grounding connection is available.
- Verify that the voltage and frequency of the power supply comply with the specifications and that the installed power is sufficient to ensure the operation of any other domestic appliance connected to the same electric lines.
- Always verify that the cut-off and protection switches are suitably dimensioned.
- Verify that the product is connected to the power supply in accordance with the instructions provided in the wiring diagram included in the manual.
- Always verify that electric connections (cable entry, section of leads, protections...) are compliant with the electric specifications and with the instructions provided in the wiring scheme. Always verify that all connections comply with the standards applicable to the installation of products.
- Be sure not to perform power cable modification, extension wiring, and multiple wire connection.
  - It may cause electric shock or fire due to poor connection, poor insulation, or current limit override.
  - When extension wiring is required due to power line damage, refer to "Step 12 Optional: Extending the power cable" in the installation manual.

## CAUTION

- Make sure that you earth the cables.
  - Do not connect the earth wire to the gas pipe, water pipe, lighting rod or telephone wire. If earthing is not complete, electric shock or fire may occur.
- Install the circuit breaker.
  - If the circuit breaker is not installed, electric shock or fire may occur.
- Make sure that the condensed water dripping from the drain hose runs out properly and safely.
- Install the power cable and communication cable of the indoor and outdoor unit at least 1m away from the electric appliance.
- Install the indoor unit away from lighting apparatus using the ballast.
  - If you use the wireless remote control, reception error may occur due to the ballast of the lighting apparatus.
- Do not install the product in following places.
  - Place where there is mineral oil or arsenic acid. Resin parts flame and the accessories may drop or water may leak.  
The capacity of the heat exchanger may reduce or the product may be out of order.
  - The place where corrosive gas such as sulfurous acid gas generates from the vent pipe or air outlet. The copper pipe or connection pipe may corrode and refrigerant may leak.
  - The place where there is a machine that generates electromagnetic waves. The product may not operate normally due to control system.
  - The place where there is a danger of existing combustible gas, carbon fiber or flammable dust. The place where thinner or gasoline is handled. Gas may leak and it may cause fire.
- Please cover the product with PE BAG after installation, and remove it when you start to run product.









# Installation Procedure

## Step 1 Checking and preparing accessories

The following accessories are supplied with the indoor unit.

The type and quantity may differ depending on the specifications.

Installation plate	Installation manual
	
User manual	PE indoor unit cover
	

## Step 2 Selecting the installation location

### Indoor Unit


- Where airflow is not blocked.
- Where cool air can be distributed throughout the room.
- Install the refrigerant piping length and the height difference of both indoor and outdoor units as indicated in the installation diagram.
- Wall that prevents vibration and is strong enough to hold the product weight.
- Out of the direct sunlight.
- 1m or more away from the TV or radio (to prevent the screen from being distorted or noise from being generated).
- As far away as possible from fluorescent and incandescent lights (so that the remote control can be operated well).
- A place where the air filter can be replaced easily.

### CAUTION

- Do not install the product with EEV (commercial model) in a quiet place such as bedroom, hotel, and hospital. If installation is required in a place, install the indoor unit that has no EEV along with the EEV kit.
- Avoid the following places to prevent malfunction of the unit.
  - Where there is machine oil
  - Salty environment such as the seaside areas
  - Where sulfide gas exists
  - Other special atmosphere areas

### Space requirements for installation & service

Observe the clearances and maximum lengths as seen in the picture below when installing the product.



### NOTE

- The appearance of the unit may be different from the diagram depending on the model.




# Installation Procedure

## Step 3 Installing the indoor unit


Before fixing the installation plate to the wall or window frame, you must determine the position of the 2.56 inch(65 mm) hole through which the cable, pipe and hose pass to connect the indoor unit to the outdoor unit.

When facing the wall, the pipe and cable can be connected from the:

- Right
- Left
- Underside (right)
- Rear (right or left)



- 1 Determine the position of the pipe and drain hose hole as seen in the picture and drill the hole with an inner diameter of 2.56 inch(65 mm) so that it slants slightly downwards.




Pipe bundle hole: 2.56 inch (Ø65 mm)

(Unit: inch (mm))

Model	a	b	c
**005/007/009/012**	6.50 (165)	12.01 (305)	16.38 (416)
**015/018/024/028**	6.50 (165)	1.66 (347)	11.95 (608.5)

- 2 If you fix the indoor unit to a wall, fix the installation plate to the wall giving attention to the weight of the indoor unit.




### NOTE

- If you mount the plate to a concrete wall by using plastic anchors, make sure that gaps between the wall and the plate, created by projected anchor, are less than 0.79 inch (20 mm)
- 3 If you fix the indoor unit to a window frame, follow 4 to 6.
  - 4 Determine the positions of the wooden uprights to be attached to the window frame.
  - 5 Attach the wooden uprights to the window frame giving attention to the weight of the indoor unit.
  - 6 Attach the installation plate to the wooden uprights using tapping screw.

## Step 4 Purging the unit

Upon delivery, there may be inert gas inside the indoor unit. Purge the gas from the indoor unit before connecting the assembly pipe.

- Unscrew the caps at the end of each pipe. All inert gas exhausts from the indoor unit.



### NOTE

- To prevent dirt or foreign substances from getting into the pipes during installation, do NOT remove the caps completely until you are ready to connect the pipes.



## Step 5 Connecting the refrigerant pipe

Connect indoor and outdoor units with field-supplied copper pipes by means of flare connections. Use insulated seamless refrigeration grade pipe only, (Cu DHP type according to ISO1337), degreased and deoxidized, suitable for operating pressures of at least 4200 kPa and for burst pressure of at least 20700 kPa. Under no circumstances must sanitary type copper pipe be used.


There are 2 refrigerant pipes of different diameters:

- The smaller one is for the liquid refrigerant
- The larger one is for the gas refrigerant


A short pipe is already fitted to the product. You may need to extend the pipe using the assembly pipe. (optional)

The connection procedure for the refrigerant pipe varies according to the exit position of the pipe when facing the wall:

- Right (A)
- Left (B)
- Underside (C)
- Rear



- 1 Cut out the appropriate knock-out piece on the rear of the indoor unit unless you connect the pipe directly from the rear.
- 2 Smooth the cut edges.
- 3 Remove the protection caps of the pipes and connect the assembly pipe to each pipe. Tighten the nuts first with your hands, and then with a torque wrench, applying the following torque:



Outer diameter (inch (mm))	Torque (lbf•ft (N•m))	Torque (kgf•cm)
Ø 1/4" (6.35)	10.3 to 13.3 (14 to 18)	140~180
Ø 3/8" (9.52)	25.1 to 31.0 (34 to 42)	350~430
Ø 1/2" (12.70)	36.1 to 45.0 (49 to 61)	500~620
Ø 5/8" (15.88)	50.2 to 60.5 (68 to 82)	690~830

### NOTE

- If you want to shorten or extend pipes, refer to Step 6 Cutting or flaring the pipes.
- 4 Cut off the remaining foam insulation.
  - 5 If necessary, bend the pipe to fit along the bottom of the indoor unit. Then pull it out through the appropriate hole.
    - The pipe should not project from the rear of the indoor unit.
    - The bending radius should be 3.94 inch (100 mm) or more.
  - 6 Pass the pipe through the hole in the wall.
  - 7 For further details on how to connect to the outdoor unit and purge the air, refer to Step 4 Purging the unit.


### NOTE

- The pipe will be insulated and fixed permanently into position after finishing the installation and the gas leak test; refer to page 9 for further details.
- **DO NOT WALL UP THE PIPE CONNECTION!**  
All refrigerant pipe connection must be easy accessible and serviceable.


# Installation Procedure

## Step 6 Cutting or flaring the pipes

- 1 Make sure that you prepared the required tools. (pipe cutter, reamer, flaring tool and pipe holder)
- 2 If you want to shorten the pipe, cut it using a pipe cutter ensuring that the cut edge remains at 90° with the side of the pipe. There are some examples of correctly and incorrectly cut edges below.




- 3 To prevent a gas leak, remove all burrs at the cut edge of the pipe using a reamer.
- 4 Carry out flaring work using flaring tool as shown below.




(Unit: inch (mm))

Outer diameter	A		
	Flare tool for R410A clutch type	Conventional flare tool	
		Clutch type	Wing nut type
Ø1/4 inch (6.35 mm)	0~0.02 (0~0.5)	0.04~0.06 (1.0~1.5)	0.06~0.08 (1.5~2.0)
Ø3/8 inch (9.52 mm)	0~0.02 (0~0.5)	0.04~0.06 (1.0~1.5)	0.06~0.08 (1.5~2.0)
Ø1/2 inch (12.70 mm)	0~0.02 (0~0.5)	0.04~0.06 (1.0~1.5)	0.06~0.08 (1.5~2.0)
Ø5/8 inch (15.88 mm)	0~0.02 (0~0.5)	0.04~0.06 (1.0~1.5)	0.06~0.08 (1.5~2.0)

- 5 Check if you flared the pipe correctly. There are some examples of incorrectly flared pipes below.



- 6 Align the pipes and tighten the flare nuts first manually and then with a torque wrench, applying the following torque.





Outer diameter, D (inch (mm))	Connection Torque		Flare dimension, L (inch(mm))
	kgf•cm	(lbf•ft (N•m))	
Ø1/4 inch (6.35 mm)	140~180	10.3 to 13.3 (14 to 18)	0.34 to 0.36 (8.7 to 9.1)
Ø3/8 inch (9.52 mm)	350~430	25.1 to 31.0 (34 to 42)	0.50 to 0.52 (12.8 to 13.2)
Ø1/2 inch (12.70 mm)	500~620	36.1 to 45.0 (49 to 61)	0.64 to 0.65 (16.2 to 16.6)
Ø5/8 inch (15.88 mm)	690~830	50.2 to 60.5 (68 to 82)	0.76 to 0.78 (19.3 to 19.7)



### CAUTION

- In case of needing brazing, you must work with nitrogen gas blowing.

## Step 7 Performing leak test


### Leak test

LEAK TEST WITH NITROGEN (before opening valves)

In order to detect basic refrigerant leaks, before recreating the vacuum and recirculating the R410A, it's responsible of installer to pressurize the whole system with nitrogen (using a pressure regulator) at a pressure above 4.1MPa (gauge).

LEAK TEST WITH R410A (after opening valves)

Before opening valves, discharge all the nitrogen into the system and create vacuum. After opening valves check leaks using a leak detector for refrigerant R410A.




### CAUTION

- Discharge all the nitrogen to create a vacuum and charge the system.

## Step 8 Wrapping the pipes with the insulation

After checking for gas leaks in the system, insulate the pipe, hose and cables. Then place the indoor unit on the installation plate.

- To avoid condensation problems, place heat-resistant poly-ethylene foam separately around each refrigerant pipe in the lower part of the indoor unit.




- Wrap the refrigerant pipe and the drain hose in the rear of the indoor unit with the absorbent pad.



### NOTE

- Wind the pipe and hose three times to the end of the indoor unit with the absorbent pad. (0.79 inch (20 mm) interval)
- Wind the pipe, assembly cable and drain hose with insulation tape.
  - Place the bundle (the pipe, assembly cable and drain hose) in the lower part of the indoor unit carefully so it doesn't project from the rear of the indoor unit.



- Hook the indoor unit to the installation plate and move the unit to the right and left until it is securely in place.
- Wrap the rest of the pipe with vinyl tape.
- Attach the pipe to the wall using clamps (optional).







# Installation Procedure

## Step 9 Installing the drain hose

When installing the drain hose for the indoor unit, check if condensation draining is adequate. When passing the drain hose through the 2.56 inch (65 mm) hole drilled in the wall, check the following:



- 1 If necessary, connect the 6.56 ft (2 meter) extension drain hose to the drain hose.
- 2 If you use the extension drain hose, insulate the inside of the extension drain hose with a shield.
- 3 Fit the drain hose into 1 of 2 drain hose holes, then fix the end of the drain hose tightly with a clamp.



### NOTE

- If you don't use the other drain hose hole, block it with a rubber stopper.

- 4 Pass the drain hose under the refrigerant pipe, keeping the drain hose tight.
- 5 Pass the drain hose through the hole in the wall. Check if it slants downwards as seen in the picture.


### NOTE

- The hose will be fixed permanently into position after finishing the installation and the gas leak test; refer to page 9 for further details.
- DO NOT WALL UP THE DRAIN HOSE CONNECTION! Drain hose connection must be easy accessible and serviceable.


## Step 10 Optional: Changing direction of the drain hose

You can select the direction of the drain hose, depending on where you want to install the indoor unit.

- 1 Detach the rubber cap with the flyer.



- 2 Detach the drain hose by pulling it and turning to the left.
- 3 Insert the drain hose by fixing it into the groove of the drain hose and the outlet of the drain pan.




- 4 Attach the rubber cap with a screwdriver by turning it to the right until it fixes to the end of the groove.



## Step 11 Connecting the power and communication cables

- 1 Before wiring work, you must turn off all power source.
- 2 Indoor unit power should be supplied through the breaker (ELCB or MCCB+ELB) separated by the outdoor power.
  - ELCB:Earth Leakage Circuit Breaker
  - MCCB:Molded Case Circuit Breaker
  - ELB:Earth Leakage Breaker
- 3 The power cable should be used only copper wires.
- 4 Connect the power cable (1(L), 2(N)) among the units within maximum length and communication cable (F1, F2) each.
- 5 Connect F3, F4(for communication) wires at the back side of the indoor unit when installing the wired remote control.




- ELCB : Essential Installation
- The EEV Kit is optional component.

### WARNING

- Power off before connecting any wires; Indoor PBA will be damaged while V1, V2, F3, F4 short each other.
- You must connect the earth cable. If earthing is not complete, electric shock or fire may occur.

# Installation Procedure

## Ring terminal selection



Normal dimensions for cable (inch <sup>2</sup> (mm <sup>2</sup> ))	Normal dimensions for screw (inch (mm))	B		D		d1		E	F	L	d2		t
		Standard dimension (inch (mm))	Allowance (inch (mm))	Standard dimension (inch (mm))	Allowance (inch (mm))	Standard dimension (inch (mm))	Allowance (inch (mm))	Min.	Min.	Max.	Standard dimension (inch (mm))	Allowance (inch (mm))	Min.
0.0023 (1.5)	0.157 (4)	0.260 (6.6)	± 0.008 (0.2)	0.134 (3.4)	+0.012 (0.3) -0.008 (0.2)	0.067 (1.7)	± 0.008 (0.2)	0.161 (4.1)	0.236 (6)	0.630 (16)	0.169 (4.3)	+0.008 (0.2) 0 (0)	0.028 (0.7)
	0.157 (4)	0.315 (8)											
0.0039 (2.5)	0.157 (4)	0.260 (6.6)	± 0.008 (0.2)	0.165 (4.2)	+0.012 (0.3) -0.008 (0.2)	0.091 (2.3)	± 0.008 (0.2)	0.236 (6)	0.236 (6)	0.689 (17.5)	0.169 (4.3)	+0.008 (0.2) 0 (0)	0.031 (0.8)
	0.157 (4)	0.335 (8.5)											
0.0062 (4)	0.157 (4)	0.374 (9.5)	± 0.008 (0.2)	0.220 (5.6)	+0.012 (0.3) -0.008 (0.2)	0.134 (3.4)	± 0.008 (0.2)	0.236 (6)	0.197 (5)	0.787 (20)	0.169 (4.3)	+0.008 (0.2) 0 (0)	0.035 (0.9)

## Specification of electronic wire

Power supply	MCCB	ELB or ELCB	Power cable	Earth cable	Communication cable
Min : 187V Max : 253V	XA	XA, 30 mmA, 0.1 s	0.0039 inch <sup>2</sup> (2.5 mm <sup>2</sup> )	0.0039 inch <sup>2</sup> (2.5 mm <sup>2</sup> )	0.0012 to 0.0023 inch <sup>2</sup> (0.75 to 1.5 mm <sup>2</sup> )

- Refer to the unit nameplate for rating current.
- Decide the capacity of ELCB(or MCCB+ELB) by below formula.
- Power supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord. (Code designation IEC:60245 IEC 57 / CENELEC: H05RN-F or IEC:60245 IEC 66 / CENELEC: H07RN-F)

The capacity of ELCB(or MCCB+ELB)  $X[A] = 1.25 \times 1.1 \times \sum A_i$

- X : The capacity of ELCB(or MCCB+ELB).
- $\sum A_i$  : Sum of Rating currents of each indoor unit.
- Refer to each installation manual about the rating current of indoor unit.

- Decide the power cable specification and maximum length within 10% power drop among indoor units.


$$\sum_{k=1}^n \left( \frac{\text{Coef} \times 35.6 \times L_k \times i_k}{1000 \times A_k} \right) < 10 \% \text{ of input voltage [V]}$$

- coef: 1.55
- Lk: Distance among each indoor unit [m(ft)],
- Ak: Power cable specification [mm<sup>2</sup> (inch<sup>2</sup>)]
- ik: Running current of each unit [A]



## Example of Installation

- Total power cable length L = 328.08 [ft. ] (100 [m]), Running current of each units 1[A]
- Total 10 indoor units were installed




- Apply following equation.


$$\sum_{k=1}^n \left( \frac{\text{Coef} \times 35.6 \times L_k \times i_k}{1000 \times A_k} \right) < 10\% \text{ of input voltage [V]}$$

- Calculation

- Installing with 1 sort wire



- Installing with 2 different sort wire.



## CAUTION

- Select the power cable in accordance with relevant local and national regulations.
- Wire size must comply with local and national code.
- For the power cable, use the grade of H07RN-F or H05RN-F materials.
- You should connect the power cable into the power cable terminal and fasten it with a clamp.
- The unbalanced power must be maintained within 10% of supply rating among whole indoor units.
- If the power is unbalanced greatly, it may shorten the life of the condenser. If the unbalanced power is exceeded over 10% of supply rating, the indoor unit is protected, stopped and the error mode indicates.
- To protect the product from water and possible shock, you should keep the power cable and the connection cord of the indoor and outdoor units in the iron pipe.
- Connect the power cable to the auxiliary circuit breaker. An all pole disconnection from the power supply must be incorporated in the fixed wiring (≥0.12inch (3mm)).



# Installation Procedure

- You must keep the cable in a protection tube.
- Keep distances of 1.97 inch (50 mm) or more between power cable and communication cable.
- Maximum length of power cables are decided within 10% of power drop. If it exceeds, you must consider another power supplying method.
- The circuit breaker (ELCB or MCCB+ELB) should be considered more capacity if many indoor units are connected from one breaker.
- Use round pressure terminal for connections to the power terminal block.
- For wiring, use the designated power cable and connect it firmly, then secure to prevent out-side pressure being exerted on the terminal board.
- Use an appropriate screwdriver for tightening the terminal screws. A screwdriver with a small head will strip the head and make proper tightening impossible.
- Over-tightening the terminal screws may break them.
- See the table below for tightening torque for the terminal screws.

Tightening torque		
	N•m	ft•lb
M 3.5	0.8 ~ 1.2	0.59 ~ 0.89
M 4	1.2 ~ 1.8	0.89 ~ 1.33

(1 N•m = 10 kgf•cm)




## Step 12 Setting the indoor unit addresses and the installation options

You cannot set both indoor unit addresses and the installation options in a batch: set both respectively.

### Common steps for setting the addresses and options

#### Remote controls




#### NOTE

- The remote control display and buttons may vary depending on the model.

#### 1 Enter the mode for setting the options.

- Reset remote control: button Down + button Down + Press for 10 seconds
- You can see the "SW Initialization" message and enter the following in 5 seconds.
- Press button and button for 5 seconds.

- Make sure that you are entered to the mode for setting options.



#### 2 Set the option values.

#### CAUTION

- The total number of available options are 24 : SEG1 to SEG24
- Because SEG1, SEG7, SEG13 and SEG19 are the page options used by the previous remote control models, the modes to set values for these options are skipped automatically.
- Set a 2-digit value for each option pair in the following order.
- You can see 20 SEG ( except SEG1, SEG7, SEG13, SEG19) SEG2 → ... → SEG6 → SEG8 → ..... → SEG12 → SEG14 → .... → SEG18 → SEG20 → ... → SEG24

























SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
0	X	X	X	X	X
SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
1	X	X	X	X	X
SEG13	SEG14	SEG15	SEG16	SEG17	SEG18
2	X	X	X	X	X
SEG19	SEG20	SEG21	SEG22	SEG23	SEG24
3	X	X	X	X	X

- You can set the next SEG by pressing the button.
- You can change the digit value through the following operation.  
Left value: up or down, range : 0 ~ F  
Right value: up or down, range : 0 ~ F



















# Installation Procedure

Take the steps presented in the following table:

























Steps	Remote control display
<p><b>1</b> Set the SEG2 and SEG3 values:</p> <p><b>a</b> Set the SEG2 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p><b>b</b> Set the SEG3 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p>When you press the  or  button, values appear in the following order:  →  → ... →  → </p>	<div> SEG2</div> <div> SEG3</div>
<p><b>2</b> Press the  button to move to the next page.</p>	<div></div>
<p><b>3</b> Set the SEG4 and SEG5 values:</p> <p><b>a</b> Set the SEG4 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p><b>b</b> Set the SEG5 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p>When you press the  or  button, values appear in the following order:  →  → ... →  → </p>	<div> SEG4</div> <div> SEG5</div>
<p><b>4</b> Press the  button to move to the next page.</p>	<div></div>



























Steps	Remote control display
<p><b>5</b> Set the SEG6 and SEG8 values:</p> <p><b>a</b> Set the SEG6 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p><b>b</b> Set the SEG8 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p>When you press the  or  button, values appear in the following order: 0 → 1 → ... E → F</p>	 <p>SEG6</p>  <p>SEG8</p>
<p><b>6</b> Press the  button to move to the next page.</p>	
<p><b>7</b> Set the SEG9 and SEG10 values:</p> <p><b>a</b> Set the SEG9 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p><b>b</b> Set the SEG10 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p>When you press the  or  button, values appear in the following order: 0 → 1 → ... E → F</p>	 <p>SEG9</p>  <p>SEG10</p>
<p><b>8</b> Press the  button to move to the next page.</p>	



# Installation Procedure















Steps	Remote control display
<p><b>9</b> Set the SEG11 and SEG12 values:</p> <p><b>a</b> Set the SEG11 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p><b>b</b> Set the SEG12 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p>When you press the  or  button, values appear in the following order:  →  → ... →  → </p>	 SEG11  SEG12
<p><b>10</b> Press the  button to move to the next page.</p>	
<p><b>11</b> Set the SEG14 and SEG15 values:</p> <p><b>a</b> Set the SEG14 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p><b>b</b> Set the SEG15 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p>When you press the  or  button, values appear in the following order:  →  → ... →  → </p>	 SEG14  SEG15
<p><b>12</b> Press the  button to move to the next page.</p>	



Steps	Remote control display
<p><b>13</b> Set the SEG16 and SEG17 values:</p> <p><b>a</b> Set the SEG16 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p><b>b</b> Set the SEG17 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p>When you press the  or  button, values appear in the following order:   →  → ...  → </p>	 <p>SEG16</p>  <p>SEG17</p>
<p><b>14</b> Press the  button to move to the next page.</p>	
<p><b>15</b> Set the SEG18 and SEG20 values:</p> <p><b>a</b> Set the SEG18 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p><b>b</b> Set the SEG20 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p>When you press the  or  button, values appear in the following order:   →  → ...  → </p>	 <p>SEG18</p>  <p>SEG20</p>
<p><b>16</b> Press the  button to move to the next page.</p>	




# Installation Procedure

Steps	Remote control display
<p><b>17</b> Set the SEG21 and SEG22 values:</p> <p><b>a</b> Set the SEG21 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p><b>b</b> Set the SEG22 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p>When you press the  or  button, values appear in the following order: 0 → 1 → ... → E → F</p>	<div> SEG21</div> <div> SEG22</div>
<p><b>18</b> Press the  button to move to the next page.</p>	<div></div>
<p><b>19</b> Set the SEG23 and SEG24 values:</p> <p><b>a</b> Set the SEG23 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p><b>b</b> Set the SEG24 value by pressing the  button repeatedly until the value you want to set appears on the remote control display.</p> <p>When you press the  or  button, values appear in the following order: 0 → 1 → ... → E → F</p>	<div> SEG23</div> <div> SEG24</div>







- 3 Check whether the option values you have set are correct by pressing the  button repeatedly.








EX) VWMC\*\*\*S4-4P


020010-100011-200000-300000

- 4 Save the option values into the indoor unit:  
Point the remote control to the remote control sensor on the indoor unit and then press the  button on the remote control twice.  
Make sure that this command is received by the indoor unit. When it is successfully received, you can hear a short sound from the indoor unit. If the command is not received, press the  button again.

- 5 Check whether the product operates following the option values you have set:

- a Reset the indoor or outdoor unit.
- Indoor Unit : Press  button +  button for 5 seconds
  - Outdoor Unit : Press the K3 button

- b Reset remote control:  button Down +  button Down +  Press for 10 seconds  
You can see the "SW Initialization" message.



# Installation Procedure

## Setting an indoor unit address (MAIN/RMC)

- 1 Check whether power is supplied or not.
  - When the indoor unit is not plugged in, there should be additional power supply in the indoor unit.
- 2 Before installing the indoor unit, assign an address to the indoor unit according to the air conditioning system plan.
- 3 Assign an indoor unit address by wireless remote control.
 

The initial setting status of indoor unit ADDRESS(MAIN/RMC) is "0A0000-100000-200000-300000".

Option No. : 0AXXXX-1XXXXX-2XXXXX-3XXXXX

Option	SEG1		SEG2		SEG3		SEG4		SEG5		SEG6	
Explanation	PAGE		Mode		Setting Main address		100-digit of indoor unit address		10-digit of indoor unit		The unit digit of an indoor unit	
Indication and Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details
	0		A		0	No Main address	0~9	100-digit	0~9	10-digit	0~9	A unit digit
					1	Main address setting mode						
Option	SEG7		SEG8		SEG9		SEG10		SEG11		SEG12	
Explanation	PAGE		-		Setting RMC address		-		Group channel		Group address	
Indication and Details	Indication	Details			Indication	Details			Indication	Details	Indication	Details
	1				0	No RMC address			RMC1	0~F	RMC2	0~F
1			RMC address setting mode									



### CAUTION

- When A~F is entered to SEG5~6, the indoor unit MAIN ADDRESS is not changed.
- If you set the SEG3 as 0, the indoor unit will maintain the previous MAIN ADDRESS even if you input the option value of SEG5~6.
- If you set the SEG9 as 0, the indoor unit will maintain previous RMC ADDRESS even if you input the option value of SEG11~12.
- You cannot set SEG11 and SEG12 as F value at the same time.


## Setting an indoor unit installation option (suitable for the condition of each installation location)

- 1 Check whether power is supplied or not.
  - When the indoor unit is not plugged in, there should be additional power supply in the indoor unit.
- 2 Set the installation option according to the installation condition of an product.
  - The default setting of an indoor unit installation option is 020010-100000- 200000-300000.
  - Individual control of a remote control(SEG20) is the function that controls an indoor unit individually when there is more than one indoor unit.
- 3 Set the indoor unit option by wireless remote control.

## O2 series installation option

SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
0	2	-	External room temperature sensor / Minimizing fan operation when thermostat is off	Central control	-
SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
1	Use of drain pump	-	-	EEV Step when heating stops	Dew removal operation in Wind-Free mode / Evaporator Drying fan mode / Auto fan smart comfortable mode
SEG13	SEG14	SEG15	SEG16	SEG17	SEG18
2	External control	Setting the output of external control / External heater signal / Cooling operation signal / Free Cooling control signal	-	Buzzer	Number of hours using filter
SEG19	SEG20	SEG21	SEG22	SEG23	SEG24
3	Individual control of a remote control	Heating setting compensation / Removing condensated water in heating mode	EEV Step of stopped unit during oil return/ defrost mode	-	-

- When setting the option other than above SEG values, the option will be set as "0".
- SEG5 central control option is basically set as 1 (Use), so you don't need to set the central control option additionally.
- However, if the central control is not connected but it doesn't indicate an error message, you need to set the central control option as 0 (Disuse) to exclude the indoor unit from the central control.
- The external output of SEG15 is generated by VSTAT10P-1 connection. (Refer to the manual of VSTAT10P-1.)
- If you set the Maximum filter usage time (SEG18) option to a value other than 2 and 6, it is automatically set to 2 (1000 hours).
- If you set the Individual control with remote control (SEG20) option to a value other than 0 to 4, it is automatically set to 0 (Indoor 1).



# Installation Procedure

## 02 series installation option (Detailed)

Option No. : 02XXXX-1XXXX-2XXXX-3XXXX

Option	SEG1		SEG2		SEG3	SEG4				
Explanation	PAGE		Mode		-	Use of external room temperature sensor / Minimizing fan operation when thermostat is off				
Indication and Details	Indication	Details	Indication	Details		Indication	Details			
	0		2			Use of external room temperature sensor	Minimizing fan operation when thermostat is off			
						0	Default	Default		
						1	Use	Disuse		
						2	Disuse	Use (Heating) (*1)		
						3	Use	Use (Heating) (*1)		
						4	Disuse	Use (Cooling) (*1)		
						5	Use	Use (Cooling) (*1)		
						6	Disuse	Use (Heating / Cooling) (*1)		
						7	Use	Use (Heating / Cooling) (*1)		
						8	Disuse	Use (Cooling Ultra Low Fan ) (*1)		
						9	Use	Use (Cooling Ultra Low Fan ) (*1)		
						A	Disuse	Use (Heating / Cooling Ultra Low Fan ) (*1)		
						B	Use	Use (Heating / Cooling Ultra Low Fan ) (*1)		
Option					SEG5		SEG6		SEG7	
Explanation	Use of central control		-		PAGE		Use of drain pump (*2)			
Indication and Details	Indication	Details			Indication	Details	Indication		Details	
	0	Disuse			1		0	Disuse		
	1	Use					8	External drain pump signal use		

Option	SEG9	SEG10	SEG11		SEG12				
Explanation	-	-	EEV Step when heating stops		Dew removal operation in Wind-Free mode / Auto Evaporator Drying fan mode / Auto fan smart comfortable mode				
Indication and Details			Indication	Details	Indication	Dew removal operation in Wind-Free	Auto Evaporator Drying fan mode	Auto fan smart comfortable	
			0	Default value	0 (Default)	Maintain blade status in Wind-Free mode	Use every fan mode	Use	
			1	Stopped Unit's Noise Decreasing Setting	1	Cooling operation by opening the blade	Use every fan mode	Use	
			2-B	Running Unit's Noise Decreasing Setting (*3)	2	Maintain blade status in Wind-Free mode	Use only Wind-Free mode	Use	
					3	Cooling operation by opening the blade	Use only Wind-Free mode	Use	
					4	Maintain blade status in Wind-Free mode	Use every fan mode	Disuse	
					5	Cooling operation by opening the blade	Use every fan mode	Disuse	
					6	Maintain blade status in Wind-Free mode	Use only Wind-Free mode	Disuse	
7	Cooling operation by opening the blade	Use only Wind-Free mode			Disuse				
Option	SEG13		SEG14		SEG15			SEG16	
Explanation	PAGE		Use of external control		Setting the output of external control / External heater signal / Cooling operation signal / Free Cooling control signal			-	
Indication and Details	Indication	Details	Indication	Details	Indication	Details		-	-
	2		0	Disuse	0	External control (Thermo On)		-	-
					1	External control (Operation On)			
			1	ON/OFF control	2	External heater signal (*4)			
					3	External heater signal (*4)			
			2	OFF control	4	Cooling operation signal (*5)			
					5	Free Cooling control (Cooling Thermo On) (*6)			
			3	Window ON/OFF control	6	Free Cooling control (Cooling/Dry Thermo On) (*6)			

# Installation Procedure

Option	SEG17			SEG18		SEG19		SEG20	
Explanation	Buzzer control			Hours of filter usage		PAGE		Individual control of a remote control	
Indication and Details	Indication	Details		Indication	Details	Indication	Details	Indication	Details
	0	Use buzzer		2	1000 Hour	3		0 or 1	channel 1
	1	Disuse buzzer		6	2000 Hour			2	channel 2
								3	channel 3
							4	channel 4	
Option	SEG21			SEG22			SEG23	SEG24	
Explanation	Heating setting compensation / Removing condensated water in heating mode			EEV Step of stopped unit during oil return/ defrost mode			-	-	
Indication and Details	Indication	Details		Indication	Details				
		Heating Setting Compensation	Removing Condensated Water in Heating Mode						
	0	Default (*7)	Disuse	0	Default value				
	1	2 °C	Disuse						
	2	5 °C	Disuse						
	3	Default (*7)	Use (*8)	1	Oil return or Noise decreasing in defrost mode				
	4	2 °C	Use (*8)						
5	5 °C	Use (*8)							

(\*1) Minimizing fan operation when thermostat is off

- Fan operates for 20 seconds at an interval of 5 minutes in heat mode.
- Fan stops or operates Ultra low in Cooling when thermostat is off.

(\*2) If external drain pump signal is used, external control (SEG14) can't be used.

(\*3) It is only for wall-mounted indoor unit with EEV Integrated. If any design condition meets either of the following below, please set SEG11 to "7".

- The total number of wall-mounted indoor units with EEV Integrated in one (modular) system is more than 20.
  - The total number of wall-mounted indoor units with EEV Integrated in one (modular) system is more than "the total of one (modular) system's capacity(kW) / 2" ("the total of one (modular) system's capacity (BTU/h) / 6800").
- ex) Outdoor capacity 28kW → 28 / 2 = 14. The total number of wall-mounted indoor units with EEV Integrated in one (modular) system is more than 14.

Please refer to the EEV step table below for the system (for heating) at stop.

Indication			0	2	3	4	5	6	7	8	9	A	B
Stopped Unit's EEV step	Wall MountedWith EEV	A Step	100	90	100	110	120	130	160	200	250	300	400
		B Step	125	160	160	160	160	160	160	200	250	300	400
	Other Indoor Units except for wall mounted with EEV		Default	No Function									

(\*4) When the following 2 or 3 is used as external heater On/Off signal, the signal for monitoring external contact control will not be output.

2: Fan is turned on continually when the external heater is turned on.

3: Fan is turned off when the external heater is turned on with cooling only indoor unit

- If Fan is set to off for cooling only indoor unit by setting the SEG15=3, you need to use an external sensor or wired remote controller sensor to detect indoor temperature exactly.

(\*5) When indoor unit is in cooling or Dry mode, The output signal is "ON"

(\*6) For free cooling control, Economizer controller is required.

(\*7) Default setting value

- 4Way Cassette: 9 °F (5°C)
- Other indoor units: 3.6 °F (2°C)

(\*8) This function can be applied to 4 Way Cassette only. If the product operates the heating mode immediately after finishing the cooling mode, the condensated water in the drain pan becomes water vapor by the heat of the indoor unit heat exchanger. Since the water vapor might be condensed on the indoor unit, which may fall into a living space, use this function to get rid of the water vapor out of the indoor unit by operating the fan (for maximum 20 minutes) even when the indoor unit is turned off after cooling mode is turned to heating mode.

# Installation Procedure

## 05 series installation option

SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
0	5	Use of Auto Change Over for HR only in Auto mode / Use of Cooling only indoor unit of HR	(When setting SEG3) Standard heating temp. Offset	(When setting SEG3) Standard cooling temp. Offset	(When setting SEG3) Standard for mode change Heating → Cooling
SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
1	(When setting SEG3) Standard for mode change Cooling → Heating	(When setting SEG3) Time required for mode change	Compensation option for Long pipe or height difference between indoor units	MTFC	-
SEG13	SEG14	SEG15	SEG16	SEG17	SEG18
2	-	-	-	-	Control variables when using hot water / external heater
SEG19	SEG20	SEG21	SEG22	SEG23	SEG24
3	-	-	-	Forced FAN Operation for Heating and Cooling	-

## 05 series installation option (Detailed)

Option No. : 02XXXX-1XXXXX-2XXXXX-3XXXXX

Option	SEG1		SEG2		SEG3		SEG4		SEG5		SEG6	
Explanation	PAGE		MODE		Use of Auto Change Over for HR only in Auto mode / Use of Cooling only indoor unit of HR		(When setting SEG3) Standard heating temp. Offset		(When setting SEG3) Standard cooling temp. Offset		(When setting SEG3) Standard for mode change Heating → Cooling	
Indication and Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details
	0		5		0	Follow product option	0	0 °F (0 °C)	0	0 °F (0 °C)	0	1.8 °F (1.0 °C)
							1	0.9 °F (0.5 °C)	1	0.9 °F (0.5 °C)	1	2.7 °F (1.5 °C)
					1	Use Auto Change Over for HR only	2	1.8 °F (1.0 °C)	2	1.8 °F (1.0 °C)	2	3.6 °F (2.0 °C)
							3	2.7 °F (1.5 °C)	3	2.7 °F (1.5 °C)	3	4.5 °F (2.5 °C)
							4	3.6 °F (2.0 °C)	4	3.6 °F (2.0 °C)	4	5.4 °F (3.0 °C)
					2	Use Cooling only indoor unit for HR	5	4.5 °F (2.5 °C)	5	4.5 °F (2.5 °C)	5	6.3 °F (3.5 °C)
							6	5.4 °F (3.0 °C)	6	5.4 °F (3.0 °C)	6	7.2 °F (4.0 °C)
							7	6.3 °F (3.5 °C)	7	6.3 °F (3.5 °C)	7	8.1 °F (4.5 °C)



Option	SEG7		SEG8		SEG9		SEG10		SEG11		SEG12
Explanation	PAGE		(When setting SEG3) Standard for mode change Cooling → Heating		(When setting SEG3) Time required for mode change		Compensation option for Long pipe or height difference between indoor units		MTFC (*3)		
Indication and Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	
	1		0	1.8 °F (1.0°C)	0	5min	0	Default	0	Default	-
			1	2.7 °F (1.5°C)	1	7min	1	(*1) Height difference is more than 30m or (*2) Distance is longer than 110m			
			2	3.6 °F (2.0°C)	2	9min					
			3	4.5 °F (2.5°C)	3	11min					
			4	5.4 °F (3.0°C)	4	13min	2	(*1) Height difference is 15~30m or (*2) Distance is 50~110m	2	Use	
			5	6.3 °F (3.5°C)	5	15min					
			6	7.2 °F (4.0°C)	6	20min					
	7	8.1 °F (4.5°C)	7	30min							
Option	SEG13		SEG14	SEG15	SEG16	SEG17	SEG18				
Explanation	-		-	-	-	-	Control variables when using hot water / external heater (*4)				
Indication and Details	Indication	Details					Indication	Details			
	2							Set temp. for heater On/Off		Delay time for heater On	
							0	At the same time as thermo on		No delay	
							1	At the same time as thermo on		10 minutes	
							2	At the same time as thermo on		20 minutes	
							3	2.7 °F (1.5°C)		No delay	
							4	2.7 °F (1.5°C)		10 minutes	
							5	2.7 °F (1.5°C)		20 minutes	
							6	5.4 °F (3.0°C)		No delay	
							7	5.4 °F (3.0°C)		10 minutes	
							8	5.4 °F (3.0°C)		20 minutes	
							9	8.1 °F (4.5°C)		No delay	
							A	8.1 °F (4.5°C)		10 minutes	
							B	8.1 °F (4.5°C)		20 minutes	
							C	10.8°F (6.0°C)		No delay	
							D	10.8°F (6.0°C)		10 minutes	
							E	10.8°F (6.0°C)		20 minutes	

# Installation Procedure

Option	SEG19		SEG20	SEG21	SEG22	SEG23			SEG24		
Explanation	PAGE		-	-	-	Forcing FAN Operation for Heating and Cooling			-		
Indication and Details	Indication	Details				3				Details	
										Cooling Fan Setting	Heating Fan Setting
	0	Disuse								Disuse	
	1	Disuse								Use (Fan: User setting)	
	2	Disuse								Use (Fan: High)	
	3	Disuse								Use (Fan: Low)	
	4	Use (Fan: User setting)								Disuse	
	5	Use (Fan: User setting)								Use (Fan: User setting)	
	6	Use (Fan: User setting)								Use (Fan: High)	
	7	Use (Fan: User setting)								Use (Fan: Low)	
	8	Use (Fan: High)								Disuse	
	9	Use (Fan: High)								Use (Fan: User setting)	
	A	Use (Fan: High)								Use (Fan: High)	
	B	Use (Fan: High)								Use (Fan: Low)	
	C	Use (Fan: Low)								Disuse	
	D	Use (Fan: Low)								Use (Fan: User setting)	
E	Use (Fan: Low)	Use (Fan: High)									
F	Use (Fan: Low)	Use (Fan: Low)									

(\*1) Height difference : The difference of the height between the corresponding indoor unit and the indoor unit installed at the lowest place. For example, When the indoor unit is installed 131.23 ft. (40 m) higher than the indoor unit installed at the lowest place, select the option "1".

(\*2) Distance : The difference between the pipe length of the indoor unit installed at farthest place from an outdoor unit and the pipe length of the corresponding indoor unit from an outdoor unit. For example, when the farthest pipe length is 328 ft. (100 m) and the corresponding indoor unit is 131.23 ft. (40 m) away from an outdoor unit, select the option "2". (100 - 40 = 196.85 ft. (60m))

(\*3) For MTFC option, MTFC(Multi Tenant Function Controller) kit is required.

(\*4) Heater operation when the SEG9 of 02 series installation option is set to using hot water heater or when SEG15 is set to using external heater


e.g. 1) Setting 02 series SEG9 = "1" / Setting 05 series SEG18 = "0": Hot water heater is turned on at the same time as the heating thermostat is on, and turned off when the heating thermostat is off.

e.g. 2) Setting 02 series SEG15 = "2" / Setting 05 series SEG18 = "A":

- Room temp. ≤ set temp. + f (heating compensation temp.)  
External heater is turned on when the temperature is maintained as 8.1 °F (4.5 °C) for 10 minutes.
- Room temp. > set temp. + f (heating compensation temp.)  
External heater is turned off when the temperature is maintained as 8.1 °F (4.5 °C) + 1.8 °F (1 °C). (1.8 °F (1 °C) is the Hysteresis for On/Off selection.)

### SEG 3, 4, 5, 6, 8, 9 additional information

When the SEG3 is set as "1" and follow Auto Change Over for HR only operation, it will operate as follows.



Cooling/Heating mode can be changed when Thermo Off status is maintained during the time with SEG9.



# Installation Procedure

## Changing a particular option

You can change each digit of set option.

Option	SEG1		SEG2		SEG3		SEG4		SEG5		SEG6	
Explanation	PAGE		MODE		The option mode you want to change		The tens' digit of an option SEG you will change		The unit digit of an option SEG you will change		Changed value	
Indication and Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details
	0		D		Option mode	1~6	Tens' digit of SEG	0~9	Unit digit of SEG	0~9	The changed value	0~F



### NOTE

- When changing a digit of an indoor unit address setting option, set the SEG3 as 'A'.
- When changing a digit of indoor unit installation option, set the SEG3 as '2'.

Ex) When setting the 'buzzer control' into disuse status.

Option	SEG1		SEG2		SEG3		SEG4		SEG5		SEG6	
Explanation	PAGE		MODE		The option mode you want to change		The tens' digit of an option SEG you will change		The unit digit of an option SEG you will change		Changed value	
Indication	0		D		2		1		7		1	






### CAUTION

- If you are using heat pump model, mixed operation mode (two or more indoor units operating in different operation mode simultaneously) is not available when the indoor units are connected to same outdoor unit. If you set the main indoor unit with a remote control, outdoor unit will operate in the mode which was set in the main indoor unit.




### Step 13 Performing the final check

To complete the installation, perform the following checks and tests to ensure that the product operates correctly.

- 1 Check the following:
  - Strength of the installation site
  - Tightness of pipe connection to detect gas leak
  - Electric wiring connection
  - Heat-resistant insulation of the pipe
  - Drainage
  - Grounding conductor connection
  - Correct operation (follow the steps below)
- 2 Press the  button and check the following:
  - The indicator on the indoor unit lights up.
  - The airflow blade opens and the fan gears up for operation.
- 3 Press any button and check the following:
  - The appropriate indicator lights up and the product operates according to the selected mode or function.
- 4 Press the  button and check the following:
  - The airflow blades work properly.
- 5 Press the  button and check the following:
  - The airflow blades work properly.

#### NOTE

- The  button is only for Wind-Free models.

### Step 14 Providing information for user

After finishing the installation of the product, you should explain the following to the user. Refer to appropriate pages in the user & installation manual.

- 1 How to start and stop the product
- 2 How to select the modes and functions
- 3 How to adjust the temperature and fan speed
- 4 How to adjust the airflow direction
- 5 How to set the timers
- 6 How to clean and replace the filters

#### NOTE

- When you complete the installation successfully, hand over the user & installation manual to the user for storage in a handy and safe place.

### Step 15 Charging additional refrigerant

The amount of additional refrigerant for each indoor unit.

Model	Charging additional refrigerant lb (kg)
VWMC005S4-4P VWMC007S4-4P	0.51 (0.23)
VWMC009S4-4P VWMC012S4-4P	0.71 (0.32)
VWMC015S4-4P VWMC018S4-4P VWMC024S4-4P	1.06 (0.48)
VWMC028S4-4P	1.41 (0.64)

# Troubleshooting

If a problem occurs to the product, the following error codes will appear on the display of the indoor unit or outdoor unit.

## Error detection and re-operation

- If an error occurs during operation, an error code will appear and all the operations are stopped except the display panel.
- If you re-operate the product by a remote controller or switch, it will operate normally at first, then detect an error.

## Detected errors indicated on display

Error description	Error code
Error on indoor room temperature sensor (Open/short)	E121
1. Error on Eva-in sensor (Open/short)	E122
2. Error on Eva-out sensor (Open/short)	E123
3. Error on Indoor Fan	E154
1. Error on outdoor temperature sensor	E221
2. Error on cond sensor	E237
3. Error on discharge sensor	E251
Other outdoor unit sensor errors that are not on the above list	
1. When there is no communication between the indoor and outdoor units for 2 minutes	E101
2. Communication error received from the outdoor unit	E102
3. 3 minute tracking error on outdoor unit	E202
4. Communication error after tracking due to unmatching number of installed units	E201
5. Error due to using the same communication address twice.	E108
6. Error due to incomplete communication address setting	E109
Other outdoor unit communication errors that are not on the above list	
Self diagnosis error display	
1. Error due to opened EEV (2nd detection)	E151
2. Error due to closed EEV (2nd detection)	E152
3. Eva in sensor is detached	E128
4. Eva out sensor is detached	E129
5. Thermal Fuse Open Error	E198
1. COND mid sensor is detached	E241

Error description	Error code
2. Refrigerant leakage (2nd detection)	E554
3. Abnormally high temperature on Cond (2nd detection)	E450
4. Low pressure s/w (2nd detection)	E451
5. Abnormally high temperature on discharged air on outdoor unit (2nd detection)	E416
6. Indoor unit shut-down due to unconfirmed error on outdoor unit	E559
7. Error due to reverse phase detection	E425
8. Comp stop due to freeze detection (6th detection)	E403
9. High pressure sensor is detached	E301
10. Low pressure sensor is detached	E306
11. Outdoor unit compression ratio error	E428
12. Outdoor sump down_1 protection control	E413
13. Compressor down due to low pressure sensor protection control_1	E410
14. Simultaneous opening of cooling/heating MSB SOL valve (1st detection)	E180
15. Simultaneous opening of cooling/heating MSB SOL valve (2nd detection)	E181
Other outdoor unit self-diagnosis errors that are not on the above list	
External contact input error	E665
EEPROM error	E162
EEPROM option error	E163
Error due to incompatibility with an indoor unit that special consumption tax is applied.	E164

- If you turn off the product when the error display is on, all the displays are turned off.
- If you re-operate the product, it will operate normally at first, then detect and display an error again.
- When E108 error occurs, change the address and reset the system.  
e.g. When the address of the indoor unit #1 and #2 are set as 5, address of the indoor unit #1 will become 5 and indoor unit #2 will display E108, A002.
- The E665 error occurs when the 02 series installation option (SEG8) is set to "External drain pump use" and the external contact input (VSTAT10P-1) is open.

