



VRF

©2019 Lennox Industries Inc. Dallas, Texas, USA



THIS MANUAL MUST BE LEFT WITH THE OWNER FOR FUTURE REFERENCE

These instructions are intended as a general guide and do not supersede local codes in any way. Consult authorities having jurisdiction before installation.

⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life.

Installation and service must be performed by a licensed professional HVAC installer, service agency or the gas supplier.

Failure to follow safety warnings and these instructions exactly could result in property damage, dangerous operation, serious injury, or death.

Any additions, changes, or conversions required in order for the appliance to satisfactorily meet the application needs must be made by a licensed professional HVAC installer (or equivalent) using factory-specified parts.

Do not use this system if any part has been under water. A flood-damaged appliance is extremely dangerous. Immediately call a licensed professional HVAC service technician (or equivalent) to inspect the system and to replace all controls and electrical parts that have been wet, or to replace the system, if deemed necessary.

⚠ CAUTION

As with any mechanical equipment, contact with sharp sheet metal edges can result in personal injury. Take care while handling this equipment and wear gloves and protective clothing.

To ensure proper system performance and reliability, Lennox does not recommend operation of VRF systems during any phase of construction. Construction debris, low temperatures, harmful vapors, and operation of the unit with misplaced filters can damage the units. Failure to follow these guidelines will result in the warranty being voided.

INSTALLATION INSTRUCTION

VOSB Outside Air Ducted Units

VRF SYSTEMS -- Indoor Units

507896-02

06/2019

⚠ IMPORTANT

The Clean Air Act of 1990 bans the intentional venting of refrigerant (CFC's and HCFC's) as of July 1, 1992. Approved methods of recovery, recycling or reclaiming must be followed. Fines and/or incarceration may be levied for non-compliance.

General

The VOSB outside air ducted indoor units are matched with an outdoor heat recovery or heat pump unit to create a VRF (variable refrigerant flow) system that uses R-410A refrigerant. VOSB indoor units are designed for indoor installation only.

Refer to the Product Specification bulletin (EHB) for the proper use of these indoor units with specific heat pumps, heat recovery units, mode switching devices, branch pipes, line sets and controls.

Shipping and Packing List

Check the components for shipping damage. If you find any damage, immediately contact the last carrier.

Package 1 of 1 contains the following:

- 1 - Assembled high-static, concealed duct unit
- 1 - Digital Display Panel
- 2 - Refrigerant piping insulation sleeves
- 1 - Flexible condensate connector (VOSB036-054)
- 1 - Hose clamp (VOSB036-054)
- 1 - Condensate connection pipe (VOSB072-096) (Packed in Supply side of cabinet.)
- 1 - Roll tape for condensate pipe (VOSB072-096)
- 1 - Condensate overflow connection harness
- 1 - 120 Ohm End of Line Resistor
- 1 - Installation manual

Safety Requirements

⚠ WARNING

ELECTRICAL SHOCK, FIRE, OR EXPLOSION HAZARD.


Do not touch the unit or the controller if your hands are wet.

DO NOT spray water on the indoor unit for any reason.

Do not replace a fuse with a fuse of a different rating. Do not use a jumper wire to replace a fuse. Do not insert your hands, tools or any other item into the air intake or air outlet at either the indoor or outdoor unit.

Do not allow children to operate the system.

Model Number Identification



NOTE - Only Lennox VRF indoor units will work with Lennox VRF outdoor units and associated mechanical equipment. Lennox Mini Split indoor units are similar in appearance but must not be connected to a Lennox VRF refrigerant circuit. Please refer to model numbers to confirm compatibility. Model numbers for Lennox VRF units start with a "V" and model numbers for Lennox Mini-Splits start with a "M".

System Piping

⚠ CAUTION

VRF system piping is customized for each installation. The LVSS piping report is an engineered design that must be followed. The piping diagram or diagrams included within the LVSS report have been prepared based on the information provided to the Lennox VRF applications department.

When the indicated lengths change from the figures stated within the report, it is imperative that prior to the commencement of the refrigerant pipe work installation, Lennox VRF applications department are informed of these proposed changes.

Upon receipt of this new information the Lennox VRF applications department will confirm any changes that may be applicable to this installation. If changes are required, a new piping diagram will be produced and will supersede all other previously provided documents.



Failure to provide this information regarding changes to the original design may lead to insufficient capacity, equipment failure, warranty being made void and the refusal to commission the system.

⚠ NOTICE


When using as part of a VRF Heat Recovery system, refer to the specific pipe connection details located in the Mode Selection Box installation manual and the detailed drawing on page 16 of this manual.

Unit Dimensions - Inches (mm)


VOSB036, 048, 054




SECTION D-D



SECTION C-C








SECTION B-B



SECTION A-A



Unit Dimensions - Inches (mm)

VOSB072, 096



Clearances

Refer to Figure 1 for minimum clearance requirements.



NOTE - No part of the suspended ceiling, or other supports not directly associated with the indoor unit installation, can be fixed to, or touch the indoor unit, in any form. Minimum clearances must be observed at all times.

NOTE - Horizontal installation only.

Figure 1. Minimum Installation Clearances

Unit Placement

WARNING

Do not install the unit in an area where flammable materials are present due to risk of explosion resulting in serious injury or death.

Check suitability of structure to which the unit support mechanism will be fixed to. If structure is not capable of carrying the weight of the unit, unit may fall causing personal injury or equipment damage.

Use the provided and specified components when installing equipment. Failure to do so may result in unit falling, water leaking or electrical shocks, causing personal injury or equipment or property damage.

Consider the possibility of earthquakes in your area when installing the equipment. If the unit is not correctly secured, it may fall, causing personal injury or equipment damage.

Safely dispose of packing materials, which include nails, wood and other sharp objects, as well as plastic wrapping. Children playing with plastic wrap or bags risk the danger of suffocation.

CAUTION

Do not place items which may be damaged by water under or around the unit.

The unit should be installed at least 8 feet above the floor (if possible) to ensure maximum performance and comfort.

AVOID

Do not install the unit in the following locations:

- Areas near commercial kitchen exhaust hoods where odors and grease may enter the air stream.
- Areas near flue and/or exhaust vents where flue gasses, waste gasses, or debris may enter the air stream.
- Areas exposed to petrochemicals or petrochemical products
- Areas exposed to salt or other corrosive materials or caustic gasses
- Areas exposed to extreme voltage variations (such as factories)
- Tightly enclosed areas that may impede service of the unit
- Areas exposed to fossil fuels (such as oil or gas in kitchens)
- Areas exposed to strong electromagnetic forces
- Areas exposed to acids or alkaline detergents (laundry rooms)

DO:

- Locate the unit so that it is not exposed to direct sunlight
- Ensure the structural ceiling can support the weight of the unit.
- Select a location where condensate line will have the shortest run to a suitable drain per local codes.
- Allow sufficient space around unit for proper operation and maintenance
- Install unit a minimum of 3 feet away from any antenna, power cord (line) radio, telephone, security system, or intercom. Electrical interference and radio frequencies from any of these sources may affect operation

Installation

It is important to locate the unit where it can be accessed for service in the future. Refer to unit dimensions on Pages 3-5 for exact locations of suspension brackets, return air and supply air openings.

1. **Make sure that the structural ceiling or slab is able to support the weight of the indoor unit. It may be necessary to add extra support.**
2. Install suspension rods in the structural ceiling or concrete slab in a suitable location. If the structural ceiling is constructed of concrete, install anchors to accept four $\frac{3}{8}$ " threaded rods to suspend the indoor unit. If the structural ceiling includes wooden joists, use angle iron or Unistrut channel fixed securely in place to accept the $\frac{3}{8}$ " threaded rods. **NOTE - Threaded rod (requirement of Lennox warranty program) is the ONLY acceptable method of suspending the unit; do not use chains or straps.** See Figure 2.




Figure 2. Suspending Methods

3. Slide one nut and one washer onto each threaded rod. Use electrical tape to keep the washer from falling off. Position the nuts slightly above the final resting place of the four suspension brackets. See Figure 3.




Figure 3. Suspension Hardware




Figure 4. Isolation Grommet

4. Use either a mechanical lifting device or a minimum of two people to raise the unit and insert the threaded rods into the suspension brackets on the unit base. Slide a washer and then a nut onto each rod below each suspension bracket. Use the leveling nut (beneath suspension bracket) to adjust the unit to the correct height. Remove the electrical tape holding the upper washers and nuts in place and tighten each of the four nuts above the brackets down onto the brackets. This will ensure that the unit remains level.
5. It is recommended to install a field-provided isolation grommet as shown in Figure 4 to prevent transmission of vibration from unit to structural ceiling.
6. If the unit is being installed in an application that includes a sheet rock (plasterboard) ceiling, it is required that an access panel be installed in a suitable location. This will also allow access for future maintenance (requirement of Lennox warranty program). Access is required during the commissioning process to test the condensate disposal system and to check the local disconnect.
7. The unit is factory-configured for the supply air to be delivered from the front and the return air filter at the rear of the unit.

INSTALLATION GUIDELINES

- It is recommended to install a field-provided isolation grommet as shown in Figure 4 to prevent transmission of vibration from unit to structural ceiling.
- Provide separate support for the weight of the duct system. Duct system must not be supported by the indoor unit.
- Use flexible joints (canvas) at the point where the duct connects to the unit on both ends. Material must meet all local and national code requirements.
- When unit is being installed in a location where even the slightest noise would be a problem (meeting room or other very quiet space), design duct system to avoid transmission of vibration to the structure to the extent possible.
- When sizing the return air filter grille, a minimum surface area of 200 sq. in. per ton is recommended.

Return Air Filter

Return Air Filter

The factory-supplied return air filter is segmented to allow it to be separated if needed to remove it from the unit in tight spaces. The segments are connected with hook & loop (Velcro-style) straps. See Table 1 for filter dimensions.




Figure 5. Segmented Factory-Supplied Return Air Filter

Remove Return Air Filter Instructions

1. Loosen the screw that secures the filter retaining bracket and slide the bracket away from the unit.




Figure 6. Loosen Filter Retaining Bracket

2. Grasp the filter removal tab and slide the filter out.




Figure 7. Slide Out Filter




Figure 8. Filter Partially Removed

3. Reverse these steps to reinstall the filter. Be sure to reinstall the receiver if it was detached during the filter removal.

Table 1. Filter Dimensions

Indoor Unit Model	Filter Dimensions	Each Section of Filter Dimensions
VOSB036, 048, 054	42-5/8 x 13-1/4 x 3/8 in. 1083 x 336 x 10 mm	14-1/8 x 13-1/4 x 3/8 in. 359 x 336 x 10 mm
VOSB072, 096	44-1/2 x 13-1/4 x 3/8 in. 1130 x 336 x 10 mm	14-3/4 x 13-1/4 x 3/8 in. 375 x 336 x 10 mm

External Static Pressure

External Static Pressure setting on wired controller

- Use high speed air flow for selection and design.
- Set the external static pressure (ESP) on wired controller, the setting value should not be 0.2 in.w.g (50Pa) higher than the actual external static pressure of the duct.

Refrigerant Piping Connections

WARNING

Refrigerant leaks are unlikely; however, if a refrigerant leak occurs, open a door or windows to dilute the refrigerant in the room. Turn off the unit and all other appliances that may cause a spark. Call a licensed professional HVAC technician (or equivalent) to repair the leak.

Use only R410A refrigerant to charge this system. Use of other refrigerant or gas will damage the equipment.

Do not allow air or other contaminants to enter system during installation of refrigerant piping. Contaminants will result in lower system capacity and abnormally high operating pressures and may result in system failure or explosion.

Insulate all refrigerant piping.

Refrigerant pipes may be very hot during unit operation. Do not allow contact between wiring and bare copper pipes.

After refrigerant piping connections have been completed, check the system for leaks per commissioning instructions.

WARNING



Danger of fire. Bleeding the refrigerant charge from only the high side may result in pressurization of the low side shell and suction tubing. Application of a brazing torch to a pressurized system may result in ignition of the refrigerant and oil mixture. Check the high and low pressures before applying heat.

CAUTION

Brazing alloys and flux contain materials which are hazardous to your health.

Avoid breathing vapors or fumes from brazing operations. Perform operations only in well-ventilated areas.

Wear gloves and protective goggles or face shield to protect against burns.

Wash hands with soap and water after handling brazing alloys and flux.

CAUTION

Purge low pressure nitrogen [1 to 2 psig (6.0 to 12.8 kPA)] through the refrigerant piping during brazing. This will help to prevent oxidation and the introduction of moisture into a system.

To prevent the build-up of high levels of nitrogen when purging be sure it is done in a well ventilated area.

IMPORTANT

Refrigerant lines must be clean, dry, refrigerant-grade copper lines. Air handler coils should be installed only with specified line sizes for approved system combinations.

Handle refrigerant lines gently during the installation process. Sharp bends or kinks in the lines will cause restrictions.

IMPORTANT

Only use brazing rods/sticks which are suitable/recommended for air conditioning pipework installations - Do Not Use Soft Solder.

IMPORTANT

The compressor in the unit this air handler is matched with contains PVE oil (Polyvinyl ether). PVE oil is formulated for hydrofluorocarbon (HFC) refrigerants, such as R410A, which this system contains. While it may have some miscibility properties with mineral-based oil and POE oil (Polyolester), it is not recommended to mix PVE oil with any other type of refrigerant oil.

- Refrigerant lines must be connected by a qualified technician in accordance with established procedures.
- Field provided piping consists of two HVAC/R rated copper lines connected to the indoor unit.
- Final equipment connections must be brazed connections. Compression or other types of fittings are not permitted for final connections.
- All refrigerant piping shall be free of defects, debris, and oil.
- Copper-phosphorous brazing alloys are to be used to join all pipework connections where applicable.
- Always flow/purge nitrogen to avoid oxidation while brazing.
- Always use an appropriate heat absorption compound to protect the unit and internal sensors from conductive heat while brazing.

1. The seal on the unit refrigerant piping connections should remain in place until the last possible moment. This will prevent dust or moisture from getting into the refrigerant piping before it is connected.
2. Prior to brazing remove rubber air grommets from indoor unit refrigerant line ports.
3. Slowly loosen one of the rubber plugs to release the factory nitrogen charge. Remove the rubber plug from both liquid and gas lines.
4. Connect the liquid and gas lines to the evaporator coil.
5. Reinstall the rubber grommets into the refrigerant piping panel.
6. Insulate both pipes individually.

Table 2. Refrigerant Piping Connections

Indoor Unit Size (Btuh)	Liquid Line	Vapor Line
36,000 48,000 54,000	3/8"	5/8"
72,000 96,000	3/8"	7/8"

Sealing the Unit

Seal the unit so that warm air is not allowed into the cabinet. Warm air introduces moisture, which results in condensation problems.

This is especially important when the unit is installed in an unconditioned area.

If installed in an unconditioned space, sealant should be applied around the electrical wires, refrigerant tubing, and condensate lines where they enter the cabinet.

WARNING

There must be an air-tight seal between the unit and the return air plenum. Use fiberglass sealing strips, caulking, or equivalent sealing method between the plenum and the air handler cabinet to ensure a tight seal. Return air must not be drawn from a room where this unit or any gas-fueled appliance (i.e. water heater) or carbon monoxide-producing device (i.e. wood fireplace) is installed.

Condensate Piping Connections

VOSB036-054 indoor units have a factory-installed condensate lift pump capable of 28 inches (711 mm) of lift and one gravity drain connection on each side of the unit. If using gravity drain, select one connection to use and leave the unused connection port sealed.

Seal and plug the lift pump connection port when using a gravity drain connection port. Disconnect the factory-installed lift pump that is connected to the CN labeled PUMP..

VOSB072-096 indoor units have one gravity drain connection.

⚠ CAUTION

Make sure that drain piping is properly routed and insulated in order to prevent both leaks and condensation. Follow these instructions exactly to ensure proper drainage and unit operation.

1. Use the provided hose clamp to secure the provided flexible condensate drain connector and insulating sleeve to the drain line stub on the side of the indoor unit. See Figure 9. **NOTE** - Take care not to over-tighten the hose clamps this may damage the drain line stub.




Figure 9. Condensate Drain Connection

⚠ IMPORTANT

You must confirm operation of every drain and pump in the system as part of the commissioning procedure.

2. Make a water-tight connection between the field-provided condensate drain line and the flexible condensate connector (1" I.D.).

3. See Figure 10 for applications including a single unit and a single gravity drain. In this case, ensure that the drain line is properly sloped (no less than 1/4 inch per foot) and condensate lines are routed to ensure moisture is drained away from the indoor unit.




Figure 10. Sloped Condensate Gravity Drain Single Unit

⚠ IMPORTANT

Drain should have a slope of at least 1/4 inch per foot and should be approved corrosion-resistant pipe.

4. See Figure 12 for applications including multiple units and a single gravity drain. In this case, ensure that the drain line is properly sloped (no less than 1/4 inch per foot) and condensate lines are routed to ensure moisture is drained away from the indoor unit. See
5. See Figure 11 for applications including a single unit using the factory-mounted lift pump.




Figure 11. Condensate Drain with Lift Pump Single Unit

6. See Figure 13 for applications including multiple units using the internal lift pump to provide lift into a single, correctly sized main drain. In this case, ensure that the main drain line is properly sloped, no less than 1/4 inch per foot (6 mm per 305 mm), and that each individual drain is connected to the main drain exactly as shown.




Figure 12. Scaled Condensate Gravity Drain Multiple Indoor Units




Figure 13. Condensate Drain with Lift Pump Multiple Indoor Units

7. In all cases, drain should be as short as possible and should not have any droops or kinks that would restrict condensate flow and shall be constructed using an approved pipe. All drains should contain traps. **There must be a 2-inch space between the end of the condensate drain and the final termination point (ground, open drain, etc.) to ensure that the line will drain freely.**
8. **After system installation is complete, the condensate drain line must be checked for leaks and if a condensate pump has been fitted, it must be checked to ensure proper operation. This check is part of the commissioning procedure.**

Table 3. Condensate Pump Accessory Options

Capacity	Brand	Model Name	Model #	Cat #	Max Flow Rate (gal per hr)	Max head	Max suction lift*
VOSB072-096	Lennox VRF	Drain Pump Kit	V8DRNP05	17U32	-	18 in	-
	Blue Diamond	MegaBlue	X87-835	14T71	13.2	66.5 ft	23 ft

*Optional pump maximum suction lift is measured from the pump outlet.

Table 4. Condensate Connection Sizes

Model	Condensate Life Pump Factory Mounted	Condensate Pump Lift Measurement	Condensate Pump Facility on Indoor PCB Board	Condensate Outlet of Indoor Unit	Flexible Drain Connection (supplied with unit)
VOSB Outside Air Ducted	Yes - 036-054 No - 072/096	18 "	Yes	1" O.D. 1-5/8" O.D. adapter provided	1" I.D.

Using an External Water Level Switch

1. Disconnect the closed circuit loop connection labeled WATER.
2. Connect the provided overflow harness accessory to the WATER connection. See Figure 14.
3. See unit wiring diagrams for location of the WATER connection.

The connection has 5 VDC current, do not supply field voltage.

Table 3 lists available external condensate pump accessories. See Table 4 for connection sizes.




Figure 14. External Water Level Switch Connection

Wiring Connections

⚠ WARNING

Isolate the power supply before accessing unit electrical terminals.

Install unit so that unit disconnect is accessible.

Follow all local and national codes, as well as this installation instruction, during installation. Do NOT overload electrical circuit, as this may lead to failure and possible fire.

Use specified wiring and cable to make electrical connections. Clamp cables securely and make sure that connections are tight to avoid strain on wiring. Insecure wiring connections may result in equipment failure and risk of fire.

Wiring must be installed so that all cover plates can be securely closed.

- Do not attempt to repair a damaged power cord.
- Do not modify the power cord in any way. Do not attempt to extend the length of the power cord or use an extension cord with this appliance. Do not share the single power outlet with any other appliances.

- Indoor and outdoor unit equipment must each be on their own a dedicated breaker.
- Indoor units must have a dedicated service disconnect. Switches are acceptable; however it must be a double pole switch that disconnects L1 and L2.

⚠ CAUTION

This unit must be properly grounded and protected by a circuit breaker. The ground wire for the unit must not be connected to a gas or water pipe, a lightning conductor or a telephone ground wire.

Do not connect power wires to the outdoor unit until all other wiring and piping connections have been completed.

Install all wiring at least 3 feet away from televisions, radios or other electronic devices in order to avoid the possibility of interference with the unit operation.

Do not install the unit near a lighting appliance that includes a ballast. The ballast may affect remote control operation.

In the U.S.A., wiring must conform with current local codes and the current National Electric Code (NEC). In Canada, wiring must conform with current local codes and the current Canadian Electrical Code (CEC).

Refer to unit nameplate for minimum circuit ampacity and maximum overcurrent protection size.

NOTE - Two-conductor stranded shielded cable must be used for the communication wiring. This is necessary to ensure proper system communication and operation.

1. Remove the screws that secure the control box cover. Remove the cover and place it to the side where it will not be damaged.
2. Locate the terminal strip in the control box. Connect the power wiring (sized per NEC/CEC and local codes) and communications cable (two-conductor shielded cable). Refer to unit nameplate for rated voltage.
3. If the indoor unit is the final unit in a group that is wired in series, install the provided resistor across terminals P and Q.

Indoor units and mode selection boxes on the same refrigeration circuit should have a common power supply but must have an independent disconnect switch installed adjacent to each item of equipment for servicing and maintenance purposes. Indoor unit and mode selection box power supply MUST not be taken from the outdoor unit. Always follow NEC/CEC and Local Codes.




Figure 15. Typical Power Wiring Diagram (VRF Heat Recovery System Shown)




Figure 16. Typical Communication Wiring Diagram (VRF Heat Recovery System)




Figure 17. Typical Communication Wiring Diagram (VRF Heat Pump System)

Tightening torque for the terminal screws

- Use the correct screwdriver for tightening the terminal screws.
- If the terminal screws are over tightened, screws might be damaged.
- Refer to Table 5 for the tightening torque of the terminal screws.

Table 5. Terminal Screw Tightening Torque

	Tightening torque (lb-ft)
Terminal base of remote controller/Signal transmission wire (X2M)	0.58-0.72
Terminal base of power supply (X1M)	0.87-1.06
Grounding terminal (M4)	1.06-1.43

- After wiring, confirm all connections are correct; Then turn on power supply to the unit.

⚠ IMPORTANT


DO NOT adjust DIP switch settings. Settings may only be adjusted by a trained technician as part of the commissioning procedures.

Error code	Error Content
E0	● Mode conflict
E1	● Communication error between indoor and main outdoor unit
E2	● T0 (Inlet air temperature sensor) malfunction
E3	● T2 (Middle of evaporator sensor) malfunction
E4	● T2B (Outlet of evaporator sensor) malfunction
E5	● T2A (Inlet of evaporator sensor) malfunction
E6	● DC fan motor error
E7	● EEPROM failure
EC	● TA (Outlet air temperature sensor) malfunction

Error code	Error Content
U4	● MS self-inspection error
F8	● MS error
Eb	● EEV malfunction
Ed	● Outdoor unit fault
EE	● High water alarm
FE	● No address
A0	● Emergency stop
D8	● Remote off

Code	Title
FM	Indoor fan motor
T0	Inlet air temperature sensor
T2A	Inlet of evaporator sensor
T2B	Outlet of evaporator sensor
T2	Middle of evaporator sensor
TA	Outlet air temperature sensor
XP1-5	Connectors

Code	Title
XS1-5	Connectors
XT1-2	Terminals
PUMP	Pump motor
CS	Water level switch
ALARM	Warning lamp
EEV	Electronic expansion valve
SVD	Solenoid valve



NOTE:
 1. Refer to manual for communication wiring
 2. Please use the 2-conductor shielded twisted cable for communication


NOTE:
 Component in dash line is optional or field wiring

Typical wiring diagram. Refer to wiring diagram on the unit for actual wiring.

**Figure 18. VOSB036H4-3, VOSB048H4-3, & VOSB054H4-3
 Typical Wiring Diagram**

Error code	Error Content	Error code	Error Content
E0	● Mode conflict	U4	● MS self-inspection error
E1	● Communication error between indoor and main outdoor unit	F8	● MS error
E2	● T0 (Inlet air temperature sensor) malfunction	Eb	● EEV malfunction
E3	● T2 (Middle of evaporator sensor) malfunction	Ed	● Outdoor unit fault
E4	● T2B (Outlet of evaporator sensor) malfunction	EE	● High water alarm
E5	● T2A (Inlet of evaporator sensor) malfunction	FE	● No address
E6	● DC fan motor error	A0	● Emergency stop
E7	● EEPROM failure	D8	● Remote off
EC	● TA (Outlet air temperature sensor) malfunction		

Code	Title	Code	Title
FM	Indoor fan motor	XS1-6	Connectors
T0	Inlet air temperature sensor	XT1-2	Terminals
T2A	Inlet of evaporator sensor	PUMP	Pump motor
T2B	Outlet of evaporator sensor	CS	Water level switch
T2	Middle of evaporator sensor	ALARM	Warning lamp
TA	Outlet air temperature sensor	EEV	Electronic expansion valve
XP1-6	Connectors	SVD	Solenoid valve



Typical wiring diagram. Refer to wiring diagram on the unit for actual wiring.

Figure 19. VOSB072H4-3 and VOSB096H4-3 Typical Wiring Diagram

Dip-switch setting:

See Table 6 for allowed indoor to outdoor unit combinations.

Use the SW8-1 dip switch to set whether or not the all of the indoor units in the system are VOSB units or if there is a mix of indoor units in the system.

0 - All indoor units in the system are VOSB.

1 - VOSB and common indoor units mix in one system.

Table 6. VOSB Indoor Unit to Outdoor Unit Allowed Connection Ratio

Outdoor Unit	Indoor Unit	IDU/ODU Connection Ratio	VOSB/ODU Connection Ratio
Heat Pump	VOSB Only	≤100%	≤100%
Heat Pump	VOSB + other indoor units	≤100%	≤30%
Heat Recovery	VOSB Only	NOT ALLOWED	NOT ALLOWED
Heat Recovery	VOSB + other indoor units	≤100%	≤30%

Relocate T0 Return Air Sensor

Relocate the unit return air from inside the unit to a location within the conditioned zone whenever the return is pulling air from above the ceiling or if fresh air is being introduced and mixed into the return. The T0 sensor cannot accurately read the space temperature under these conditions if the sensor remains located inside of the unit.

This sensor can be extended with 18 AWG stranded shielded cable.

1. Identify the T0 connection on the main board - CN4. (white wires soldered to PCB)




Figure 20. Identify T0 Sensor Connection on PCB

2. Identify where the white wire is plugged into the black wire.




Figure 21. Identify White Plug into Black Wire

3. Cut the black wire between the plug and the sensor thermistor. Leave adequate room for making wiring connections on each end.




Figure 22. Cut the Black Wire

4. Prepare the 18 AWG stranded shielded extension cable.
5. Solder the extension cable to the black wire on each end or use the VRF accessory V0SNSR00P (13G99) to splice in the extension cable.
6. Locate the return air thermistor to the conditioned area of which the indoor unit serves.





Figure 23. Sensor Thermistor

⚠ IMPORTANT

Avoid installing sensor in high load or heat loss areas such as exterior walls or walls that are against unconditioned spaces, near entry doors and windows, or where direct sunlight may be present.



Typical wiring diagram. Refer to wiring diagram on the unit for actual wiring.

Figure 24. Identify T0 Sensor on Wiring Diagram




Figure 25. Typical Wiring Connections

Setting Blower Operation

Blower cycling can be configured to determine indoor operation.

- Default operation is indoor unit blower OFF when the indoor unit is in thermo OFF.
- Settings can be adjusted in the -3P controller and cannot be configured at the indoor unit PCB.

- Consult the specific controller manual for detailed blower setting information.

NOTE - Ensure the blower is set to the ON position when using an electrical duct heater.

Mounting the Receiver/Display

The VOSB unit receiver/display must be field-connected and mounted. Mounting slots are available on the bottom of the electrical control box.

1. Remove receiver from accessories package.
2. Insert the two fixed plastic mounting brackets on the back of the receiver (Figure 26) into the two slots on the bottom of the electrical control box (Figure 25) and slide to secure it.
3. Connect the 10-conductor wire of the receiver to the unit control board. Pass the wire through the cable path. See Figure 27.




Figure 26. Receiver




Figure 27. Receiver Mounting Location

If it is necessary to position the receiver a distance from the unit, use the optional extension cable kit V0CTRL93P-1 (cat # 14R84).

Network Address and Commissioning

After the system has been installed, each indoor unit must be assigned an address as part of the commissioning procedure.

Spot Check Instructions

Use the Spot Check Performance table below and the Manual button on the unit receiver to view diagnostic information the indoor unit.

Table 7. Spot Check Performance Identification Table

No.	Content	Recorded Value/Date
0	Normal display	
1	Communication address of indoor unit	
2	Indoor unit capacity (horsepower)	
3	Network address of indoor unit	
4	The actual setpoint temperature	
5	The actual indoor temperature T1	
6	The middle coil temperature T2	
7	The coil inlet temperature T2A	
8	The coil outlet temperature T2B	
9	The discharge temperature TA	
10	The actual superheat temperature	
11	The target subcool (heating) /superheat (cooling) temperature	
12	The actual subcool temperature	
13	Error Code	
14	Indoor software version	
15	End (--)	

This Spot Check Performance table is located on the unit service panel.

The diagnostic information can also be obtained using the wired remote controller.

Troubleshooting

Digital Display

The indoor unit is equipped with a receiver that has a digital display that provides an error code. Refer to the table to view the error codes. The error code will replace the temperature setting displayed on the receiver. If more than one error has occurred, the codes will alternate so that all codes are shown.

Make note of the code (E1, EE, etc.), then reset the display by pressing the ON/OFF button on the unit controller. Press the ON/OFF button a second time to reapply power to unit. If the code is still displayed, disconnect and restore power at the unit disconnect switch or circuit breaker. If the problem was temporary, the code will not reappear. If the error code reappears after power has been broken and restored at the disconnect switch or circuit breaker, call VRF Technical Support 1-844-438-8731.



Figure 28. Receiver/Display

Table 8. Fault Code Display on Indoor Unit Receiver

Error Code	Description
FE	No address
E0	Mode conflict
E1	Communication error between indoor and main outdoor unit
E2	T0 (Room temperature sensor) malfunction
E3	T2 (Middle of evaporator sensor) malfunction
E4	T2B (Outlet of evaporator sensor) malfunction
E5	T2A (Inlet of evaporator sensor) malfunction
E6	DC fan motor error
E7	EEPROM failure
Eb	EXV malfunction
EC	TA (Discharge temperature sensor) malfunction
Ed	Outdoor unit Fault
EE	High Water Alarm
A0	Emergency stop
D8	Remote off
U4	MS self-inspection error
F8	MS error

Table 9. Fault Code Display on Controller

Error Code	Description
F0	Communication/Address error between indoor units and wired controller
F1	Communication/Wiring error between indoor units and wired controller
E2	Controller temperature sensor error

Technical Support

1-844-GET-VRF1

(1-844-438-8731)

vrftechsupport@lennoxind.com

www.LennoxVRF.com

Download the app
from the Apple App Store or the Google Play store.

