

**CBA25UH (HFC-410A) SERIES UNITS**



**⚠ WARNING**

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a licensed professional HVAC installer or equivalent, service agency, or the gas supplier.

**⚠ IMPORTANT**

The Clean Air Act of 1990 bans the intentional venting of refrigerant (CFCs, HCFCs and HFCs) as of July 1, 1992. Approved methods of recovery, recycling or reclaiming must be followed. Fines and/or incarceration may be levied for noncompliance.

**NOTICE**

A thermostat is not included and must be ordered separately.

- A Lennox communicating thermostat must be used in communicating applications.
- In non-communicating applications, the Lennox ComfortSense® thermostat may be used, as well as other non-communicating thermostats.

In all cases, setup is critical to ensure proper system operation.

Field wiring for both communicating and non-communicating applications is illustrated in diagrams, which begin on page 29.

**⚠ CAUTION**

As with any mechanical equipment, contact with sharp sheet metal edges can result in personal injury. Take care while handling this equipment and wear gloves and protective clothing.

**Table of Contents**

CBA25UH Unit Dimensions – Upflow – inches (mm).....2  
 Specifications and Electrical Data .....3  
 Model Number Identification.....4  
 Blower Data .....5  
 Unit Components.....7  
 ECBA25 Electric Heat Data.....9  
 Heat Section Installation.....14  
 Configuration Modification .....16  
 Brazing Connections .....19  
 Installing the Condensate Drain .....22  
 Electrical Connections .....24  
 Inspecting and Replacing Filters .....25  
 Wiring Diagrams.....26  
 Professional Maintenance .....30  
 Check-out Procedures .....30  
 Sequence of Operation .....31

**General Information**

This indoor unit **with all-aluminum coil** is designed for installation with optional field-installed electric heat and a matched outdoor unit that is charged with HFC-410A refrigerant. These units, designed for indoor installation in multiple positions, are completely assembled for upflow and horizontal right-hand discharge before being shipped from the factory.


All CBA25UH air handlers are equipped with a factory-installed, internally mounted check / expansion valve, which is suitable for use in HFC-410A applications.

This air handler is compatible with the ComfortSense® non-communicating thermostat and non-communicating outdoor units. In addition, this unit has the enhanced capability of communicating with communicating thermostats and communicating outdoor units using the Lennox RSBus protocols.

**NOTE** - For downflow or horizontal left-hand air discharge, certain field modifications are required.

**IMPORTANT:** Special procedures are required for cleaning the all-aluminum coil in this unit. See page 29 in this instruction for information.

# CBA25UH Unit Dimensions – Upflow – inches (mm)



Dimensions	018		024		030		036, 042		048		060	
	in.	mm	in.	mm	in.	mm	in.	mm	in.	mm	in.	mm
<b>A</b>	43-1/2	1105	45-1/2	1156	47	1194	53-5/8	1362	55	1397	59-3/4	1518
<b>B</b>	18-1/2	470	18-1/2	470	18-1/2	470	21-1/2	546	21-1/2	546	21-1/2	546
<b>C</b>	16-1/2	419	16-1/2	419	16-1/2	419	19-1/2	495	19-1/2	495	19-1/2	495
<b>D</b>	16-1/4	413	16-1/4	413	16-1/4	413	19-1/4	489	19-1/4	489	19-1/4	489

NOTE - Unit is shipped configured for horizontal right-hand air discharge. Unit may be converted to horizontal left-hand air discharge by repositioning horizontal drain pan.

Dimensions remain the same in all configurations.

## Specifications and Electrical Data

General Data		Model Number	CBA25UH-018	CBA25UH-024	CBA25UH-030	CBA25UH-036
		Nominal tonnage	1.5	2	2.5	3
Connections	Suction/Vapor line (o.d.) - in. sweat		3/4	3/4	3/4	7/8
	Liquid line (o.d.) - in. sweat		3/8	3/8	3/8	3/8
	Condensate - in. fpt		(2) 3/4	(2) 3/4	(2) 3/4	(2) 3/4
Indoor Coil	Net face area - ft. <sup>2</sup>		3.30	3.77	4.72	5.66
	Tube outside diameter - in.		3/8	3/8	3/8	3/8
	Number of rows		3	3	3	3
	Fins per inch		15	15	15	15
Blower	Wheel nominal diameter x width - in.		9 x 6	9 x 6	10 x 8	10 x 8
	Blower motor output - hp		1/5	1/3	1/2	1/3
<sup>1</sup> Filters	Size of filter - in.		15 x 20 x 1	15 x 20 x 1	15 x 20 x 1	18 x 20 x 1
Shipping Data -1 package - lbs.			129	136	143	169

### ELECTRICAL DATA

Voltage - 1 phase (60 hz)		208/230V	208/230V	208/230V	208/230V
<sup>2</sup> Maximum overcurrent protection (unit only)		15	15	15	15
<sup>3</sup> Minimum circuit ampacity (unit only)		5.0	5.0	5.0	5.0
Blower Motor Full Load Amps		1.1	1.6	2.2	2.0

### SPECIFICATIONS

General Data		Model Number	CBA25UH-042	CBA25UH-048	CBA25UH-060
		Nominal tonnage	3.5	4	5
Connections	Suction/Vapor line (o.d.) - in. sweat		7/8	7/8	7/8
	Liquid line (o.d.) - in. sweat		3/8	3/8	3/8
	Condensate - in. fpt		(2) 3/4	(2) 3/4	(2) 3/4
Indoor Coil	Net face area - ft. <sup>2</sup>		5.66	6.13	7.08
	Tube outside diameter - in.		3/8	3/8	3/8
	Number of rows		3	3	3
	Fins per inch		15	15	15
Blower	Wheel nominal diameter x width - in.		10 x 8	12 x 10	12 x 10
	Blower motor output - hp		1/2	1	1
<sup>1</sup> Filters	Size of filter - in.		18 x 20 x 1	18 x 20 x 1	18 x 20 x 1
Shipping Data -1 package - lbs.			169	179	190

### ELECTRICAL DATA

Voltage - 1 phase (60 hz)		208/230V	208/230V	208/230V
<sup>2</sup> Maximum overcurrent protection (unit only)		15	15	15
<sup>3</sup> Minimum circuit ampacity (unit only)		5.0	9.5	9.5
Blower Motor Full Load Amps		2.5	7.6	7.6

<sup>1</sup> Disposable filter.


<sup>2</sup> HACR type circuit breaker or fuse.

<sup>3</sup> Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements. Use wires suitable for at least 167°F.

### OPTIONAL ACCESSORIES - ORDER SEPARATELY

Model	-018	-024 -030	-036	-042 -048 -060
iComfort® M30 Smart Wi-Fi Thermostat	15Z69	15Z69	15Z69	15Z69
Remote Outdoor Temperature Sensor	X2658	X2658	X2658	X2658
Downflow Conversion Kit	Y9658	Y9658	Y9659	Y9659
Electric Heat - See Electric Heat Data Tables	4 to 20 kW			
Horizontal Support Frame Kit	56J18	56J18	56J18	56J18
Side Return Unit Stand (Upflow Only)	45K32	45K32	45K32	45K32
Single-Point Power Source Control Box (for Electric Heat)	21H39	21H39	21H39	21H39
Wall Hanging Bracket Kit (Upflow Only)	45K30	45K30	45K30	45K30
High Performance Economizer (Commercial Only)	10U53	10U53	10U53	10U53

## Model Number Identification



## Air Flow – Cooling Blower Speed

The cooling blower speed is factory configured to provide correct air flow for an outdoor unit that matches the cooling capacity rating of the air handler.

If the outdoor unit is smaller than the maximum cooling capacity rating for the air handler, the cooling blower speed may need to be changed. Refer to blower performance chart, table 2 on page 16 .

## ⚠ WARNING



Electric shock hazard! - Disconnect all power supplies before servicing.

Replace all parts and panels before operating.

Failure to do so can result in death or electrical shock.

## CHANGE BLOWER SPEED

- 1 - Disconnect all power supplies.
- 2 - Remove the air handler access panel.
- 3 - Locate pin number 2 on the blower relay. Two black wires are connected to this terminal pin. One connects to pin number 5 on the blower relay, one connects to an in-line splice connecting to a blue wire.
- 4 - Select the required blower motor speed. Connect red-LO or black-HI and plug it into the 4-pin blower relay harness connector.

**NOTE** - Reuse the factory-installed wire nut on the unused wires.

- 5 - Replace all panels.
- 6 - Reconnect power.

**NOTE** - Refer to wiring diagram located on the unit access panel, this figure and blower performance (table 2).

- All air data measured external to unit with 1 inch non-pleated air filter in place.
- All factory settings are medium speed.
- All data given while air handler is operating with a dry DX coil.
- All downflow applications run on high speed when utilizing electric heat.

### BLOWER RELAY




FIGURE 1. Changing Blower Speed

## Blower Data

### CBA25UH-018 PERFORMANCE

External Static Pressure in. w.g.	Air Volume / Watts at Various Blower Speeds					
	High		Medium		Low	
	cfm	Watts	cfm	Watts	cfm	Watts
0.10	920	264	690	190	540	144
0.20	880	251	670	183	525	140
0.30	855	238	640	176	505	136
0.40	790	224	605	167	470	130
0.50	710	210	550	155	420	122

NOTE - All air data measured external to unit with dry coil and 1 inch non-pleated air filter in place. Electric heaters have no appreciable air resistance.

### CBA25UH-024 PERFORMANCE

External Static Pressure in. w.g.	Air Volume / Watts at Various Blower Speeds					
	High		Medium		Low	
	cfm	Watts	cfm	Watts	cfm	Watts
0.10	1105	342	1010	280	675	210
0.20	1045	322	980	262	675	202
0.30	1000	307	940	247	655	192
0.40	915	284	805	235	630	180
0.50	855	268	740	216	590	170

NOTE - All air data measured external to unit with dry coil and 1 inch non-pleated air filter in place. Electric heaters have no appreciable air resistance.

### CBA25UH-030 PERFORMANCE

External Static Pressure in. w.g.	Air Volume / Watts at Various Blower Speeds					
	High		Medium		Low	
	cfm	Watts	cfm	Watts	cfm	Watts
0.10	1310	496	1080	391	870	310
0.20	1260	466	1055	378	870	301
0.30	1215	449	1025	361	855	288
0.40	1155	431	985	343	810	278
0.50	1085	408	935	325	770	265

NOTE - All air data measured external to unit with dry coil and 1 inch non-pleated air filter in place. Electric heaters have no appreciable air resistance.

### CBA25UH-036 PERFORMANCE

External Static Pressure in. w.g.	Air Volume / Watts at Various Blower Speeds					
	High		Medium		Low	
	cfm	Watts	cfm	Watts	cfm	Watts
0.10	1560	532	1275	402	1020	295
0.20	1520	518	1240	388	970	287
0.30	1445	502	1190	375	955	280
0.40	1395	480	1150	363	910	270
0.50	1325	460	1085	346	805	254

NOTE - All air data measured external to unit with dry coil and 1 inch non-pleated air filter in place. Electric heaters have no appreciable air resistance.

## Blower Data

### CBA25UH-042 PERFORMANCE

External Static Pressure in. w.g.	Air Volume / Watts at Various Blower Speeds					
	High		Medium		Low	
	cfm	Watts	cfm	Watts	cfm	Watts
0.10	1815	674	1525	498	1300	394
0.20	1755	652	1495	486	1275	387
0.30	1695	634	1450	473	1250	376
0.40	1605	607	1390	455	1210	367
0.50	1530	582	1345	441	1155	356

NOTE - All air data measured external to unit with dry coil and 1 inch non-pleated air filter in place.  
Electric heaters have no appreciable air resistance.

### CBA25UH-048 PERFORMANCE (Less Filter)


External Static Pressure in. w.g.	Air Volume / Watts at Various Blower Speeds									
	High		Medium-High		Medium		Medium-Low		Low	
	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts
0.10	1895	597	1770	493	1715	454	1500	315	1250	211
0.20	1860	629	1735	510	1670	470	1465	331	1210	222
0.30	1835	632	1700	529	1635	487	1435	348	1185	231
0.40	1795	656	1670	544	1615	504	1400	364	1130	239
0.50	1760	667	1650	552	1575	514	1360	379	1110	251

NOTE - All air data measured external to unit with dry coil and 1 inch non-pleated air filter in place.  
Electric heaters have no appreciable air resistance.

### CBA25UH-060 PERFORMANCE (Less Filter)

External Static Pressure in. w.g.	Air Volume / Watts at Various Blower Speeds									
	High		Medium-High		Medium		Medium-Low		Low	
	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts	cfm	Watts
0.10	1980	624	1905	538	1815	484	1625	354	1100	132
0.20	1955	644	1870	563	1785	493	1595	365	1050	140
0.30	1925	643	1835	568	1760	507	1565	385	1000	144
0.40	1895	663	1810	585	1730	527	1520	398	925	162
0.50	1860	673	1765	595	1685	542	1490	398	830	172

NOTE - All air data measured external to unit with dry coil and 1 inch non-pleated air filter in place.  
Electric heaters have no appreciable air resistance.



**FIGURE 2. Typical Unit Parts Arrangement**

### Application

All major blower coil components must be matched according to Lennox recommendations for the unit to be covered under warranty. Refer to the Product Specification bulletin for approved system matchups. A misapplied system will cause erratic operation and can result in early unit failure.

The units come with factory installed check and expansion valve for all applications. The TXV valve has been installed internally for a cleaner installation and is accessible if required.


### Unit Components

#### CONTROL BOX

The CBA25UH control box is located above the blower section shown in figure 2. Line voltage and electric heat connections are made in the control box. Optional electric heat fits through an opening located in the center of the control box. When electric heat is not used, cover plates cover the opening. The electric heat control arrangement is detailed in the electric heat section of this manual.

#### TRANSFORMER

All CBA25UH series units use a single line voltage to 24VAC transformer mounted in the control box. The transformer supplies power to the control circuits in the indoor and outdoor unit. Transformers are rated at 40VA. 208/240VAC single phase transformers use two primary voltage taps as shown in figure 3.



**FIGURE 3. 208 / 240 Volt Transformer**


#### BLOWER RELAY

All CBX25UH units use a double-pole single-throw (DPST) switch relay to energize the blower motor. The relay coil is energized by blower demand from indoor thermostat. When the coil is energized, a set of normally open (N.O.) contacts closes to energize the blower motor on cooling speed. When de-energized, a set of normally closed (N.C.) contacts allows the electric heat relay to energize the blower on heating speed (refer to unit wiring diagram).

#### TIME DELAY RELAY

Blower time delay operation:

- 1 - When cooling demand is initiated, there is a 1 second motor-on delay.
- 2 - After the motor-on delay expires, motor ramps up to 100% and runs at 100% until cooling demand is satisfied.
- 3 - Once demand is met, motor runs at 100% for 45 seconds.
- 4 - Motor ramps down to stop.




**FIGURE 4. Blower Time Delay**

#### BLOWER MOTOR (B3)

CBA25UH -018, -024, -030, -036 and -048 units use single-phase direct drive blower motors with a run capacitor. Figure 5 shows the parts arrangement. All motors have three speed taps. Typically, the MED speed tap is energized during normal operation.

All units are factory wired for heat pump and cooling applications with or without electric heat. The unit wiring diagrams will provide factory set blower speeds.

## BLOWER ASSEMBLY



**FIGURE 5. Blower Assembly**

### **BLOWER MOTOR CAPACITOR**

All CBA25UH -018, -024, -030 and -036 series units use single-phase direct drive motors with a run capacitor. The run capacitor is mounted on the blower housing. See figure 5. Capacitor ratings are shown on side of capacitor and indoor blower motor nameplate.

### **COIL**

CBA25UH units have dual slab coils arranged in an A configuration. Each coil has two or three rows of aluminum tubes fitted with ripple-edged aluminum fins. An expansion valve feeds multiple parallel circuits through the coils. The coil is designed to easily slide out of the unit cabinet.

### **PLASTIC DRAIN PANS**

Drain pans are provided and installed on the CBA25UH. The drain pans are made from fiberglass filled plastic.

## ECBA25 Electric Heat Data

### ELECTRIC HEAT DATA

### CBA25UH-018 | SINGLE PHASE

	Electric Heat Model Number	Input			Blower Motor Full Load Amps	<sup>2</sup> Minimum Circuit Ampacity	<sup>3</sup> Maximum Overcurrent Protection
		Volt	kW	<sup>1</sup> Btuh			
<b>4 kW</b>	ECBA25-4 (19V31) Terminal Block	208	3.0	10,250	1.1	19	<sup>4</sup> 20
		220	3.4	11,450	1.1	20	<sup>4</sup> 20
	ECBA25-4CB (19V32) 30A Circuit Breaker	230	3.7	12,550	1.1	21	<sup>4</sup> 25
		240	4.0	13,650	1.1	22	<sup>4</sup> 25
<b>5 kW</b>	ECBA25-5 (16Y36) Terminal Block	208	3.6	12,300	1.1	23	<sup>4</sup> 25
		220	4.0	13,800	1.1	24	<sup>4</sup> 25
	ECBA25-5CB (16Y39) 30A Circuit Breaker	230	4.4	15,000	1.1	25	<sup>4</sup> 25
		240	4.8	16,400	1.1	26	30
<b>7.5 kW</b>	ECBA25-7.5 (16Y37) Terminal Block	208	5.6	19,200	1.1	35	<b>35</b>
		220	6.3	21,500	1.1	37	<sup>4</sup> 40
	ECBA25-7.5CB (16Y41) 45A Circuit Breaker	230	6.9	23,500	1.1	39	<sup>4</sup> 40
		240	7.5	25,600	1.1	40	<sup>4</sup> 40
<b>10 kW</b>	ECBA25-10 (16Y38) Terminal Block	208	7.2	24,600	1.1	45	<sup>4</sup> 45
		220	8.0	27,500	1.1	47	<sup>4</sup> 50
	ECBA25-10CB (16Y42) 60A Circuit Breaker	230	8.8	30,000	1.1	49	<sup>4</sup> 50
		240	9.6	32,700	1.1	51	60

### ELECTRIC HEAT DATA

### CBA25UH-024 | SINGLE PHASE

	Electric Heat Model Number	Input			Blower Motor Full Load Amps	<sup>2</sup> Minimum Circuit Ampacity	<sup>3</sup> Maximum Overcurrent Protection
		Volt	kW	<sup>1</sup> Btuh			
<b>4 kW</b>	ECBA25-4 (19V31) Terminal Block	208	3.0	10,250	1.6	20	<sup>4</sup> 20
		220	3.4	11,450	1.6	21	<sup>4</sup> 25
	ECBA25-4CB (19V32) 30A Circuit Breaker	230	3.7	12,550	1.6	22	<sup>4</sup> 25
		240	4.0	13,650	1.6	23	<sup>4</sup> 25
<b>5 kW</b>	ECBA25-5 (16Y36) Terminal Block	208	3.6	12,300	1.6	24	<sup>4</sup> 25
		220	4.0	13,800	1.6	25	<sup>4</sup> 25
	ECBA25-5CB (16Y39) 30A Circuit Breaker	230	4.4	15,000	1.6	26	30
		240	4.8	16,400	1.6	27	30
<b>7.5 kW</b>	ECBA25-7.5 (16Y37) Terminal Block	208	5.6	19,200	1.6	36	<sup>4</sup> 40
		220	6.3	21,500	1.6	38	<sup>4</sup> 40
	ECBA25-7.5CB (16Y41) 45A Circuit Breaker	230	6.9	23,500	1.6	39	<sup>4</sup> 40
		240	7.5	25,600	1.6	41	45
<b>10 kW</b>	ECBA25-10 (16Y38) Terminal Block	208	7.2	24,600	1.6	45	<sup>4</sup> 45
		220	8.0	27,500	1.6	48	<sup>4</sup> 50
	ECBA25-10CB (16Y42) 60A Circuit Breaker	230	8.8	30,000	1.6	50	<sup>4</sup> 50
		240	9.6	32,700	1.6	52	60

NOTE - Circuit 1 Minimum Circuit Ampacity includes the Blower Motor Full Load Amps.

<sup>1</sup> Electric heater capacity only - does not include additional blower motor heat capacity.

<sup>2</sup> Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements. Use wires suitable for at least 167°F.

<sup>3</sup> HACR type breaker or fuse.

<sup>4</sup> Bold indicates that the circuit breaker on "CB" circuit breaker models must be replaced with size shown. See table on page 13.

## ELECTRIC HEAT DATA

## CBA25UH-030 | SINGLE PHASE

Electric Heat Model Number	Input			Blower Motor Full Load Amps	<sup>2</sup> Minimum Circuit Ampacity		<sup>3</sup> Maximum Overcurrent Protection		Single Point Power Source	
	Volt	kW	<sup>1</sup> Btuh		Ckt 1	Ckt 2	Ckt 1	Ckt 2	<sup>2</sup> Minimum Circuit Ampacity	<sup>3</sup> Maximum Overcurrent Protection
<b>4 kW</b> ECBA25-4 (19V31) Terminal Block ECBA25-4CB (19V32) 30A Circuit Breaker	208	3.0	10,250	2.2	21	---	<b>4 25</b>	---	---	---
	220	3.4	11,450	2.2	22	---	<b>4 25</b>	---	---	---
	230	3.7	12,550	2.2	23	---	<b>4 25</b>	---	---	---
	240	4.0	13,650	2.2	24	---	<b>4 25</b>	---	---	---
<b>5 kW</b> ECBA25-5 (16Y36) Terminal Block ECBA25-5CB (16Y39) 30A Circuit Breaker	208	3.6	12,300	2.2	24	---	<b>4 25</b>	---	---	---
	220	4.0	13,800	2.2	26	---	30	---	---	---
	230	4.4	15,000	2.2	27	---	30	---	---	---
	240	4.8	16,400	2.2	28	---	30	---	---	---
<b>7.5 kW</b> ECBA25-7.5 (16Y37) Terminal Block ECBA25-7.5CB (16Y41) 45A Circuit Breaker	208	5.6	19,200	2.2	37	---	<b>4 40</b>	---	---	---
	220	6.3	21,500	2.2	39	---	<b>4 40</b>	---	---	---
	230	6.9	23,500	2.2	40	---	<b>4 40</b>	---	---	---
	240	7.5	25,600	2.2	42	---	45	---	---	---
<b>10 kW</b> ECBA25-10 (16Y38) Terminal Block ECBA25-10CB (16Y42) 60A Circuit Breaker	208	7.2	24,600	2.2	46	---	<b>4 50</b>	---	---	---
	220	8.0	27,500	2.2	49	---	<b>4 50</b>	---	---	---
	230	8.8	30,000	2.2	51	---	60	---	---	---
	240	9.6	32,700	2.2	53	---	60	---	---	---
<b>12.5 kW</b> ECBA25-12.5CB (16Y43) (1) 50A and (1) 25A Circuit Breaker	208	9.4	32,000	2.2	40	19	<b>4 40</b>	<b>4 20</b>	59	60
	220	10.5	35,800	2.2	43	20	<b>4 45</b>	<b>4 20</b>	62	70
	230	11.5	39,200	2.2	44	21	<b>4 45</b>	25	65	70
	240	12.5	42,600	2.2	46	22	50	25	68	70
<b>15 kW</b> ECBA25-15CB (16Y44) (1) 60A and (1) 25A Circuit Breaker	208	10.8	36,900	2.2	46	22	<b>4 50</b>	25	68	70
	220	12.1	41,300	2.2	49	23	<b>4 50</b>	25	72	80
	230	13.2	45,100	2.2	51	24	60	25	75	80
	240	14.4	49,100	2.2	53	25	60	25	78	80

NOTE - Circuit 1 Minimum Circuit Ampacity includes the Blower Motor Full Load Amps.

<sup>1</sup> Electric heater capacity only - does not include additional blower motor heat capacity.

<sup>2</sup> Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements. Use wires suitable for at least 167°F.

<sup>3</sup> HACR type breaker or fuse.

<sup>4</sup> **Bold indicates that the circuit breaker on "CB" circuit breaker models must be replaced with size shown. See table on page 13.**

**ELECTRIC HEAT DATA**

**CBA25UH-036 | SINGLE PHASE**

Electric Heat Model Number	Input			Blower Motor Full Load Amps	<sup>2</sup> Minimum Circuit Ampacity		<sup>3</sup> Maximum Overcurrent Protection		Single Point Power Source	
	Volt	kW	<sup>1</sup> Btuh		Ckt 1	Ckt 2	Ckt 1	Ckt 2	<sup>2</sup> Minimum Circuit Ampacity	<sup>3</sup> Maximum Overcurrent Protection
<b>4 kW</b> ECBA25-4 (19V31) Terminal Block ECBA25-4CB (19V32) 30A Circuit Breaker	208	3.0	10,250	2.0	21	---	<b>4 25</b>	---	---	---
	220	3.4	11,450	2.0	22	---	<b>4 25</b>	---	---	---
	230	3.7	12,550	2.0	22	---	<b>4 25</b>	---	---	---
	240	4.0	13,650	2.0	23	---	<b>4 25</b>	---	---	---
<b>5 kW</b> ECBA25-5 (16Y36) Terminal Block ECBA25-5CB (16Y39) 30A Circuit Breaker	208	3.6	12,300	2.0	24	---	<b>4 25</b>	---	---	---
	220	4.0	13,800	2.0	25	---	<b>4 25</b>	---	---	---
	230	4.4	15,000	2.0	26	---	30	---	---	---
	240	4.8	16,400	2.0	28	---	30	---	---	---
<b>7.5 kW</b> ECBA25-7.5 (16Y37) Terminal Block ECBA25-7.5CB (16Y41) 45A Circuit Breaker	208	5.6	19,200	2.0	36	---	<b>4 40</b>	---	---	---
	220	6.3	21,500	2.0	38	---	<b>4 40</b>	---	---	---
	230	6.9	23,500	2.0	40	---	<b>4 40</b>	---	---	---
	240	7.5	25,600	2.0	42	---	45	---	---	---
<b>10 kW</b> ECBA25-10 (16Y38) Terminal Block ECBA25-10CB (16Y42) 60A Circuit Breaker	208	7.2	24,600	2.0	46	---	<b>4 50</b>	---	---	---
	220	8.0	27,500	2.0	48	---	<b>4 50</b>	---	---	---
	230	8.8	30,000	2.0	50	---	<b>4 50</b>	---	---	---
	240	9.6	32,700	2.0	53	---	60	---	---	---
<b>12.5 kW</b> ECBA25-12.5CB (16Y43) (1) 50A and (1) 25A Circuit Breaker	208	9.4	32,000	2.0	40	19	<b>4 40</b>	<b>4 20</b>	59	60
	220	10.5	35,800	2.0	42	20	<b>4 45</b>	<b>4 20</b>	62	70
	230	11.5	39,200	2.0	44	21	<b>4 45</b>	25	65	70
	240	12.5	42,600	2.0	46	22	50	25	68	70
<b>15 kW</b> ECBA25-15CB (16Y44) (1) 60A and (1) 25A Circuit Breaker	208	10.8	36,900	2.0	46	22	<b>4 50</b>	25	68	70
	220	12.1	41,300	2.0	48	23	<b>4 50</b>	25	71	80
	230	13.2	45,100	2.0	50	24	<b>4 50</b>	25	74	80
	240	14.4	49,100	2.0	53	25	60	25	78	80

NOTE - Circuit 1 Minimum Circuit Ampacity includes the Blower Motor Full Load Amps.

<sup>1</sup> Electric heater capacity only - does not include additional blower motor heat capacity.

<sup>2</sup> Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements. Use wires suitable for at least 167°F.

<sup>3</sup> HACR type breaker or fuse.

<sup>4</sup> **Bold indicates that the circuit breaker on "CB" circuit breaker models must be replaced with size shown. See table on page 13.**

**ELECTRIC HEAT DATA**

**CBA25UH-042 | SINGLE PHASE**

Electric Heat Model Number	Input			Blower Motor Full Load Amps	<sup>2</sup> Minimum Circuit Ampacity		<sup>3</sup> Maximum Overcurrent Protection		Single Point Power Source	
	Volt	kW	<sup>1</sup> Btuh		Ckt 1	Ckt 2	Ckt 1	Ckt 2	<sup>2</sup> Minimum Circuit Ampacity	<sup>3</sup> Maximum Overcurrent Protection
<b>4 kW</b> ECBA25-4 (19V31) Terminal Block ECBA25-4CB (19V32) 30A Circuit Breaker	208	3.0	10,250	2.5	21	---	<sup>4</sup> 25	---	---	---
	220	3.4	11,450	2.5	22	---	<sup>4</sup> 25	---	---	---
	230	3.7	12,550	2.5	23	---	<sup>4</sup> 25	---	---	---
	240	4.0	13,650	2.5	24	---	<sup>4</sup> 25	---	---	---
<b>5 kW</b> ECBA25-5 (16Y36) Terminal Block ECBA25-5CB (16Y39) 30A Circuit Breaker	208	3.6	12,300	2.5	25	---	<sup>4</sup> 25	---	---	---
	220	4.0	13,800	2.5	26	---	30	---	---	---
	230	4.4	15,000	2.5	27	---	30	---	---	---
	240	4.8	16,400	2.5	28	---	30	---	---	---
<b>7.5 kW</b> ECBA25-7.5 (16Y37) Terminal Block ECBA25-7.5CB (16Y41) 45A Circuit Breaker	208	5.6	19,200	2.5	37	---	<sup>4</sup> 40	---	---	---
	220	6.3	21,500	2.5	39	---	<sup>4</sup> 40	---	---	---
	230	6.9	23,500	2.5	41	---	45	---	---	---
	240	7.5	25,600	2.5	42	---	45	---	---	---
<b>10 kW</b> ECBA25-10 (16Y38) Terminal Block ECBA25-10CB (16Y42) 60A Circuit Breaker	208	7.2	24,600	2.5	46	---	<sup>4</sup> 50	---	---	---
	220	8.0	27,500	2.5	49	---	<sup>4</sup> 50	---	---	---
	230	8.8	30,000	2.5	51	---	60	---	---	---
	240	9.6	32,700	2.5	53	---	60	---	---	---
<b>12.5 kW</b> ECBA25-12.5CB (16Y43) (1) 50A and (1) 25A Circuit Breaker	208	9.4	32,000	2.5	41	19	<sup>4</sup> 45	<sup>4</sup> 20	60	60
	220	10.5	35,800	2.5	43	20	<sup>4</sup> 45	<sup>4</sup> 20	63	70
	230	11.5	39,200	2.5	45	21	<sup>4</sup> 45	25	66	70
	240	12.5	42,600	2.5	47	22	50	25	68	70
<b>15 kW</b> ECBA25-15CB (16Y44) (1) 60A and (1) 25A Circuit Breaker	208	10.8	36,900	2.5	46	22	<sup>4</sup> 50	25	68	70
	220	12.1	41,300	2.5	49	23	<sup>4</sup> 50	25	72	80
	230	13.2	45,100	2.5	51	24	60	25	75	80
	240	14.4	49,100	2.5	53	25	60	25	78	80

NOTE - Circuit 1 Minimum Circuit Ampacity includes the Blower Motor Full Load Amps.

<sup>1</sup> Electric heater capacity only - does not include additional blower motor heat capacity.

<sup>2</sup> Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements. Use wires suitable for at least 167°F.

<sup>3</sup> HACR type breaker or fuse.

<sup>4</sup> **Bold indicates that the circuit breaker on "CB" circuit breaker models must be replaced with size shown. See table on page 13.**

**ELECTRIC HEAT DATA CBA25UH-048 | CBA25UH-060 | SINGLE PHASE**

Electric Heat Model Number	Input			Blower Motor Full Load Amps	<sup>2</sup> Minimum Circuit Ampacity		<sup>3</sup> Maximum Overcurrent Protection		Single Point Power Source	
	Volt	kW	<sup>1</sup> Btuh		Ckt 1	Ckt 2	Ckt 1	Ckt 2	<sup>2</sup> Minimum Circuit Ampacity	<sup>3</sup> Maximum Overcurrent Protection
<b>4 kW</b> ECBA25-4 (19V31) Terminal Block ECBA25-4CB (19V32) 30A Circuit Breaker	208	3.0	10,250	7.6	28	---	30	---	---	---
	220	3.4	11,450	7.6	29	---	30	---	---	---
	230	3.7	12,550	7.6	29	---	30	---	---	---
	240	4.0	13,650	7.6	30	---	30	---	---	---
<b>5 kW</b> ECBA25-5 (16Y36) Terminal Block ECBA25-5CB (16Y39) 30A Circuit Breaker	208	3.6	12,300	7.6	31	---	<b><sup>4</sup> 35</b>	---	---	---
	220	4.0	13,800	7.6	32	---	<b><sup>4</sup> 35</b>	---	---	---
	230	4.4	15,000	7.6	33	---	<b><sup>4</sup> 35</b>	---	---	---
	240	4.8	16,400	7.6	35	---	<b><sup>4</sup> 35</b>	---	---	---
<b>7.5 kW</b> ECBA25-7.5 (16Y37) Terminal Block ECBA25-7.5CB (16Y41) 45A Circuit Breaker	208	5.6	19,200	7.6	43	---	45	---	---	---
	220	6.3	21,500	7.6	45	---	45	---	---	---
	230	6.9	23,500	7.6	47	---	<b><sup>4</sup> 50</b>	---	---	---
	240	7.5	25,600	7.6	49	---	<b><sup>4</sup> 50</b>	---	---	---
<b>10 kW</b> ECBA25-10 (16Y38) Terminal Block ECBA25-10CB (16Y42) 60A Circuit Breaker	208	7.2	24,600	7.6	53	---	60	---	---	---
	220	8.0	27,500	7.6	55	---	60	---	---	---
	230	8.8	30,000	7.6	57	---	60	---	---	---
	240	9.6	32,700	7.6	60	---	60	---	---	---
<b>12.5 kW</b> ECBA25-12.5CB (16Y43) (1) 50A and (1) 25A Circuit Breaker	208	9.4	32,000	7.6	47	19	50	<b><sup>4</sup> 20</b>	66	70
	220	10.5	35,800	7.6	49	20	50	<b><sup>4</sup> 20</b>	69	70
	230	11.5	39,200	7.6	51	21	<b><sup>4</sup> 60</b>	25	72	80
	240	12.5	42,600	7.6	53	22	<b><sup>4</sup> 60</b>	25	75	80
<b>15 kW</b> ECBA25-15CB (16Y44) (1) 60A and (1) 25A Circuit Breaker	208	10.8	36,900	7.6	53	22	60	25	75	80
	220	12.1	41,300	7.6	55	23	60	25	78	80
	230	13.2	45,100	7.6	57	24	60	25	81	90
	240	14.4	49,100	7.6	60	25	60	25	85	90
<b>20 kW</b> ECBA25-20CB (16Y46) (1) 60A and (1) 50A Circuit Breaker	208	14.4	49,200	7.6	53	43	60	<b><sup>4</sup> 45</b>	96	100
	220	16.1	55,000	7.6	55	46	60	50	101	110
	230	17.6	60,100	7.6	57	48	60	50	105	110
	240	19.2	65,500	7.6	60	50	60	50	110	110

NOTE - Circuit 1 Minimum Circuit Ampacity includes the Blower Motor Full Load Amps.

<sup>1</sup> Electric heater capacity only - does not include additional blower motor heat capacity.

<sup>2</sup> Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements. Use wires suitable for at least 167°F.

<sup>3</sup> HACR type breaker or fuse.

<sup>4</sup> **Bold indicates that the circuit breaker on "CB" circuit breaker models must be replaced with size shown. See table on page 13.**

## Heat Section Installation

### **⚠ WARNING**




Before installing or servicing unit, be sure ALL power to the unit is OFF. More than one disconnect switch may be present. *Electrical shock can cause personal injury or death!*

Before installing the unit, check information on the unit rating plate to ensure that the unit meets the job specification, proper electrical power is available, and that proper duct clearances are maintained.

**NOTE** – If installing heat sections at the same time as the air handler unit, install the electric heat section in the air handler unit before setting the air handler unit and attaching the plenum.

- 1 - Shut off all power to the air handler unit. More than one disconnect may be required.
- 2 - Remove air handler access panel and keep the six screws to reattach access panel after installing heat elements.
- 3 - Disconnect any existing field supply wires and pull them out of the air handler. Disconnect and remove wiring harness and fastener (see figure 6). If not removed, these items will prevent the heat section's base from resting properly in the compartment.
- 4 - Remove the no-heat seal plate in the air handler frame (see figure 6).


**NOTE** – If a small heater is installed in the unit, the installer will need to remove the no-heat plate and break it apart at the perforations and reinstall the two pieces so the smaller heater can be installed into the unit.



**FIGURE 6. Prepare to Install Heat Element**

- 5 - Slide the electric heat section into the air handler. Be careful that the heating elements do not rub against the sheet metal opening when they slide into the air handler. The mounting holes should then line up with holes in the air handler control box.

- 6 - Secure the electric heater assembly into place with the screws that were removed from the heat element panel. Install two field-provided #8 SDST screws in the front of the electric heater assembly (see figure 7).



**FIGURE 7. Installing the Heat Element Assembly**

- 7 - The air handler's access panels have a cover plate that is fastened with a screw and will need to be positioned to fit either one breaker or two, but do not install the access panel until all electrical connections have been completed.


### **⚠ WARNING**

Foil face insulation must be cut to eliminate the possibility for any frayed foil to come in contact with any main or low voltage connections. Insulation must be kept a minimum of 1/2" away from any electrical connection.

#### **CHANGING CIRCUIT BREAKER ORIENTATION**


The air handler comes from the factory ready for horizontal right hand discharge installation. Always rotate the breaker so up is the ON position in all orientations. The circuit breaker orientation change is required by UL 1995, Article 26.18 (25 September 2005).

- 1 - Locate the one clip located on the right side (see arrow) of each breaker (see figure 8). The clip secures the circuit breaker to the mounting bracket. Pull the clip to release the breaker from the mounting bracket and rotate the breaker to the proper position.



**FIGURE 8. Circuit Breaker Clip**

2 - Install the circuit breaker cover plate.



**FIGURE 9. Circuit Breaker Cover Plate**

**NOTE –** If electric heat kit has only one circuit breaker, the breaker cover plate needs to be moved up and installed over the opening without the circuit breaker. Fasten the breaker cover plate to the access panel using the circled hole in figure 9. If the electric heat kit has two circuit breakers, the breaker cover plate is not required.

**Electrical Connections**

**⚠ WARNING**

Electric shock hazard! - Disconnect all power supplies before servicing.  
 Replace all parts and panels before operating.  
 Failure to do so can result in death or electrical shock.

**⚠ IMPORTANT**  
**USE COPPER CONDUCTORS ONLY**


**NOTE –** Refer to the nameplate on the air handler unit for minimum circuit ampacity and maximum overcurrent protection size.

The air handler units are provided with openings to be used with 1-1/2 inch trade size (1-31/32 inch diameter) conduit.

If you want a single point power supply, refer to the nameplate on the single point power supply accessory for minimum circuit ampacity and maximum overcurrent protection size. Select the proper supply circuit conductors in accordance with tables 310-16 and 310-17 in the National Electric Code, ANSI/NFPA No. 70 or tables 1 through 4 in the Canadian Electric Code, Part I, CSA Standard C22.1.

Refer to figure 13 for typical low voltage field wiring for air handler/condensing unit and heat pump applications. Figure 10 is a diagram of the air handler connections and the heater high-voltage wiring.

- 1 - Make wiring connections as follows:  
**Heaters equipped with circuit breakers –** Connect field power supply wiring to circuit breaker(s). Figure 5 shows **L1**, **L2** and ground (**GND**) connections for a 2-breaker configuration.




**FIGURE 10. Field Power Supply Wiring**

- 2 - Remove the interface harness from the air handler unit and connect the 6-pin connector on the heater assembly to the mating connector on the air handler unit.
- 3 - For applications using a two-stage room thermostat and/or an outdoor thermostat, connect wiring as shown in figures 9 and 10.

**Circuit Breaker Cover Installation**

- 1 - Remove any installed patch plates still present.
- 2 - Remove paper backing from the adhesive around the perimeter of the back side of the circuit breaker cover (figure 11).
- 3 - Position the breaker cover over the air handler circuit breaker opening.




**FIGURE 11. Remove Paper Cover**

## **⚠ IMPORTANT**

Confirm air tight seal between breaker cover and air handler access panel. Apply a thin silicone bead to the adhesive back seat to ensure air tight seal.

Failure to seal circuit breaker cover will allow warm moist air to be pulled into control panel which can create condensation to form on the circuit breaker and other electrical components within the control panel.



**FIGURE 12. Typical Circuit Breaker Cover Installation**

## **Air Handler Speed Connections**

When using the electric heat sections with air handler units, you must adjust the air handler speed according to the size of electric heat and air handler unit. **Air handler speed tap for electric heat in upflow and horizontal position is medium. For downflow it is high speed.** See specific air handler installation instructions for air handler speed adjustment procedure and location.


- 1 - Set the thermostat above room temperature.

- 2 - Check the heat pump and the heat section for normal operation.
- 3 - Set the thermostat to desired setting.
- 4 - Affix the wiring diagram sticker to air handler scroll, aligned with circuit breaker unit wiring diagram sticker.

## **Configuration Modification**

### **UPFLOW APPLICATION**

- 1 - The air handler must be supported on the bottom only and set on solid floor or field-supplied support frame. Securely attach the air handler to the floor or support frame.
- 2 - If installing a unit in an upflow application, remove the horizontal drain pan. **IMPORTANT - The horizontal drain pan is not required in upflow air discharge installations; its removal provides the best efficiency and air flow.**
- 3 - Place the unit in the desired location and slope unit as previously mentioned. Connect return and supply air plenums as required using sheet metal screws.
- 4 - Install units that have no return air plenum on a stand that is at least 14" from the floor. This will allow proper air return.




**FIGURE 13. Upflow Configuration**

## HORIZONTAL APPLICATION

### **⚠ IMPORTANT**

When removing the coil, there is possible danger of equipment damage and personal injury. Be careful when removing the coil assembly from a unit installed in right- or left-hand applications. The coil may tip into the drain pan once it is clear of the cabinet. Support the coil when removing it.



**FIGURE 14. Suspend Horizontal Unit**

**NOTE** – When the unit is installed in horizontal applications, a secondary drain pan is recommended. Refer to local codes.

**NOTE** – This unit may be installed in left- or right-hand air discharge horizontal applications. Adequate support must be provided to ensure cabinet integrity. Ensure that there is adequate room to remove service and access panels if installing in the horizontal position.

### LEFT-HAND DISCHARGE


For horizontal left-hand air discharge, the following field modifications are required.

- 1 - Remove access panels and the corrugated padding between the blower and coil assembly. Discard the corrugated padding.
- 2 - Pull the coil assembly from unit. Pull off the horizontal drain pan.
- 3 - Remove the drain plugs from back drain holes on horizontal drain pan and reinstall them on front holes.

### **⚠ IMPORTANT**


After removal of drain pan plug(s), check drain hole(s) to verify that drain opening is fully open and free of any debris. Also check to make sure that no debris has fallen into the drain pan during installation that may plug up the drain opening.

- 4 - Rotate drain pan 180° front-to-back and install it on the opposite side of the coil.
- 5 - Remove screws from top cap.
- 6 - Remove plastic plug from left hole on coil front end seal and reinstall plug in back hole.



**FIGURE 15. Field Modification for Left-Hand Discharge**

- 7 - Rotate top cap 180° front-to-back and align with unused screw holes. Holes must align with front and back coil end plates. The top cap has a 45° bend on one side and a 90° bend on the other. **The 90° bend must be on the same side as the horizontal drain pan as illustrated in figure 4.**



**FIGURE 16. Left-Hand Discharge Configuration**

**NOTE** – Be very careful when reinstalling the screws into the coil end plate engaging holes. Misaligned screws may damage the coil.


- 8 - From the upflow position, flip cabinet 90° to the left and set into place. Replace blower assembly. Secure coil in place by bending down the tab on the cabinet support rail as illustrated.
- 9 - Install the horizontal shield (-060 model) on the front edge of the horizontal drain pan as illustrated in figure 5.

**NOTE** – For horizontal applications in high humidity areas, remove the downflow rail closest to the drain pan. To remove rail, remove screw from rail at back of unit and at cabinet support rail. Remove downflow rail then replace screws. Also, seal around the exiting drain pipe, liquid and suction lines to prevent infiltration of humid air.

- 10 - Knock out drain seal plate from access door. Secure plate to cabinet front flange with screw provided.
- 11 - Flip access door and replace it on the unit.
- 12 - Set unit so that it is sloped 1/4" toward the drain pan end of the unit. Connect return and supply air plenums as required using sheet metal screws.
- 13 - If suspending the unit, it must be supported along the entire length of the cabinet. If using chain or strap, use a piece of angle iron or sheet metal attached to the unit (either above or below) so that the full length of the cabinet is supported. Use securing screws no longer than 1/2" to avoid damage to coil or filter, as illustrated in figure 3. Connect return and supply air plenums as required using sheet metal screws.

### RIGHT-HAND DISCHARGE

- 1 - Determine which plugs are required for drain line connections.
- 2 - With access door removed, remove drain line plugs to install drain lines.
- 3 - Set unit so that it is sloped toward the upflow drain pan end of the unit and level from front to back of unit (see figure 7).
- 4 - The horizontal configuration is shown in figure 2.



**FIGURE 17. Right-Hand Discharge Configuration**

- 5 - If the unit is suspended, the entire length of the cabinet must be supported. If you use a chain or strap, use a piece of angle iron or sheet metal attached to the unit (either above or below) to support the length of the cabinet. Use securing screws no longer than 1/2 inch to avoid damaging the coil or filter. See figure 3. Use sheet metal screws to connect the return and supply air plenums as required.

### DOWNFLOW APPLICATION

Use the following procedures to configure the unit for downflow operations:

**! IMPORTANT**

If electric heat section with circuit breakers (ECB29/ECB31) is installed in a CBA25UH unit in a downflow application, the circuit breakers must be rotated 180° to the UP position. See ECB29/ECB31 installation instructions for more details.


Table 2 outlines the sizes of the various drip shields.

**NOTE - (-060 Model Only)** Remove access panels and horizontal drip shield from the corrugated padding between the blower and coil assembly.

- 1 - Remove the coil assembly from the unit.
- 2 - For best efficiency and air flow, remove the horizontal drain pan from the units in downflow positions as illustrated in figure 6.
- 3 - Rotate cabinet 180° from the upright position. See figure 6. You may need to first remove the blower assembly to lighten the cabinet for lifting.
- 4 - Foam tape that is provided creates a seal between the drip shield and the coil so that water does not leak into the air stream. The foam tape pieces are pre-cut. Apply the tape to the drip shields as illustrated in figure 7 and specified as follows:
  - Apply two pieces of foam tape provided down both ends of each shield. The tape should measure 4-3/4" X 2" (120 X 25 mm). Ensure that the tape covers both sides of the shield equally.
  - Apply the longer piece of 1 inch wide foam tape between the end pieces of tape.
- 5 - From the underside of the coil, install the downflow drip shield firmly in place as illustrated in figure 8.

**TABLE 1. Downflow Drip Shields (Tape Required)**

Units	Length	Width
-018/024	Not Required	Not Required
-030	15-7/8"	4-11/16"
-036, -042	17-7/8"	4-11/16"
-048, -060	19-7/8"	4-11/16"



**FIGURE 18. Downflow Discharge Position**



## IMPORTANT

To prevent the build-up of high levels of nitrogen when purging, it must be done in a well-ventilated area. Purge low-pressure nitrogen (1 to 2 psig) through the refrigerant piping during brazing. This will help to prevent oxidation and the introduction of moisture into the system.

## WARNING



Danger of explosion!

Can cause equipment damage, injury, or death.

When using a high pressure gas such as nitrogen to pressurize a refrigeration or air conditioning system, use a regulator that can control the pressure down to 1 or 2 psig (6.9 to 13.8 kPa).

## CAUTION

Brazing alloys and flux contain materials which are hazardous to your health.

Avoid breathing vapors or fumes from brazing operations. Perform operations only in well ventilated areas.

Wear gloves and protective goggles or face shield to protect against burns.

Wash hands with soap and water after handling brazing alloys and flux.

## WARNING



When using a high pressure gas such as nitrogen to pressurize a refrigeration or air conditioning system, use a regulator that can control the pressure down to 1 or 2 psig (6.9 to 13.8 kPa).


**TABLE 2. CBA25UH Refrigerant Connections and Line Set Requirements**

Model	Liquid Line	Vapor Line	L15 Line Sets
-018/ 024	3/8" (10mm)	3/4" (19mm)	L15 line set sizes are dependant on unit match-up. See Product Specifications (EHB) for outdoor unit to determine correct line set sizes
-030 -036	3/8" (10mm)	3/4" (19mm)	
-042 -048	3/8" (10mm)	7/8" (22mm)	
-060	3/8" (10mm)	7/8" (22mm)	Field fabricated

NOTE - Some applications may require a field-provided 7/8" to 1-1/8" adapter.

**NOTE** - When installing refrigerant lines longer than 50 feet, see the Lennox Refrigerant Piping Design and Fabrication Guidelines, CORP. 9351-L9, or contact Lennox Technical Support Product Applications for assistance.

PLEASE READ IMPORTANT ISSUES CONCERNING BRAZING OPERATIONS ON PAGE 10 BEFORE PROCEEDING.





**C** USE A WET RAG TO PROTECT CTX SENSING BULB WHEN BRAZING SUCTION LINE CONNECTIONS.

NOTE — REFER TO OUTDOOR UNIT INSTALLATION INSTRUCTIONS FOR REFRIGERANT PIPING SIZE REQUIREMENTS

NOTE - Use silver alloy brazing rods with five or six percent minimum silver alloy for copper-to-copper brazing, 45 percent alloy for copper-to-brass and copper-to-steel brazing.

**A** REMOVE ACCESS PANEL




PIPING PLATE

**B** REMOVE RUBBER PLUG FROM BOTH LIQUID AND SUCTION LINES

NOTE — CBA38MV SERIES UNITS USE NITROGEN OR DRY AIR AS A HOLDING CHARGE. IF THERE IS NO PRESSURE WHEN THE RUBBER PLUGS ARE REMOVED, CHECK THE COIL FOR LEAKS BEFORE INSTALLING.


**D** EITHER REMOVE OR PUSH PIPE WRAPPING BACK THROUGH HOLE IN PIPING PLATE BEFORE LINE SET CONNECTION AND BRAZING.

**F** CONNECT GAUGES AND START NITROGEN FLOW



FLOW REGULATED NITROGEN (AT 1 TO 2 PSIG) THROUGH THE REFRIGERATION GAUGE SET INTO THE VALVE STEM PORT CONNECTION ON THE OUTDOOR UNIT LIQUID LINE SERVICE VALVE AND OUT OF THE VALVE STEM PORT CONNECTION ON THE SUCTION SERVICE VALVE.

NITROGEN




**E** CONNECT PIPES

NOTE — REFRIGERANT LINE SETS SHOULD BE ROUTED TO ALLOW FILTER ACCESSIBILITY.

**G** PLACE A WET RAG AGAINST PIPING PLATE AND AROUND THE SUCTION LINE CONNECTION. A

**H** BRAZE CONNECTION. ALLOW PIPE TO COOL BEFORE REMOVING WET RAG FROM CTX SENSING BULB AND PIPING PANEL AREA.



**I** REPEAT PREVIOUS PROCEDURE FOR LIQUID LINE.

REFER TO INSTRUCTIONS PROVIDED WITH OUTDOOR UNIT FOR LEAK TESTING, EVACUATING AND CHARGING PROCEDURES

**FIGURE 23. Brazing Connections**

## Installing the Condensate Drain

### ! IMPORTANT

On units of this type, where the blower “draws” rather than “blows” air through the coil, traps must be installed in the condensate drain lines (primary and auxiliary, if used). Traps prevent the blower from drawing air through the drain lines into the air supply.




FIGURE 24. Typical Main and Overflow Drain Installations

### ! IMPORTANT

After removal of drain pan plug(s), check drain hole(s) to verify that drain opening is fully open and free of any debris. Also check to make sure that no debris has fallen into the drain pan during installation that may plug up the drain opening.

- 1 - Remove the appropriate drain knockouts. If necessary, remove the indoor coil assembly from the cabinet.
- 2 - Connect primary drain line connection to the primary drain pan connection. The primary drain connection is flush with the bottom of the inside of the pan. Secondary connection is raised above the bottom of the inside of the pan.

NOTE – When making drain fitting connections to the drain pan, hand tighten the fitting and use a thread sealant. Over-tightening the fittings can split connections on the drain pan.

- 3 - If the auxiliary drain line is to be used, remove the plug and route the drain line so that water draining from the outlet will be easily noticed by the homeowner. The auxiliary drain line does not require venting or a trap. Refer to local codes.
- 4 - After removal of drain pan plugs, check the drain port to see if holes have been drilled. If not drilled, use a 19/32" bit to drill out the primary drain hole; use a 3/8" drill bit for the secondary drain hole. Remove all drill shavings.
- 5 - Make sure drain ports and drain pan are free of all debris.

- 6 - Plug and check any unused drain pan openings for tightness. Torque plugs to 30 in. lb. to prevent water leaks or seepage from the drain pan.
- 7 - Install a 2" trap in the primary drain lines as close to the unit as practical (see figure 24). Make sure the top of the trap is below the connection to the drain pan to allow complete drainage of the pan.

NOTE – Horizontal runs must have an anti-siphon air vent (standpipe) installed ahead of the horizontal run. An extremely long horizontal run may require an oversized drain line to eliminate air trapping.

NOTE – Do not operate air handler without a drain trap. The condensate drain is on the negative pressure side of the blower; therefore, air being pulled through the condensate line will prevent positive drainage without a proper trap.

- 8 - Route the drain line to the outside or to an appropriate drain. Drain lines must be installed so they do not block service access to the front of the air handler. A 24" clearance is required for filter, coil, or blower removal and service access.

NOTE – Check local codes before connecting the drain line to an existing drainage system.

Insulate the drain lines where sweating could cause water damage.

### TEST CONDENSATE DRAIN

Test the drain pan and drain line after installation:

- 1 - Pour several quarts of water into drain pan, enough to fill drain trap and line.
- 2 - Check to make sure the drain pan is draining completely, no leaks are found in drain line fittings, and water is draining from the end of the primary drain line.
- 3 - Correct any leaks found.

### BEST PRACTICES

The following best practices are recommended for the condensate removal process:

- Main and overflow drain lines should **NOT** be smaller than both drain connections at drain pan.
- Overflow drain line should run to an area where homeowner will notice drainage.
- It is recommended that the overflow drain line be vented and a trap installed. Refer to local codes.
- Condensate drain lines must be configured or provided with a cleanout to permit the clearing of blockages and for maintenance without requiring the drain line to be cut.

## IMPORTANT

A field-fabricated secondary drain pan, with a drain pipe to the outside of the building, is required in all installations over a finished living space or in any area that may be damaged by overflow from the main drain pan. In some localities, local codes may require a secondary drain pan for any horizontal installation.

### DUCT SYSTEM

The air handler is provided with flanges for the connection of the plenum and ducts. The air handler is equipped with flanges that can form a filter rack for the installation of the air filter, or the filter may be installed as part of the return air duct system.

Supply and return duct system must be adequately sized to meet the system's air requirements and static pressure capabilities. The duct system should be insulated with a minimum of 1" thick insulation with a vapor barrier in conditioned areas or 2" minimum in unconditioned areas.

Supply plenum should be the same size as the flanged opening provided around the blower outlet and should extend at least 3 ft. from the air handler before turning or branching off plenum into duct runs. The plenum forms an extension of the blower housing and minimizes air expansion losses from the blower.

### INSTALLING DUCT SYSTEM

Connect supply air duct to the flange on top of the air handler. If an isolation connector is used, it must be nonflammable.

A return air duct system is recommended. If the unit is installed in a confined space or closet, a return connection must be run, full size, to a location outside the closet.

### CONNECTING REFRIGERANT LINES

Refrigerant lines must be connected by a qualified technician in accordance with established procedures.

## IMPORTANT

Refrigerant lines must be clean, dehydrated, refrigerant-grade copper lines. Air handler coils should be installed only with specified line sizes for approved system combinations.

Handle the refrigerant lines gently during the installation process. Sharp bends or possible kinking in the lines will cause a restriction.

Do not remove the caps from the lines or system connection points until connections are ready to be completed.

- 1 - Route the suction and liquid lines from the fittings on the indoor coil to the fittings on the outdoor unit. Run the lines in as direct a path as possible avoiding unnecessary turns and bends.
- 2 - Make sure that the suction line is insulated over the entire exposed length and that neither suction nor liquid lines are in direct contact with floors, walls, duct system, floor joists, or other piping.
- 3 - Connect the suction and liquid lines to the evaporator coil.
- 4 - To avoid damaging the rubber grommets in the cabinet while brazing, slide the rubber grommets over the refrigerant lines until they are away from the heat source.
- 5 - Braze using an alloy of silver or copper and phosphorus with a melting point above 1,100°F (593°C).

NOTE – Do not use soft solder.

6. Reinstall the rubber grommets after brazing is finished.
7. Make sure outdoor unit has been put in place according to the Installation Instructions and is connected to the refrigerant lines.

### SEALING THE UNIT

Seal the unit so that warm air is not allowed into the cabinet. Warm air introduces moisture, which results in water blow-off problems. This is especially important when the unit is installed in an unconditioned area.

If installed in an unconditioned space, sealant should be applied around the electrical wires, refrigerant tubing, and condensate lines where they enter the cabinet.

## ⚠ WARNING

There must be an airtight seal between the bottom of the air handler and the return air plenum. Use fiberglass sealing strips, caulking, or equivalent sealing method between the plenum and the air handler cabinet to ensure a tight seal. Return air must not be drawn from a room where this air handler or any gas-fueled appliance (i.e., water heater), or carbon monoxide-producing device (i.e., wood fireplace) is installed.

Make sure the liquid line and suction line entry points are sealed with either the provided flexible elastomeric thermal insulation, or field provided material (e.g. Armaflex, Permagem or equivalent). Any of the previously mentioned materials may be used to seal around the main and auxiliary drains, and around open areas of electrical inlets.

### Electrical Connections

## ⚠ WARNING

Electric Shock Hazard. Can cause injury or death. Unit must be properly grounded in accordance with national and local codes.



Line voltage is present at all components when unit is not in operation on units with single-pole contactors. Disconnect all remote electric power supplies before opening access panel. Unit may have multiple power supplies.

## ⚠ WARNING

Electric Shock Hazard.

Can cause injury or death.

Foil-faced insulation has conductive characteristics similar to metal. Be sure there are no electrical connections within a 1/2" of the insulation. If the foil-faced insulation comes in contact with electrical voltage, the foil could provide a path for current to pass through to the outer metal cabinet. While the current produced may not be enough to trip existing electrical safety devices (e.g. fuses or circuit breakers), the current can be enough to cause an electric shock hazard that could cause personal injury or death.

- All field wiring must be done in accordance with National Electrical Code, applicable requirements of UL and local codes, where applicable.
- Electrical wiring, disconnect means and over-current protection are to be supplied by the installer. Refer to the air handler rating plate for maximum over-current protection, minimum circuit ampacity, as well as operating voltage.
- The power supply must be sized and protected according to the specifications supplied on the product.
- This air handler is factory-configured for 240 volt, single phase, 60 cycles. For 208-volt applications, see "208 Volt Conversion" later in this section.
- For optional field-installed electric heat applications, refer to the instructions provided with the accessory for proper installation.

## ⚠ IMPORTANT

### USE COPPER CONDUCTORS ONLY

- 1 - Disconnect all power supplies.
- 2 - Remove the air handler access panel.
- 3 - Route the field supply wires to the air handler electrical connection box.
- 4 - Use UL-listed wire nuts to connect the field supply conductors to the unit black and yellow leads, and the ground wire to ground terminal marked GND.
- 5 - 5. Replace the air handler access panel.




FIGURE 25. Making Electrical Connections

## 208 VOLT CONVERSION

- 1 - Disconnect all power supplies.
- 2 - Remove the air handler access panel.
- 3 - Using the wiring diagram located on the unit access panel as a reference, move the 2 connected black transformer leads from the 240 volt terminal on the transformer to the 208 volt terminal on the transformer.

<b>⚠ WARNING</b>	
	Electrically ground air handler. Connect ground wire to ground terminal marked "GND". Failure to do so can result in death or electrical shock.

## Inspecting and Replacing Filters

<b>⚠ IMPORTANT</b>
Filter access door must be in place during unit operation. Excessive warm air entering the unit from unconditioned space may result in water blow-off problems.

Filters may be duct-mounted or installed in the cabinet. A filter is installed at the factory. Note that filter access door fits over access panel. Air will leak if the access panel is placed over the filter door.

Filters should be inspected monthly and must be cleaned or replaced when dirty to assure proper furnace operation.

### To replace filter:


- 1 - Loosen the thumbscrews holding the filter panel in place.
- 2 - Slide the filter out of the guides on either side of cabinet.
- 3 - Insert new filter.
- 4 - Replace panel.

See table 3 for replacement filter sizes.



**TABLE 3. Filter Dimensions**

CBA25UH	Filter Size – In. (mm)
-018/024, -030, -036	15 x 20 x 1 (381 x 508 x 25)
-042, -048, -060	18 x 20 x 1 (457 x 508 x 25)


# Wiring Diagrams




**FIGURE 26. Low Voltage Connections (3-Speed PSC Motor) – Field Wiring**



**FIGURE 27. Low Voltage Field Wiring Electric Heat**



**FIGURE 28. Unit Wiring Diagram – Electric Heat and Air Handler**



**FIGURE 29. Unit Wiring Diagram – Electric Heat and Air Handler**

**ELECTRIC HEAT  
CONSTANT TORQUE LABEL WIRING  
DIAGRAM**

## Professional Maintenance

### NOTICE !

Failure to follow instructions will cause damage to the unit.

This unit is equipped with an aluminum coil. Aluminum coils may be damaged by exposure to solutions with a pH below 5 or above 9. The aluminum coil should be cleaned using potable water at a moderate pressure (less than 50psi). If the coil cannot be cleaned using water alone, Lennox recommends use of a coil cleaner with a pH in the range of 5 to 9. The coil must be rinsed thoroughly after cleaning.

In coastal areas, the coil should be cleaned with potable water several times per year to avoid corrosive buildup (salt).

## Check-out Procedures

### IMPORTANT

During installation, service or maintenance, make sure that copper tubing does not rub against metal edges or other copper tubing. Care should also be taken to ensure that tubing does not become kinked. Use wire ties to secure tubing to prevent movement.

Do not secure electrical wires to tubing that carries hot refrigerant gas. Heat from the tubing may melt the wiring insulation, causing a short circuit.

**NOTE** – Refer to outdoor unit installation instructions for system start-up instructions and refrigerant charging instructions.

### PRE-START-UP CHECKS

- Is the air handler properly and securely installed?
- If horizontally configured, is the unit sloped up to 1/4 inch toward drain lines?
- Will the unit be accessible for servicing?
- Has an auxiliary pan been provided under the unit with separate drain for units installed above a finished ceiling or in any installation where condensate overflow could cause damage?
- Have ALL unused drain pan ports been properly plugged?
- Has the condensate line been properly sized, run, trapped, pitched, and tested?
- Is the duct system correctly sized, run, sealed, and insulated?
- Have all cabinet openings and wiring been sealed?
- Is the indoor coil factory-installed TXV properly sized for the outdoor unit being used?

- Have all unused parts and packaging been disposed of?
- Is the filter clean, in place, and of adequate size?
- Is the wiring neat, correct, and in accordance with the wiring diagram?
- Is the unit properly grounded and protected (fused)?
- Is the thermostat correctly wired and in a good location?
- Are all access panels in place and secure?

### CHECK BLOWER OPERATION

- Set thermostat to FAN ON.
- The indoor blower should come on.

### CHECK COOLING OPERATION

- Set thermostat to force a call for cooling (approximately 5°F lower than the indoor ambient temperature).
- The outdoor unit should come on immediately and the indoor blower should start between 30 - 60 seconds later.
- Check the air flow from a register to confirm that the system is moving cooled air.
- Set the thermostat 5°F higher than the indoor temperature. The indoor blower and outdoor unit should cycle off.

### CHECK ELECTRIC HEAT (IF USED)

- Set thermostat to call for auxiliary heat (approximately 5°F above ambient temperature). The indoor blower and auxiliary heat should come on together. Allow a minimum of 3 minutes for all sequencers to cycle on.
- Set the thermostat so that it does not call for heat. Allow up to 5 minutes for all sequencers to cycle off.

## Use of Air Handler During Construction

Lennox does not recommend the use of its air handler unit during any phase of construction. Very low return air temperatures, harmful vapors and operation of the unit with clogged or misplaced filters will damage the unit.

Air handler units may be used for heating (heat pumps) or cooling of buildings under construction, if the following conditions are met:

- A room thermostat must control the air handler. The use of fixed jumpers is not allowed.
- Air filter must be installed in the system and must be maintained during construction.
- Air filter must be replaced upon construction completion.
- The air handler evaporator coil, supply fan assembly and duct system must be thoroughly cleaned following final construction clean-up.
- All air handler operating conditions must be verified according to these installation instructions.

## Sequence of Operation

### COOLING (COOLING ONLY OR HEAT PUMP)

When the thermostat calls for cooling, 24 volts is put on the blower time-delay relay coil and then the indoor blower relay energizes. The normally open contacts close, causing the indoor blower motor to operate. The circuit between **R** and **Y** is completed, closing the circuit to the contactor in the outdoor unit, starting the compressor and outdoor fan motor.

On heat pumps, circuit **R** and **O** energizes the reversing valve, switching the valve to the cooling position. (The reversing valve remains energized as long as the thermostat selector switch is in the COOL position.)

At the completion of the cooling demand, the indoor blower and outdoor unit should cycle off. Air handler should cycle off 45 seconds after the outdoor unit shuts off.

### HEATING (ELECTRIC HEAT ONLY)

When the thermostat calls for heat, the circuit between **R** and **W** is completed, and the heat sequencer is energized. A time delay follows before the heating elements and the indoor blower motor come on. Units with a second heat sequencer can be connected with the first sequencer to **W** on the thermostat subbase, or they may also be connected to a second stage on the subbase.

### HEATING (HEAT PUMP)

When the thermostat calls for heating, 24 volts is put on the blower time-delay relay coil. Then normally open contacts close, causing the indoor blower motor to operate. The circuit between **R** and **Y** is completed, closing the circuit to the contactor in the outdoor unit, starting the compressor and outdoor fan motor.

If the room temperature should continue to fall, the circuit between **R** and **W1** is completed by the second-stage heat room thermostat. Circuit **R-W1** energizes a heat sequencer. The completed circuit will energize supplemental electric heat (if applicable). Units with a second heat sequencer can be connected with the first sequencer to **W1** on the thermostat. They may also be connected to a second heating stage **W2** on the thermostat subbase.

### EMERGENCY HEAT (HEATING HEAT PUMP)

If the selector switch on the thermostat is set to the emergency heat position, the heat pump will be locked out of the heating circuit, and all heating will be electric heat (if applicable). A jumper should be placed between **W2** and **E** on the thermostat subbase so that the electric heat control will transfer to the first-stage heat on the thermostat. This will allow the indoor blower to cycle on and off with the electric heat when the fan switch is in the AUTO position.


Installing Contractor's Name \_\_\_\_\_

Installing Date \_\_\_\_\_

Installing Contractor's Phone \_\_\_\_\_

Air Handler Model # \_\_\_\_\_

Job Address \_\_\_\_\_



- |  |   |
|--|---|
| <p><b>① DUCT SYSTEM</b></p> <p>SUPPLY AIR DUCT</p> <p><input type="checkbox"/> Sealed</p> <p><input type="checkbox"/> Insulated (if necessary)</p> <p><input type="checkbox"/> Registers Open and Unobstructed</p> <p>RETURN AIR DUCT</p> <p><input type="checkbox"/> Sealed</p> <p><input type="checkbox"/> Filter Installed and Clean</p> <p><input type="checkbox"/> Registers Open and Unobstructed</p> <p><b>② INTEGRATED CONTROL</b></p> <p><input type="checkbox"/> Jumpers Configured Correctly (if applicable)</p> <p><input type="checkbox"/> Appropriate Links in Place (if applicable)</p> <p><b>③ VOLTAGE CHECK</b></p> <p><input type="checkbox"/> Supply Voltage _____</p> <p><input type="checkbox"/> Low Voltage _____</p> <p><input type="checkbox"/> Electrical Connections Tight</p> <p><b>④ DRAIN LINE</b></p> <p><input type="checkbox"/> Leak Free</p> <p><input type="checkbox"/> Explained Operation of System to Homeowner</p> | <p><b>⑤ TOTAL EXTERNAL STATIC (dry coil)</b></p> <p style="text-align: right;">dry coil    wet coil</p> <p>Supply External Static _____</p> <p>Return External Static _____</p> <p>Total External Static = _____</p> <p><b>⑥ ELECTRIC HEAT AMPS</b> _____</p> <p><b>⑦ INDOOR BLOWER AMPS</b> _____</p> <p>INDOOR BLOWER CFM _____</p> <p><b>⑧ TEMPERATURE DROP (Cooling Mode)</b></p> <p>Return Duct Temperature _____</p> <p>Supply Duct Temperature - _____</p> <p>Temperature Drop = _____</p> <p><b>⑧ TEMPERATURE RISE (Heating Mode)</b></p> <p>Return Duct Temperature _____</p> <p>Supply Duct Temperature - _____</p> <p>Temperature Rise = _____</p> <p><b>⑨ THERMOSTAT</b></p> <p><input type="checkbox"/> Adjusted and Programmed</p> <p><input type="checkbox"/> Operation Explained to Owner</p> |
|--|---|

Technician's Name: \_\_\_\_\_ Date Start-Up & Performance Check Completed \_\_\_\_\_

**FIGURE 30. Start-up and Performance Checklist (Upflow Configuration)**


Installing Contractor's Name \_\_\_\_\_

Installing Date \_\_\_\_\_

Installing Contractor's Phone \_\_\_\_\_

Air Handler Model # \_\_\_\_\_

Job Address \_\_\_\_\_



**1 DUCT SYSTEM**

**SUPPLY AIR DUCT**

- Sealed
- Insulated (if necessary)
- Registers Open and Unobstructed

**RETURN AIR DUCT**

- Sealed
- Filter Installed and Clean
- Registers Open and Unobstructed

**2 INTEGRATED CONTROL**

- Jumpers Configured Correctly (if applicable)
- Appropriate Links in Place (if applicable)

**3 VOLTAGE CHECK**

- Supply Voltage \_\_\_\_\_
- Low Voltage \_\_\_\_\_
- Electrical Connections Tight

**4 DRAIN LINE**

- Leak Free

Explained Operation of System to Homeowner

**5 TOTAL EXTERNAL STATIC (dry coil)**

dry coil    wet coil

Supply External Static \_\_\_\_\_

Return External Static \_\_\_\_\_

Total External Static = \_\_\_\_\_

**6 ELECTRIC HEAT AMPS** \_\_\_\_\_

**7 INDOOR BLOWER AMPS** \_\_\_\_\_

INDOOR BLOWER CFM \_\_\_\_\_

**8 TEMPERATURE DROP (Cooling Mode)**

Return Duct Temperature \_\_\_\_\_

Supply Duct Temperature - \_\_\_\_\_

Temperature Drop = \_\_\_\_\_

**8 TEMPERATURE RISE (Heating Mode)**

Return Duct Temperature \_\_\_\_\_

Supply Duct Temperature - \_\_\_\_\_

Temperature Rise = \_\_\_\_\_

**9 THERMOSTAT**

- Adjusted and Programmed
- Operation Explained to Owner

Technician's Name: \_\_\_\_\_ Date Start-Up & Performance Check Completed \_\_\_\_\_

**FIGURE 31. Start-Up and Performance Checklist (Horizontal Configuration)**