# LHT SERIES 13 to 20 ton

# **UNIT INFORMATION**

Service Literature

100138 01/2025

### LHT156 through 240 with R454B

The LHT156, 180 and 240 are configure to order units (CTO) with a wide selection of factory installed options.

Optional electric heat is factory- or field-installed. Electric heat operates in single or multiple stages depending on the kW input size. 15kW to 60 kW heat sections are available for the LHT156 and 180 units and 15 kW to 90 kW heat sections are available for the LHT240.

Cooling capacities range from 13 to 20 tons. The LHT 156, 180 & 240 utilize two compressors and six condenser fans.

Multi-Stage Air Volume MSAV® blower option is available. The VFD-driven blower will operate at lower speeds when demand is low and increase to higher speeds when demand is high.

All LHT units are designed to accept any of several different energy management thermostat control systems with minimum field wiring. Factory- or field-provided control options connect to the unit through Smartwire connectors. When "plugged in" the controls become an integral part of the unit wiring.


False ceilings or drop ceiling may be used as a return air plenum only if the unit being installed has a Refrigerant Detection System

All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out with work in confined spaces being avoided.

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

# **A** WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a licensed professional HVAC installer or equivalent, service agency, or the gas supplier



# **A WARNING**

To prevent serious injury or death:

- 1- Lock-out/tag-out before performing maintenance.
- 2- If system power is required (e.g., smoke detector maintenance), disable power to blower, remove fan belt where applicable, and ensure all controllers and thermostats are set to the "OFF" position before performing maintenance.
- 3- Always keep hands, hair, clothing, jewelry, tools, etc., away from moving parts.

#### **Table of Contents**

Tubio of Contonto
Options / Accessories Page 4
Specifications
Blower Data
Electrical / Electric Heat Data Page 12
Unit Parts Arrangement Page 18
I-Unit Components Page 18
II-Placement and Installation Page 36
III-Charging
IV Start Up - Operation Page 40
V-System Service Checks Page 40
VI-Maintenance Page 40
VII-Accessories Page 44
VIII-Multi-Staged Blower Page 48
IX-Wiring and Operation Sequence Page 51
X-Decommissioning Page 63

# **A** CAUTION

As with any mechanical equipment, contact with sharp sheet metal edges can result in personal in jury. Take care while handling this equipment and wear gloves and protective clothing.

# **A WARNING**

Only manufacturer approved auxiliary devices are permitted to be installed in this unit.

# **WARNING**

If this appliance is conditioning a space with an area smaller than TAmin or stored in a space with an area smaller than Amin as defined by this instruction, then that space must be without continuously operating open flames (e.g. an operating gas appliance) or other potential ignition sources (e.g. an operating electric heater or similar hot surface). A flame-producing device may be installed in the same space if the device is provided with an effective flame arrest system.

# **A** CAUTION

Auxiliary devices which may be a potential ignition source shall not be installed in the duct work. Examples of such potential ignition sources are hot surfaces with a temperature exceeding 700°C and electric switching devices.

# **A** CAUTION

The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction

# **▲** CAUTION

Children should be supervised not to play with the appliance.

# **▲** CAUTION

Any personnel installing, decommissioning, or performaing maintenance on the unit must be properly trained with A2L refrigerants.

# **A** CAUTION

Servicing shall be performed only as recommended by the manufacturer.

# WARNING

- •This appliance must be installed in accordance with local and national wiring regulations.
- •If the appliance is not fitted with an option for full disconnection from power, a means of disconnection must be incorporated in the fixed wiring in accordance with national and local wiring regulations.

# **A** CAUTION

Leak Detection System installed. Unit must be powered except for service.

# WARNING

- •Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- •The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance, or an operating electric heater).
- •Do not pierce or burn.
- •Be aware that refrigerants may not contain an odor

# WARNING

Ducts connected to an appliance shall not contain a potential ignition source.

## **▲** IMPORTANT

Pipe work, including piping material, pipe routing, and installation shall include protection from physical damage in operation and service, and be in compliance with national and local codes and standards, such as ASHRAE 15, ASHRAE 15.2, IAPMO Uniform Mechanical Code, ICC International Mechanical Code, or CSA B52. All field joints shall be accessible for inspection prior to being covered or enclosed.

## **A** IMPORTANT

Refrigerant sensors for refrigerant detection systems shall only be replaced with sensors specified by the appliance manufacture.

# **A** CAUTION

This unit is equipped with electrically powered safety measures. To be effective, the unit must be electrically powered at all times after installation, other than when servicing.

#### **A2L Refrigerant Considerations**

Ensure that the work area is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects, taking into account the effects of aging or continual vibration from sources such as compressors or fans.

Under no circumstances shall potential sources of ignition be used when searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used. Electronic leak detectors may be used to detect refrigerant leaks but, in the case of flammable refrigerants, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed. Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work. If a leak is suspected, all naked flames shall be removed/extinguished. If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.

When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practices be followed since flammability is a consideration. The following procedure shall be adhered to:

- -Safely remove refrigerant following local and national regulations.
- -Evacuate the circuit.
- -Purge the circuit with inert gas.
- -Evacuate.
- -Purge the circuit with inert gas.
- -Open the circuit

The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygenfree nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems. Refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be vented down to atmospheric pressure to enable work to take place. Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and that ventilation is available.

OPTIONS / ACC	ESSORIES				
Itam Decemention		Order		Size	
Item Description		Number	156	180	240
COOLING SYSTEM					
Condensate Drain Trap	PVC	22H54	Х	Х	Х
	Copper	76W27	Х	Х	Х
Drain Pan Overflow Sv	vitch	21 <b>Z</b> 07	OX	OX	OX
BLOWER - SUPPLY A	.IR				
Blower Option	MSAV® Multi-Stage Air Volume option (With VFD Bypass Control)	Factory	0	0	
N	MSAV® Multi-Stage Air Volume option (Without VFD Bypass Control)	Factory	0	0	0
Motors	Belt Drive - 3 hp	Factory	0	0	
	Belt Drive - 5 hp	Factory	0	0	0
	Belt Drive - 7.5 hp	Factory		0	0
	Belt Drive - 10 hp	Factory			0
Drive Kits	Kit #1 535-725 rpm	Factory	0	0	
See Blower Data Table	es for usage and Kit #2 710-965 rpm	Factory	0	0	
selection	Kit #3 685-856 rpm	Factory	0	0	0
	Kit #4 850-1045 rpm	Factory	0	0	0
	Kit #5 945-1185 rpm	Factory	0	0	0
	Kit #6 850-1045 rpm	Factory		0	0
	Kit #7 945-1185 rpm	Factory		0	0
	Kit #8 1045-1285 rpm	Factory		0	0
	Kit #10 1045-1285 rpm	Factory			0
	Kit #11 1105-1330 rpm	Factory			0
	Blower Belt Auto-Tensioner	24B80	X	Х	X
CABINET					
Combination Coil/Hail	Guards	23U71	OX	OX	OX
Corrosion Protection		Factory	0	0	0
CONTROLS					
Commercial Controls	LonTalk® Module	54W27	OX	OX	OX
	Novar® LSE	Factory	0	0	0
Dirty Filter Switch		53W68	OX	OX	OX
Fresh Air Tempering		21Z08	OX	OX	OX
· · · · · · · · · · · · · · · · · · ·	oly or Return (Power board and one sensor)	22H56	OX	OX	OX
Smoke Detector - Supp	ply and Return (Power board and two sensors)	22H57	OX	OX	OX

NOTE - Order Numbers shown are for ordering field installed accessories.

OX = Configure To Order (Factory Installed) or Field Installed.

O = Configure To Order (Factory Installed).

X = Field Installed.

Item Description		Order		Size		
nom bescription		Number	156	180	240	
NDOOR AIR QUALITY						
Air Filters						
Healthy Climate® High Efficiency Air Filters	MERV 8	54W67	OX	OX	OX	
24 x 24 x 2 (Order 6 per unit)	MERV 13	52W40	OX	OX	OX	
	MERV 16	21U42	X	Х	Х	
Replacement Media Filter With Metal Mesh Frame (includes non-pleated filter media)		44N61	X	Х	Х	
Indoor Air Quality (CO₂) Sensors						
Sensor - Wall-mount, off-white plastic cover with LCD	display	77N39	Х	Х	Х	
Sensor - Wall-mount, off-white plastic cover, no displa	ay	23V86	Х	Х	Х	
Sensor - Black plastic case, LCD display, rated for pla	enum mounting	87N52	Х	Х	Х	
Sensor - Black plastic case, no display, rated for plen	um mounting	23V87	Х	Х	Х	
CO <sub>2</sub> Sensor Duct Mounting Kit - for downflow applica	tions	23Y47	Х	Х	Х	
Aspiration Box - for duct mounting non-plenum rated	CO <sub>2</sub> sensors ( <b>77N39</b> )	90N43	Х	Х	Х	
Needlepoint Bipolar Ionization (NPBI)						
Needlepoint Bipolar Ionization (NPBI) Kit		21U37	X	Х		
		21U38			Х	
UVC Germicidal Light Kit						
<sup>1</sup> Healthy Climate <sup>®</sup> UVC Light Kit (110/230v-1ph)		21A94	Х	Х	Χ	
Step-Down Transformers	460V primary, 230V secondary	10H20	X	Х	Х	
	575V primary, 230V secondary	10H21	X	X	Х	
ELECTRICAL						
Voltage 60 Hz	208/230V - 3 phase	Factory	0	0	0	
	460V - 3 phase	Factory	0	0	0	
	575V - 3 phase	Factory	0	0	0	
Disconnect Switch	80 amp	54W85	OX	OX	OX	
(see Electric Heat Tables for usage,	150 amp	54W86	OX	OX	OX	
	250 amp	54W87	OX	OX	OX	
HACR Circuit Breakers		Factory	0	0	0	
<sup>2</sup> Short-Circuit Current Rating (SCCR) of 100kA (inclu	ides Phase/Voltage Detection)	Factory	0	0	0	
GFI Service Outlets 15 amp non-powere	d, field-wired (208/230V, 460V, 575V)	74M70	OX	OX	OX	
15 amp factory-	wired and powered (208/230V, 460V)	Factory	0	0	0	
³ 20 amp non-powere	d, field-wired (208/230V, 460V, 575V)	67E01	Х	Х	Х	
³ 20	amp non-powered, field-wired (575V)	Factory	0	0	0	
Weatherproof Cover for GFI		10C89	Х	Х	Х	

<sup>&</sup>lt;sup>1</sup> Lamps operate on 110-230V single-phase power supply. Step-down transformer may be ordered separately for 460V and 575V units. Alternately, 110V power supply may be used to directly power the UVC ballast(s).

NOTE - Order Numbers shown are for ordering field installed accessories.

 $<sup>^{\</sup>rm 2}$  Disconnect Switch not available with SCCR option.

SCCR option is only available with factory installed electric heat or no electric. SCCR option is not available if the MOCP of the configured unit is greater than 200A.

 $<sup>^{\</sup>rm 3}$  Canada requires a minimum 20 amp circuit. Select 20 amp, non-powered, field wired GFI.

OX = Configure To Order (Factory Installed) or Field Installed.

O = Configure To Order (Factory Installed).

X = Field Installed.

Item Description	Order		Size	
item bescription	Number	156	180	240
ELECTRIC HEAT				
15 kW 208/230V-3ph	30U62	OX	OX	OX
460V-3ph	30U63	OX	OX	OX
575V-3ph	30U64	OX	OX	OX
30 kW 208/230V-3ph	30U68	OX	OX	ОХ
460V-3ph	30U69	OX	OX	ОХ
575V-3ph	30U70	OX	OX	ОХ
45 kW 208/230V-3ph	30U74	OX	OX	OX
460V-3ph	30U75	OX	OX	ОХ
575V-3ph	30U76	OX	OX	ОХ
60 kW 208/230V-3ph	30U80	OX	OX	OX
460V-3ph	30U81	OX	OX	OX
575V-3ph	30U82	OX	OX	OX
90 kW 208/230V-3ph	30U83			ОХ
460V-3ph	30U84			ОХ
575V-3ph	30U85			OX
ECONOMIZER				
High Performance Economizer (Approved for California Title 24 Building Standards / A	AMCA Clas	s 1A Cert	tified)	
High Performance Economizer (Downflow or Horizontal)	22J18	OX	ОХ	OX
Includes Economizer Dampers with Outdoor Air Hood				
Downflow Applications - Use furnished Outdoor Air Hood - Order Downflow Barometric Relief Dampers with Exhaust Hood separately				
Harizantal Applications - Llos furnished Outdoor Air Hood - Order Harizantal Barrenstria				
Relief Dampers with Exhaust Hood separately				
Relief Dampers with Exhaust Hood separately  Economizer Controls	21Z09	OX	OX	OX
Relief Dampers with Exhaust Hood separately  Economizer Controls  Differential Enthalpy (Not for Title 24)  Order 2	21Z09 Factory	OX O	OX O	0X 0
Relief Dampers with Exhaust Hood separately  Economizer Controls  Differential Enthalpy (Not for Title 24)  Sensible Control  Sensor is Furnished				0
Relief Dampers with Exhaust Hood separately  Economizer Controls  Differential Enthalpy (Not for Title 24)  Sensible Control  Sensor is Furnished  Single Enthalpy (Not for Title 24)	Factory	0	0	0
Relief Dampers with Exhaust Hood separately  Economizer Controls  Differential Enthalpy (Not for Title 24)  Sensible Control  Sensor is Furnished  Single Enthalpy (Not for Title 24)  Global Control  Sensor Field Provided	Factory 21Z09	O OX	O OX	0 0X
Relief Dampers with Exhaust Hood separately  Economizer Controls  Differential Enthalpy (Not for Title 24)  Sensible Control  Sensor is Furnished  Single Enthalpy (Not for Title 24)  Global Control  Sensor Field Provided  Building Pressure Control	Factory 21Z09 Factory	0 0X 0	0 0X 0	0 0X 0 X
Relief Dampers with Exhaust Hood separately  Economizer Controls  Differential Enthalpy (Not for Title 24)  Sensible Control  Sensor is Furnished  Single Enthalpy (Not for Title 24)  Global Control  Sensor Field Provided  Building Pressure Control  Outdoor Air CFM Control	Factory 21Z09 Factory 13J77	0 0X 0 X	0 0X 0 X	0 0X 0 X
Relief Dampers with Exhaust Hood separately  Economizer Controls  Differential Enthalpy (Not for Title 24)  Sensible Control  Sensor is Furnished  Single Enthalpy (Not for Title 24)  Global Control  Sensor Field Provided  Building Pressure Control  Outdoor Air CFM Control  Barometric Relief Dampers With Exhaust Hood	Factory 21Z09 Factory 13J77	0 0X 0 X	0 0X 0 X	0 0 0 X X
Relief Dampers with Exhaust Hood separately  Economizer Controls  Differential Enthalpy (Not for Title 24)  Sensible Control  Sensor is Furnished  Single Enthalpy (Not for Title 24)  Global Control  Sensor Field Provided  Building Pressure Control  Outdoor Air CFM Control  Barometric Relief Dampers With Exhaust Hood  Downflow Barometric Relief Dampers	Factory 21Z09 Factory 13J77 13J76	O OX O X X	O OX O X X	0 0 0 X X
Relief Dampers with Exhaust Hood separately  Economizer Controls  Differential Enthalpy (Not for Title 24) Order 2 Sensible Control Sensor is Furnished Single Enthalpy (Not for Title 24)  Global Control Sensor Field Provided Building Pressure Control  Outdoor Air CFM Control  Barometric Relief Dampers With Exhaust Hood  Downflow Barometric Relief Dampers  Horizontal Barometric Relief Dampers	Factory 21Z09 Factory 13J77 13J76	O OX O X X X	O OX O X X	0X 0
Relief Dampers with Exhaust Hood separately  Economizer Controls  Differential Enthalpy (Not for Title 24)  Sensible Control  Sensor is Furnished  Single Enthalpy (Not for Title 24)  Global Control  Sensor Field Provided  Building Pressure Control  Outdoor Air CFM Control  Barometric Relief Dampers With Exhaust Hood  Downflow Barometric Relief Dampers  Horizontal Barometric Relief Dampers  OUTDOOR AIR	Factory 21Z09 Factory 13J77 13J76	O OX O X X X	O OX O X X	0 0 0 X X
Sensible Control Sensor is Furnished Single Enthalpy (Not for Title 24) Global Control Sensor Field Provided Building Pressure Control	Factory 21Z09 Factory 13J77 13J76	O OX O X X X	O OX O X X	0 0 0 X X

NOTE - Order Numbers shown are for ordering field installed accessories.

OX = Configure To Order (Factory Installed) or Field Installed.

X = Field Installed.

O = Configure To Order (Factory Installed).

OPTIONS / ACCESSORIES					
Item Description		Order		Size	
		Number	156	180	240
POWER EXHAUST (DOWNFLOW APPLICATIONS ONLY)					
Standard Static, SCCR Rated	208/230V	22H90	OX	OX	OX
	460V	22H91	OX	OX	OX
	575V	22V34	OX	OX	OX
ROOF CURBS					
Hybrid Roof Curbs, Downflow					
8 in. height		11F58	Х	Х	Х
14 in. height		11F59	Х	Х	Х
18 in. height		11F60	Х	Х	Х
24 in. height		11F61	Х	Х	Х
Adjustable Pitch Curb					
14 in. height		43W26	Χ	X	Χ
Standard Roof Curbs, Horizontal - Requires Horizontal Return Air Panel I	Kit				
26 in. height - slab applications		11T89	Χ	X	Χ
37 in. height - rooftop applications		11T96	Χ	Х	Х
Insulation Kit For Standard Horizontal Roof Curbs					
For 26 in. Curb		73K32	Χ	X	Χ
For 37 in. Curb		73K34	Χ	X	Χ
Horizontal Return Air Panel Kit					
Required for Horizontal Applications with Roof Curb		87M00	Χ	Х	Х
CEILING DIFFUSERS					
Step-Down - Order one	RTD11-185S	13K63	Х	Х	
ŀ	RTD11-275S	13K64			Х
Flush - Order one	FD11-185S	13K58	Х	Х	
	FD11-275S	13K59			Х
Transitions (Supply and Return) - Order one	1DIFF33C-1	12X68	Х	Х	
C	1DIFF34C-1	12X70			Х

<sup>&</sup>lt;sup>4</sup> Field installed Power Exhaust requires Economizer with Outdoor Air Hood and Downflow Barometric Relief Dampers with Exhaust Hood. Must be ordered separately.

NOTE - Order Numbers shown are for ordering field installed accessories.

OX = Configure To Order (Factory Installed) or Field Installed.

O = Configure To Order (Factory Installed).

X = Field Installed.

SPECIFI	CATIONS			
Model		LHT156H5M	LHT180H5M	LHT240H5M
Nominal To		13 Ton	15 Ton	20 Ton
Efficiency T		High	High	High
Blower Type	e	MSAV®	MSAV®	MSAV®
		Multi-Stage Air Volume	Multi-Stage Air Volume	Multi-Stage Air Volume
Cooling	Gross Cooling Capacity (Btuh)	160,000	182,000	237,000
Performanc	- 3 - 1 3 \ /	156,000	176,000	228,000
	<sup>1</sup> AHRI Rated Air Flow (cfm)	4500	5500	7000
	<sup>1</sup> IEER (Btuh/Watt)	15.4	15.5	15.5
	<sup>1</sup> EER (Btuh/Watt)	12.1	11.1	11.1
	Total Unit Power (kW)	12.9	15.8	20.5
Heating	<sup>1</sup> Total High Heat Capacity (Btuh)	150,000	176,000	226,000
Performanc	e ¹ COP	3.4	3.4	3.4
	Total Unit Power (kW)	12.9	15.2	19.5
	<sup>1</sup> Total Low Heat Capacity (Btuh)	86,000	104,000	128,000
	¹ COP	2.1	2.1	2.1
	Total Unit Power (kW)	12.0	14.5	17.8
Electric Hea	,		See page 12	
Sound Ratin		94	94	94
Refrigerant		R-454B	R-454B	R-454B
	Circuit 1	21 lbs. 0 oz.	23 lbs. 0 oz.	20 lbs. 12 oz.
	Circuit 2	19 lbs. 0 oz.	19 lbs. 8 oz.	19 lbs. 4 oz.
Compresso	r Type (number)	10 103. 0 02.	Two-Stage Scroll (1)	10 103. 4 02.
Compresso	r type (number)		Single-Stage Scroll (1)	
Outdoor	Net face area - ft.² (total)	55.1	55.1	55.1
Coils	Number of rows	2	2	2
Colls	Fins - in.	20	20	20
Outdoor	Motor HP (number and type)	1/3 (6 PSC)	1/3 (6 PSC)	1/3 (6 PSC)
Coil Fans		,	1075	`
Coll Falls	Rpm	1075		1075
	Watts (total)	2150	2150	2150
	Diameter (Number) - in.	(6) 24	(6) 24	(6) 24
	Blades	3	3	3
	Total Air volume - cfm	16,300	16,300	16,300
Indoor	Net face area - ft.² (total)	21.4	21.4	21.4
Coils	Tube diameter - in.	3/8	3/8	3/8
	Rows	4	4	4
	Fins - in.	14	14	14
	Condensate drain size (NPT) - in.	(1) 1	(1) 1	(1) 1
	Expansion device type		Port Thermostatic Expans	
<sup>3</sup> Indoor	Nominal motor HP	3, 5	3, 5, 7.5	5, 7.5, 10
Blower	Maximum usable motor HP (US)	3.45, 5.75	3.45, 5.75, 8.63	5.75, 8.62, 11.5
and	Motor - Drive kit number	3 HP	3 HP	5 HP
Drive		Kit 1 535-725 rpm	Kit 1 535-725 rpm	Kit 3 685-856 rpm
Selection		Kit 2 710-965 rpm	Kit 2 710-965 rpm	Kit 4 850-1045 rpm
		5 HP	5 HP	Kit 5 945-1185 rpm
				7.5 HP
		Kit 3 - 685-856 rpm	Kit 3 - 685-856 rpm	
		Kit 4 850-1045 rpm	Kit 4 850-1045 rpm	Kit 6 850-1045 rpm
		Kit 5 945-1185 rpm	Kit 5 945-1185 rpm	Kit 7 945-1185 rpm
			7.5 HP	Kit 8 1045-1285 rpm
			Kit 6 850-1045 rpm	10 HP
			Kit 7 945-1185 rpm	Kit 7 945-1185 rpm
			Kit 8 1045-1285 rpm	Kit 10 1045-1285 rpm
			1.00 10 10 1200 Ipili	Kit 10 1045-1203 rpm
	Wheel (Number) diameter x width - in.	(2) 15 x 15 in.	(2) 15 x 15 in.	(2) 15 x 15 in.
Filters	Type of filter	(L) IO A IO III.	MERV 4, Disposable	( <i>L)</i> 10 A 10 III.
1 111013	Number and size - in.		(6) 24 x 24 x 2	
Line velteer	e data (Volts-Phase-Hz)	200	3/230-3-60, 460-3-60, 575-3	2.60
	pacity includes evaporator blower motor heat deduc			

NOTE - Net capacity includes evaporator blower motor heat deduction. Gross capacity does not include evaporator blower motor heat deduction.

<sup>&</sup>lt;sup>1</sup> AHRI Certified to AHRI Standard 340/360:

 $<sup>\</sup>textbf{Cooling Ratings} - 95^{\circ} \text{F outdoor air temperature and } 80^{\circ} \text{F db/67}^{\circ} \text{F wb entering indoor coil air.}$ 

High Temperature Heating Ratings - 47°F db/43°F wb outdoor air temperature and 70°F entering indoor coil air.

**Low Temperature Heating Ratings** - 17°F db/15°F wb outdoor air temperature and 70°F entering indoor coil air.

<sup>&</sup>lt;sup>2</sup> Using total air volume and system static pressure requirements determine from blower performance tables rpm and motor output required. Maximum usable output of motors furnished are shown. In Canada, nominal motor output is also maximum usable motor output. If motors of comparable output are used, be sure to keep within the service factor limitations outlined on the motor nameplate.

# **BLOWER DATA**

# BLOWER TABLE INCLUDES RESISTANCE FOR BASE UNIT ONLY WITH DRY INDOOR COIL & AIR FILTERS IN PLACE

# FOR ALL UNITS ADD:

- 1 Wet indoor coil air resistance of selected unit.
  2 Any factory installed options air resistance (electric heat, Economizer, etc.)
  3 Any field installed accessories air resistance (electric heat, duct resistance, diffuser, etc.)

Then determine from blower table blower motor output and drive required. See page 10 for wet coil, option/accessory air resistance data, and factory installed drive kit specifications. See page 11 for minimum air volume required for use with optional electric heat.

	2.60	BHP	-	;	1	1	:	4.15	4.45	4.70	2.00	5.30	2.60	2.90	6.25	6.55	06.90	7.25	7.60	8.00	8.35	8.75	9.15	9.60	10.05	10.45	:	:	:	:	:	:	:	;		
	2.	RPM	:	:	:	:	1	1205	1210	1215	1225	1230	1235	1240	1250	1255	1265	1270	1275	1285	1290	1300	1305	1315	1325	1330	;	1	1	:	:	:	;	;	1	
	2.40	BHP	:	;	:	:	-	3.85	4.10	4.35	4.65	4.90	5.20	5.50	5.80	6.10	6.45	6.75	7.10	7.45	7.85	8.25	8.60	9.00	9.40	9.85	10.30	10.80	11.20	1	:	;	;	;	1	
	2.	RPM	;	;	:	-	-	1160	1165	1175	1180	1185	1195	1200	1205	1215	1220	1225	1235	1240	1250	1260	1265	1275	1280	1290	1300	1310	1315	1	:	;	:	;	1	
	50	BHP	:	;	:	1	3.30	3.55	3.75	4.05	4.25	4.50	4.80	5.10	5.35	5.65	5.95	6.30	09.9	6.95	7.30	7.65	8.05	8.40	8.85	9.25	9.65	10.10	10.55	11.05	11.50	:	;	;	1	
	2.20	RPM	:	:	:		1110	1115	1120	1130	1135	1140	1150	1155	1160	1170	1175	1185	1190	1200	1205	1215	1225	1230	1240	1250	1255	1265	1275	1285	1295	:	;	:	:	
	2.00	ВНР	:	:	:		3.00	3.25	3.45	3.65	3.90	4.15	4.40	4.70	4.95	5.20	5.50	5.85	6.10	6.45	6.75	7.15	7.50	7.85	8.25	8.65	9.02	9.40	9.85	10.30	10.80	11.25	;	:		
	2.	RPM	:	:	1		1060	1070	1075	1080	1085	1095	1100	1110	1115	1120	1130	1140	1145	1155	1160	1170	1180	1185	1195	1205	1215	1220	1230	1240	1250	1260	;	:	:	1
	1.80	BHP	:	:	1	2.55	2.70	2.90	3.10	3.30	3.55	3.80	4.00	4.25	4.50	4.80	5.05	5.35	2.60	5.95	6.25	09.9	06.9	7.25	7.65	8.05	8.35	8.75	9.20	9.60	10.05	10.50	11.00	11.45		:
(Pa)	1	RPM	:	:	;	1005	1010	1020	1025	1030	1040	1045	1050	1060	1065	1075	1080	1090	1095	1105	1115	1125	1130	1140	1150	1160	1165	1175	1185	1195	1205	1215	1225	1235	:	:
r Gauge	1.60	BHP	:	:	2.10	2.25	2.45	2.60	2.80	3.00	3.20	3.40	3.65	3.85	4.10	4.35	4.60	4.85	5.10	5.40	5.75	6.05	6.35	6.70	7.05	7.40	7.75	8.15	8.55	8.95	9.40	9.80	10.25	10.70	11.20	:
es Wate	<del>-</del>	RPM	:	:	950	922	096	965	970	980	985	995	1000	1010	1015	1025	1030	1040	1045	1055	1065	1075	1080	1090	1100	1110	1120	1130	1140	1150	1160	1170	1180	1190	1200	:
TOTAL STATIC PRESSURE - Inches Water Gauge (Pa)	1.40	BHP	:	1.70	1.85	2.00	2.15	2.30	2.45	2.65	2.85	3.05	3.25	3.45	3.65	3.90	4.15	4.40	4.65	4.95	5.25	5.50	5.80	6.10	6.45	6.80	7.15	7.50	7.85	8.25	8.65	9.05	9.55	10.00	10.45	10.90
ESSUR	1	RPM	:	882	890	006	902	910	915	925	930	940	945	922	096	920	975	985	966	1005	1015	1020	1030	1040	1050	1060	1070	1080	1090	1100	1110	1120	1135	1145	1155	1165
ATIC PR	.20	BHP	1.30	1.45	1.60	1.70	1.85	2.00	2.15	2.35	2.50	2.70	2.90	3.05	3.25	3.45	3.70	3.95	4.20	4.45	4.65	4.95	5.25	5.50	5.85	6.15	6.45	6.80	7.20	7.60	7.95	8.35	8.75	9.20	9.65	10.05
TAL ST	1.	RPM	820	825	830	840	845	850	855	865	870	880	890	895	902	910	920	930	940	950	922	965	975	985	966	1005	1015	1025	1040	1050	1060	1070	1080	1095	1105	1115
1	1.00	ВНР	1.10	1.20	1.30	1.45	1.60	1.70	1.85	2.00	2.15	2.30	2.50	2.65	2.85	3.05	3.25	3.45	3.70	3.95	4.15	4.45	4.70	4.95	5.25	5.55	5.85	6.15	6.55	06.9	7.20	7.60	8.00	8.40	8.85	9.30
	1	RPM	755	260	765	775	780	785	795	800	810	815	825	835	840	850	860	870	880	890	006	910	920	930	940	950	096	970	985	995	1005	1015	1030	1040	1055	1065
	.80	BHP	0.90	1.00	1.10	1.20	1.30	1.40	1.55	1.65	1.80	1.95	2.10	2.25	2.45	2.60	2.80	3.00	3.20	3.40	3.65	3.85	4.10	4.35	4.65	4.90	5.20	5.50	5.85	6.15	6.55	6.85	7.20	_		8.45
		RPM	089	682	969	200	710	715	725	730	740		_		775		195		815	825	835		855		880		006	910	925	935	950	096	970	_	1000	1010
	09.0	M BHP	0.70	0.75	5 0.85	0.95	1.05	5 1.10	5 1.25	5 1.35	1.45	0 1.60	_	1.85	0 2.00	0 2.15	0 2.35			5 2.90		_	3.55	_	_	_	5 4.55	0 4.85	5.15	5 5.45	5 5.75	0 6.15	0 6.45	_		09'2
		P RPM	009 0	5 610	0 615	.0 620	2 630	5 635	0 645	0 655	099 0	5 670	_	.5 690	002 0	_	0 720	5 730			0 765		062 0	_	0 810		_	0 850	.5 860	5 875	15 885	006 0.	5 910	_	.0 940	0 950
	0.40	M BHP	0.50	5 0.55		0.70	0.75	15 0.85	65 0.90	1.00	75 1.10	1.25	1.35	1.45	5 1.60		1.90		5 2.20	_	00 2.60		5 3.00	3.20	10 3.40			30 4.20	0 4.45	15 4.75	20   5.05	5.40	5.65	00.9 00		06.80
		P RPM	0 505	5 515	0 520	5 530	0 540	5 545	0 555	0 565	5 575	5 585	_	5 605	5 615	0 630	0 640	5 650	99 0		069 0		0 715		_	_	5 765	0 780	2 790	0 805	0 820	0 835	0 845	0 860	5 875	068 0
	0	M BHP	5 0.30	5 0.35	5 0.40	5 0.45	5 0.50	5 0.55	0.60	5 0.70	0.75	0.85	_	5 1.05	1.15	0 1.30				5 1.85	0 2.00	5 2.20	0 2.40		5 2.80	_	5 3.25	3.50	5 3.75	0 4.00	5 4.30	0 4.60	5 4.90			5.90
	ne 0.20	RPM	385	395	405	415	425	435	445	455	470	480	495	202	520	530	545	260	220	585	009	615	630	640	655	670	685	700	715	730	745	760	775	790	802	820
	Air Volume	5	2750	3000	3250	3200	3750	4000	4250	4500	4750	2000	5250	2200	2120	0009	6250	0059	6750	2000	7250	7500	7750	8000	8250	8200	8750	0006	9250	9200	9750	10,000	10,250	10,500	10,750	11.000

#### **BLOWER DATA**

#### **FACTORY INSTALLED BELT DRIVE KIT SPECIFICATIONS**

Nominal hp	Maximum hp	Drive Kit Number	RPM Range
3	3.45	1	535 - 725
3	3.45	2	710 - 965
5	5.75	3	685 - 856
5	5.75	4	850 - 1045
5	5.75	5	945 - 1185
7.5	8.63	6	850 - 1045
7.5	8.63	7	945 - 1185
7.5	8.63	8	1045 - 1285
10	11.50	7	945 - 1185
10	11.50	10	1045 - 1285
10	11.50	11	1135 - 1330

NOTE - Using total air volume and system static pressure requirements determine from blower performance tables rpm and motor output required. Maximum usable output of motors furnished are shown. In Canada, nominal motor output is also maximum usable motor output. If motors of comparable output are used, be sure to keep within the service factor limitations outlined on the motor nameplate.

#### FACTORY INSTALLED OPTIONS/FIELD INSTALLED ACCESSORY AIR RESISTANCE

Air Volume	Wet Indoor Coil	Electric Heat	Economizer		Filters		Horizontal Roof Curb
cfm	in. w.g.	in. w.g.	in. w.g.	MERV 8	MERV 13	MERV 16	in. w.g.
3250	.03			.01	.04	0.07	.04
3500	.03			.01	.04	0.08	.05
3750	.03			.01	.04	0.08	.05
4000	.04			.01	.04	0.09	.06
4250	.04			.01	.05	0.10	.07
4500	.05			.01	.05	0.10	.07
4750	.05			.02	.05	0.11	.08
5000	.05			.02	.06	0.12	.08
5250	.06			.02	.06	0.12	.09
5500	.07			.02	.06	0.13	.10
5750	.07			.02	.07	0.14	.11
6000	.08	.01		.03	.07	0.14	.11
6250	.08	.01	.01	.03	.07	0.15	.12
6500	.09	.01	.02	.03	.08	0.16	.13
6750	.10	.01	.03	.03	.08	0.17	.14
7000	.10	.01	.04	.04	.08	0.17	.15
7250	.11	.01	.05	.04	.09	0.18	.16
7500	.12	.01	.06	.04	.09	0.19	.17
8000	.13	.02	.09	.05	.10	0.21	.19
8500	.15	.02	.11	.05	.10	0.22	.21
9000	.16	.04	.14	.06	.11	0.24	.24
9500	.18	.05	.16	.07	.12	0.25	.26
10,000	.20	.06	.19	.07	.12	0.27	.29
10,500	.22	.09	.22	.08	.13	0.29	.31
11,000	.24	.11	.25	.09	.14	0.30	.34

NOTE - Motor service factor limit - 1.0.

#### **BLOWER DATA**

# MINIMUM AIR VOLUME REQUIRED FOR USE WITH OPTIONAL ELECTRIC HEAT

Electric Heat kW	Minimum cfm
15	6000
30	6000
45	6000
60	6000
90	6000

#### POWER EXHAUST FAN PERFORMANCE

Return Air System Static Pressure	Air Volume Exhausted					
in. w.g.	cfm					
0.00	8630					
0.05	8210					
0.10	7725					
0.15	7110					
0.20	6470					
0.25	5790					
0.30	5060					
0.35	4300					
0.40	3510					
0.45	2690					
0.50	1840					

#### CEILING DIFFUSER AIR RESISTANCE - in. w.g.

A !			Step-Dow	n Diffuser			Flush [	Diffuser
Air Volume		RTD11-185S			RTD11-275S			
cfm	2 Ends Open	1 Side/2 Ends Open	All Ends & Sides Open	2 Ends Open	1 Side/2 Ends Open	All Ends & Sides Open	FD11-185S	FD11-275S
5000	.51	.44	.39				.27	
5200	.56	.48	.42				.30	
5400	.61	.52	.45				.33	
5600	.66	.56	.48				.36	
5800	.71	.59	.51				.39	
6000	.76	.63	.55	.36	.31	.27	.42	.29
6200	.80	.68	.59				.46	
6400	.86	.72	.63				.50	
6500				.42	.36	.31		.34
6600	.92	.77	.67				.54	
6800	.99	.83	.72				.58	
7000	1.03	.87	.76	.49	.41	.36	.62	.40
7200	1.09	.92	.80				.66	
7400	1.15	.97	.84				.70	
7500				.51	.46	.41		.45
7600	1.20	1.02	.88				.74	
8000				.59	.49	.43		.50
8500				.69	.58	.50		.57
9000				.79	.67	.58		.66
9500				.89	.75	.65		.74
10,000				1.00	.84	.73		.81
10,500				1.10	.92	.80		.89
11,000				1.21	1.01	.88		.96

#### CEILING DIFFUSER AIR THROW DATA - ft.

	Air Valuma	<sup>1</sup> Effective Thr	ow Range - ft.		Air Volume	<sup>1</sup> Effective Thr	ow Range - ft.
Size	Air Volume cfm	RTD11-185S Step-Down	FD11-185S Flush	Size	cfm	RTD11-275S Step-Down	FD11-275S Flush
	5600	39 - 49	28 - 37		7200	33 - 38	26 - 35
	5800	42 - 51	29 - 38		7400	35 - 40	28 - 37
450	6000	44 - 54	40 - 50		7600	36 - 41	29 - 38
156, 180	6200	45 - 55	42 - 51		7800	38 - 43	40 - 50
100	6400	46 - 55	43 - 52	240	8000	39 - 44	42 - 51
	6600	47 - 56	45 - 56		8200	41 - 46	43 - 52
	w is the horizontal or vertical distance an airstream travels on leaving the outl				8400	43 - 49	44 - 54
ffuser before the maximum velocity is reduced to 50 ft. per minute. Four ı.					8600	44 - 50	46 - 57
•			Page 1	1	8800	47 - 55	48 - 59

#### **ELECTRICAL/ELECTRIC HEAT DATA 13 TON** LHT156H5M Model <sup>1</sup> Voltage - 60Hz 208/230V - 3 Ph 460V - 3 Ph 575V - 3 Ph Compressor 1 Rated Load Amps 23.2 9.5 7.8 (Non-Inverter) Locked Rotor Amps 142 73.1 55 22.4 7.2 Compressor 2 Rated Load Amps 9.1 (Non-Inverter) Locked Rotor Amps 166.2 74.6 54 Outdoor Fan Full Load Amps (6 Non-ECM) 2.4 1 1.3 Motors (6) Total 14.4 7.8 6 1 Power Exhaust Full Load Amps 2.4 1.3 (2) 0.33 HP 4.8 2 Total 2.6 Service Outlet 115V GFI (amps) 15 15 20 HP Indoor Blower 3 5 3 5 3 5 Motor Full Load Amps 10.6 16.7 4.8 7.6 3.9 6.1 <sup>2</sup> Maximum **Unit Only** 90 100 40 45 30 35 Overcurrent With (2) 0.33 HP 100 110 45 45 35 35 Protection (MOCP) Power Exhaust <sup>3</sup> Minimum **Unit Only** 77 83 34 37 27 30

82

88

37

39

29

32

#### **ELECTRIC HEAT DATA**

Ampacity (MCA)

Circuit

	Electric Hea	t Voltage	208V	240V	208V	240V	480V	480V	600V	600V			
<sup>2</sup> Maximum	Unit+	15 kW	125	125	<sup>4</sup> 125	150	60	60	45	50			
Overcurrent	Electric Heat	30 kW	175	175	175	175	80	90	70	70			
Protection (MOCP)		45 kW	4 200	225	4 200	225	110	110	90	90			
		60 kW	225	225	4 225	250	110	110	90	90			
<sup>3</sup> Minimum	Unit+	15 kW	116	122	122	128	57	59	45	48			
Circuit	Electric Heat	30 kW	155	167	161	173	79	82	63	66			
Ampacity (MCA)		45 kW	194	212	200	218	102	105	81	84			
		60 kW	202	221	208	227	106	109	85	87			
<sup>2</sup> Maximum	Unit+	15 kW	<sup>4</sup> 125	150	150	150	60	70	50	50			
Overcurrent	Electric Heat			Electric Heat and (2) 0.33 HP	30 kW	175	175	4 175	200	90	90	70	70
Protection (MOCP)	Power Exhaust	45 kW	4 200	225	225	225	110	110	90	90			
		60 kW	4 225	250	4 225	250	110	125	90	90			
<sup>3</sup> Minimum	Unit+	15 kW	121	127	127	133	59	62	47	50			
Circuit	Electric Heat	30 kW	160	172	166	178	82	85	65	68			
Ampacity (MCA)	and (2) 0.33 HP Fower Exhaust	45 kW	199	217	205	223	104	107	83	86			
		60 kW	207	226	213	232	109	112	87	89			

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 5000 amps.

With (2) 0.33 HP

Power Exhaust

<sup>&</sup>lt;sup>1</sup> Extremes of operating range are plus and minus 10% of line voltage.

<sup>&</sup>lt;sup>2</sup> HACR type breaker or fuse.

<sup>&</sup>lt;sup>3</sup> Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.

<sup>&</sup>lt;sup>4</sup> Factory installed circuit breaker not available.

#### **ELECTRICAL/ELECTRIC HEAT DATA 15 TON** LHT180H5M Model <sup>1</sup> Voltage - 60Hz 208/230V - 3 Ph 460V - 3 Ph 575V - 3 Ph Compressor 1 Rated Load Amps 25.2 10.6 8.6 (Non-Inverter) Locked Rotor Amps 178.5 79.1 65 27.7 9 Compressor 2 Rated Load Amps 11.5 (Non-Inverter) Locked Rotor Amps 178.5 78 103 Outdoor Fan Full Load Amps (6 Non-ECM) 2.4 1.3 1 Motors (6) Total 14.4 7.8 6 Power Exhaust Full Load Amps 2.4 1.3 1 (2) 0.33 HP 4.8 2 Total 2.6 Service Outlet 115V GFI (amps) 15 15 20 Indoor Blower HP 3 5 3 5 7.5 3 5 7.5 7.5 Motor Full Load Amps 16.7 7.6 9 10.6 24.2 4.8 11 3.9 6.1 <sup>2</sup> Maximum **Unit Only** 110 110 125 45 50 50 35 40 40 Overcurrent With (2) 0.33 HP 110 110 125 50 50 50 40 40 45 Protection (MOCP) Power Exhaust <sup>3</sup> Minimum 85 91 99 38 41 44 35 **Unit Only** 30 32 Circuit With (2) 0.33 HP 90 41 96 104 43 47 32 34 37 Ampacity (MCA)

#### **ELECTRIC HEAT DATA**

	Electric Hea	t Voltage	208V	240V	208V	240V	208V	240V	480V	480V	480	600V	600V	600V
<sup>2</sup> Maximum	Unit+	15 kW	4 125	150	150	150	150	150	70	70	70	50	50	60
Overcurrent	Electric Heat	30 kW	4 175	200	4 175	200	200	200	90	90	90	70	70	80
Protection (MOCP)		45 kW	225	225	4 2 2 5	250	4 2 2 5	250	110	110	125	90	90	90
		60 kW	4225	250	4 2 2 5	250	250	250	110	125	125	90	90	100
<sup>3</sup> Minimum	Unit+	15 kW	124	130	131	137	138	144	61	63	67	48	50	53
Circuit	Electric Heat	30 kW	164	176	170	182	177	189	83	86	89	66	69	71
Ampacity (MCA)	/ (MCA)		203	221	209	227	216	234	106	109	112	84	87	89
			210	230	217	236	224	243	110	113	116	88	90	93
<sup>2</sup> Maximum	Unit+	15 kW	150	150	150	150	150	150	70	70	70	50	60	60
Overcurrent	Electric Heat	30 kW	4 175	200	4 175	200	200	200	90	90	100	70	80	80
Protection (MOCP)	and (2) 0.33 HP Power Exhaust	45 kW	225	225	4 2 2 5	250	4 2 2 5	250	110	125	125	90	90	100
		60 kW	4225	250	4 2 2 5	250	250	250	125	125	125	90	100	100
<sup>3</sup> Minimum	Unit+	15 kW	129	135	135	141	143	149	63	66	69	50	52	55
Circuit	Electric Heat	30 kW	168	180	174	186	182	194	86	89	92	68	71	73
Ampacity (MCA)	and (2) 0.33 HP Power Exhaust	45 kW	207	225	213	232	221	239	108	111	115	86	89	91
		60 kW	215	234	221	241	229	248	113	116	119	90	92	95

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 5000 amps.

Power Exhaust

<sup>&</sup>lt;sup>1</sup> Extremes of operating range are plus and minus 10% of line voltage.

<sup>&</sup>lt;sup>2</sup> HACR type breaker or fuse.

<sup>&</sup>lt;sup>3</sup> Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.

<sup>&</sup>lt;sup>4</sup> Factory installed circuit breaker not available.

#### **ELECTRICAL/ELECTRIC HEAT DATA 20 TON** Model LHT240H5M <sup>1</sup> Voltage - 60Hz 208/230V - 3 Ph 460V - 3 Ph 575V - 3 Ph Compressor 1 Rated Load Amps 26.5 14 11.5 (Non-Inverter) Locked Rotor Amps 255 123 93.7 Compressor 2 Rated Load Amps 28.5 13.5 10.7 (Non-Inverter) Locked Rotor Amps 255 93.7 123 Outdoor Fan Full Load Amps (6 Non-ECM) 2.4 1.3 1 Motors (6) Total 14.4 7.8 6 2.4 Power Exhaust Full Load Amps 1.3 1 (2) 0.33 HP 2 Total 4.8 2.6 Service Outlet 115V GFI (amps) 15 15 20 10 Indoor Blower HP 5 7.5 5 7.5 10 7.5 10 5 Motor 16.7 24.2 7.6 14 Full Load Amps 30.8 11 6.1 9 11 <sup>2</sup> Maximum **Unit Only** 110 125 125 60 60 60 45 50 50 Overcurrent With (2) 0.33 HP 125 125 125 60 60 60 50 50 50 Protection (MOCP) Power Exhaust <sup>3</sup> Minimum **Unit Only** 94 101 108 47 50 53 38 41 43 Circuit With (2) 0.33 HP 99 106 113 50 53 56 40 43 45 Ampacity (MCA) Power Exhaust

#### **ELECTRIC HEAT DATA**

	Electric Hea	t Voltage	208V	240V	208V	240V	208V	240V	480V	480V	480V	600V	600V	600V
<sup>2</sup> Maximum	Unit+	15 kW	150	150	150	150	4 150	175	70	80	80	60	60	70
Overcurrent	Electric Heat	30 kW	4 175	200	200	200	200	200	100	100	100	80	80	80
Protection (MOCP)		45 kW	4 225	250	4 225	250	250	250	125	125	125	100	100	100
		60 kW	4 225	250	250	250	4 250	4 300	125	125	125	100	100	110
		90 kW	4 300	4 350	4 300	4 350	4 300	4 350	175	175	175	125	150	150
<sup>3</sup> Minimum	Unit+	15 kW	133	139	140	146	147	154	69	73	76	56	59	61
Circuit	Electric Heat	30 kW	172	184	179	191	187	199	92	95	98	74	77	79
Ampacity (MCA)	-	45 kW	211	229	218	237	226	244	115	118	121	92	95	97
	-	60 kW	219	238	226	246	233	253	119	122	125	95	98	100
	-	90 kW	281	310	289	318	296	325	155	159	162	124	127	129
<sup>2</sup> Maximum	Unit+	15 kW	150	150	4 150	175	175	175	80	80	80	60	70	70
Overcurrent	Electric Heat	30 kW	200	200	200	200	4200	225	100	100	110	80	80	90
Protection (MOCP)	and (2) 0.33 HP - Power Exhaust	45 kW	4 225	250	4 225	250	250	250	125	125	125	100	100	100
		60 kW	250	250	250	250	4 250	4 300	125	125	150	100	110	110
		90 kW	4 300	4 350	4 300	4 350	350	4 350	175	175	175	150	150	150
<sup>3</sup> Minimum	Unit+	15 kW	138	144	145	151	152	158	72	75	78	58	61	63
Circuit	Electric Heat	30 kW	177	189	184	196	191	203	95	98	101	76	79	81
Ampacity (MCA)	Ampacity (MCA) and (2) 0.33 HP  Power Exhaust		216	234	223	241	230	249	117	121	124	94	97	99
	2.1.2. <u></u> ,	60 kW	224	243	231	250	238	258	122	125	128	97	100	102
		90 kW	286	315	294	323	301	330	158	161	164	126	129	131

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 5000 amps.

<sup>&</sup>lt;sup>1</sup> Extremes of operating range are plus and minus 10% of line voltage.

<sup>&</sup>lt;sup>2</sup> HACR type breaker or fuse.

<sup>&</sup>lt;sup>3</sup> Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.

<sup>&</sup>lt;sup>4</sup> Factory installed circuit breaker not available.

#### **ELECTRICAL ACCESSORIES - DISCONNECTS**

#### 13 TON | LHT156H5

Motor HP	;	3		5	3	5	3	5
Electric Heat Voltage	208	240	208	240	480	480	600	600
Unit Only	54W86	54W86	54W86	54W86	54W85	54W85	54W85	54W85
+ Power Exhaust	54W86	54W86	54W86	54W86	54W85	54W85	54W85	54W85
+ Electric Heat 15 kW	54W86	54W86	54W86	54W86	54W85	54W85	54W85	54W85
+ Electric Heat 30 kW	54W87	54W87	54W87	54W87	54W85	54W86	54W85	54W85
+ Electric Heat 45 kW	54W87	54W87	54W87	54W87	54W86	54W86	54W85	54W86
+ Electric Heat 60 kW	¹ NA	54W87	¹ NA	¹ NA	54W86	54W86	54W86	54W86
+ Power Exhaust + Elec. Heat 15 kW	54W86	54W86	54W86	54W86	54W85	54W85	54W85	54W85
+ Power Exhaust + Elec. Heat 30 kW	54W87	54W87	54W87	54W87	54W86	54W86	54W85	54W85
+ Power Exhaust + Elec. Heat 45 kW	54W87	54W87	54W87	54W87	54W86	54W86	54W86	54W86
+ Power Exhaust + Elec. Heat 60 kW	¹ NA	¹ NA	¹ NA	¹ NA	54W86	54W86	54W86	54W86

#### 15 TON | LHT180H5

Motor HP	;	3		5	7.	.5	3	5	7.5	3	5	7.5
Electric Heat Voltage	208V	240V	208V	240V	208V	240V	480V	480V	480V	600V	600V	600V
Unit Only	54W86	54W86	54W86	54W86	54W86	54W86	54W85	54W85	54W85	54W85	54W85	54W85
+ Power Exhaust	54W86	54W86	54W86	54W86	54W86	54W86	54W85	54W85	54W85	54W85	54W85	54W85
+ Electric Heat 15 kW	54W86	54W86	54W86	54W86	54W87	54W86	54W85	54W85	54W85	54W85	54W85	54W85
+ Electric Heat 30 kW	54W87	54W87	54W87	54W87	54W87	54W87	54W86	54W86	54W86	54W85	54W85	54W85
+ Electric Heat 45 kW	54W87	54W87	54W87	54W87	54W87	54W87	54W86	54W86	54W86	54W86	54W86	54W86
+ Electric Heat 60 kW	¹ NA	54W86	54W86	54W86	54W86	54W86	54W86					
+ Power Exhaust + Elec. Heat 15 kW	54W86	54W86	54W87	54W86	54W87	54W87	54W85	54W85	54W85	54W85	54W85	54W85
+ Power Exhaust + Elec. Heat 30 kW	54W87	54W87	54W87	54W87	54W87	54W87	54W86	54W86	54W86	54W85	54W85	54W85
+ Power Exhaust + Elec. Heat 45 kW	54W87	54W87	54W87	54W87	NA	54W87	54W86	54W86	54W86	54W86	54W86	54W86
+ Power Exhaust + Elec. Heat 60 kW	¹ NA	54W86	54W86	54W86	54W86	54W86	54W86					

#### 20 TON | LHT240H5

Motor HP		5	7	.5	1	0	5	7.5	10	5	7.5	10
Electric Heat Voltage	208V	240V	208V	240V	208V	240V	480V	480V	480V	600V	600V	600V
Unit Only	54W86	54W86	54W86	54W86	54W86	54W86	54W85	54W85	54W85	54W85	54W85	54W85
+ Power Exhaust	54W86	54W86	54W86	54W86	54W86	54W86	54W85	54W85	54W85	54W85	54W85	54W85
+ Electric Heat 15 kW	54W86	54W86	54W87	54W86	54W87	54W87	54W85	54W85	54W85	54W85	54W85	54W85
+ Electric Heat 30 kW	54W87	54W87	54W87	54W87	54W87	54W87	54W86	54W86	54W86	54W85	54W85	54W85
+ Electric Heat 45 kW	54W87	54W87	NA	54W87	NA	54W87	54W86	54W86	54W86	54W86	54W86	54W86
+ Electric Heat 60 kW	¹ NA	54W86	54W86	54W86	54W86	54W86	54W86					
+ Electric Heat 90 kW	¹ NA	54W87	54W87	54W87	54W86	54W86	54W86					
+ Power Exhaust + Elec. Heat 15 kW	54W87	54W86	54W87	54W87	54W87	54W87	54W85	54W85	54W86	54W85	54W85	54W85
+ Power Exhaust + Elec. Heat 30 kW	54W87	54W87	54W87	54W87	54W87	54W87	54W86	54W86	54W86	54W85	54W85	54W86
+ Power Exhaust + Elec. Heat 45 kW	54W87	54W87	NA	54W87	NA	54W87	54W86	54W86	54W86	54W86	54W86	54W86
+ Power Exhaust + Elec. Heat 60 kW	¹ NA	54W86	54W86	54W86	54W86	54W86	54W86					
+ Power Exhaust + Elec. Heat 90 kW	¹ NA	54W87	54W87	54W87	54W86	54W86	54W86					

**Disconnects - 54W85 -** 80A **54W86 -** 150A **54W87 -** 250A

**<sup>54</sup>W87** - 250A <sup>1</sup> Disconnect must be field furnished.

ELE	CTRIC	HEAT	CAP	ACITI	ES										
Volts		15 kW			30 kW			45 kW			60 kW		90 kW		
Input	kW Input	Btuh Output	Stages												
208	11.3	38,600	1	22.5	76,800	1	33.8	115,300	1	45.0	153,600	1	67.6	230,700	1
220	12.6	43,000	1	25.2	86,000	1	37.8	129,000	1	50.4	172,000	1	75.6	258,000	1
230	13.8	47,100	1	27.5	93,900	1	41.3	141,000	1	55.1	188,000	1	82.7	282,200	1
240	15.0	51,200	1	30.0	102,400	1	45.0	153,600	1	60.0	204,800	1	90.0	307,100	1
440	12.6	43,000	1	25.2	86,000	1	37.8	129,000	1	50.4	172,000	1	75.6	258,000	1
460	13.8	47,100	1	27.5	93,900	1	41.3	141,000	1	55.1	188,000	1	82.7	282,200	1
480	15.0	51,200	1	30.0	102,400	1	45.0	153,600	1	60.0	204,800	1	90.0	307,100	1
550	12.6	43,000	1	25.2	86,000	1	37.8	129,000	1	50.4	172,000	1	75.6	258,000	1
575	13.8	47,100	1	27.5	93,900	1	41.3	141,000	1	55.1	188,000	1	82.7	282,200	1
600	15.0	51,200	1	30.0	102,400	1	45.0	153,600	1	60.0	204,800	1	90.0	307,100	1

- FIELD WIRING NOTES
   For use with copper wiring only
- Field wiring not furnished
- All wiring must conform to NEC or CEC and local electrical codes
- $\bullet$  For specific wiring information, please refer to the installation instructions

#### Minimum R454B Space and CFM Requirements

Minimum Airflow <sup>1</sup>											
Unit	Q <sub>min</sub> (CFM)	Q <sub>min</sub> (m³h)									
LHT156	556	944									
LHT180	609	1033									
LHT240	549	932									

<sup>1</sup> **NOTE -** The minimum airflow is the lowest CFM allowed during venting operation (leak mitigation).

Minimum Room Area of Conditioned Space <sup>2</sup>											
Unit	TA <sub>min</sub> (ft²)	TA <sub>min</sub> (m²)									
LHT56	308	28.6									
LHT180	337	31.3									
LHT240	304	28.2									

<sup>&</sup>lt;sup>2</sup> **NOTE** - The minimum room area of conditioned space is the smallest area the unit can service.

Refrigerant Charge R-454B										
Unit	M <sub>c</sub> (lbs)	M <sub>c</sub> (kg)								
LHT156 Stage 1	21	9.53								
LHT156 Stage 2	19	8.62								
LHT180 Stage 1	23	10.43								
LHT180 Stage 2	19.5	8.85								
LHT240 Stage 1	20.75	9.41								
LHT240 Stage 2	19.25	8.73								

	Altitude Adjustment Factor³												
Halt	0	200	400	600	800	1000	1200	1400	1600				
AF	1	1	1	1	1.02	1.05	1.04	1.1	1.12				
Halt	1600	1800	2000	2200	2400	2600	2800	3000	3200				
AF	1.12	1.15	1.18	1.21	1.25	1.28	1.32	1.36	1.4				

 $<sup>^{3}</sup>$  **NOTE -** Use the Altitude Adjustment Factor to adjust the values in the tables above to different altitudes. Find the relevant altitude above sea level in the two "Halt" rows and then multiply the value needed from the tables above by the altitude factor number. Example: For the minimum airflow in CFM for an LHT156 at 1000 ft. above see level, multiply 556 by 1.05 to get 583.8 CFM as the new  $Q_{min}$ .




FIGURE 1

#### I-UNIT COMPONENTS

All 13 through 20 ton units are configure to order units (CTO). Unit components are shown in figure 1. All units come standard with hinged unit panels. The unit panels may be held open with the door rod located inside the unit. All L1, L2 and L3 wiring is color coded; L1 is red, L2 is yellow and L3 is blue.

# **▲** CAUTION

As with any mechanical equipment, contact with sharp sheet metal edges can result in personal injury. Take care while handling this equipment and wear gloves and protective clothing.

# ELECTROSTATIC DISCHARGE (ESD) Precautions and Procedures

# **▲** CAUTION



Electrostatic discharge can affect electronic components. Take precautions to neutralize electrostatic charge by touching your hand and tools to metal prior to handling the control.

#### **A-Control Box Components**

Control box components are shown in FIGURE 3 and FIGURE 4. The control box is located in the upper portion of the compressor compartment.

#### 1-Disconnect Switch S48

Units with higher SCCR rating may be equipped with an disconnect switch S48. Other factory or field installed optional circuit breakers may be used, such as CB10. S48 and CB10 are toggle or twist-style switches, which can be used by the service technician to disconnect power to the unit.

#### 2-Control Transformer T1

All use a single line voltage to 24VAC transformer mounted in the control box. Transformer supplies power to control circuits in the unit. The transformer is rated at 70VA and is protected by a 3.5 amp circuit breaker (CB8). The 208/230 (Y) voltage transformers use two primary voltage taps as shown in FIGURE 2, while 460 (G) and 575 (J) voltage transformers use a single primary voltage tap.




FIGURE 2

#### **3-Contactor Transformer T18**

T18 is a single line voltage to 24VAC transformer used in all LHT 13 to 20 ton units. Transformer T18 is protected by a 3.5 amp circuit breaker (CB18). T18 is identical to transformer T1. The transformer supplies 24VAC power to the contactors.




FIGURE 3




FIGURE 4

#### 4-Terminal Block TB13

TB13 terminal block distributes line voltage power to the line voltage items in the unit.

#### 5-Outdoor Fan Motor Fuse Block & Fuses

F10 Power Exhaust Fan Motor Fuse Block and Fuses F6. STD SCCR 240V, 300V and higher rated SCCR units have three line voltage fuses F10 provide overcurrent protection to all condenser fans. Two line voltage fuses F6 provide overcurrent protection to the two optional power exhaust fans. The fuses are rated at 30A in all 208/230V units but 10A in the 208/230V 240U and 300U models.

#### 6-Compressor Contactor K1 and K2

All compressor contactors are three-pole-double-break contactors with 24VAC coils. In all units, K1 (energized by A55) energizes compressors B1 in response to first stage cool demand, and K2 (energized by A55) energizes B2 in response to second stage cool demand.

#### 7-Blower Contactor K3

Blower contactor K3, used in all units, is a three-pole-double-break contactor with a 24VAC coil used to energize the indoor blower motor B3 in response to blower demand. K3 is energized by Unit Controller (A55). Optional Staged-Blower units which are not equipped with a bypass option will not have a K3.

#### 8-Ultraviolet Germicidal Lamp (UVC) Transformer T49

UVC transformer T49 is used in 460V and 575V units which are equipped with a UVC. The auto voltage to 230VAC transformer is installed in the control box. The transformer has an output rating of 0.5 amps. T49 transformer supplies 230VAC power to the UVC lamp.

Upon restoration of gas and power, the control will restart the ignition sequence and continue until flame is established or system locks out. For a more detailed description see the Gas Heat Components section.

#### 9-Power Exhaust Relay K65 & K231 (PED units)

Power exhaust relays K65 and K231 are N.O. DPDT relays with a 24VAC coil. The relay are used in units equipped with the optional power exhaust dampers. K65 and K231 are energized by the A55 Unit Controller, after the economizer dampers reach 50% open (adjustable in ECTO). When K65 closes, exhaust fan B10 is energized and when K231 closes B11 is energized.

#### 10-Variable Frequency Drive A96 (optional)

Staged-Blower units are equipped with a VFD which alters the supply power frequency and voltage to the blower motor. Blower speed is staged depending on the compressor stages, heating demand, ventilation demand, or smoke alarm. The amount of airflow for each stage is preset from the factory. Airflow can be adjusted by changing ECTO parameters in the A55 Unit Controller. The VFD is located below the Unit Controller.

#### 11-VFD Power To Motor Contactor K202 (optional)

Contactor is used in Staged-Blower units equipped with a VFD bypass option. The three pole 40 amp contactor with a 24VAC coil is energized by the A55 Unit Controller. K202 allows power from the VFD to the B3 blower motor in response to blower demand.

# 12-Inverter Start Forward Rotation Relay K203 (optional)

Relay is used in optional Staged-Blower units and is a three-pole double-throw relay with a 24VAC coil. K203 is energized by the A55 Unit Controller and provides input to the A96 VFD to start blower forward rotation. K203 also de-energizes K3 allowing A96 to control B3 blower.

#### 13-Unit Controller A55

The Unit Controller provides all unit control functions, unit status information, unit diagnostics, programmable parameters and USB verification and profile sharing. Refer to the Unit Controller guide provided with the unit. Thermostat wires are connected to J297 on the Unit Controller.

#### **Relative Humidity Sensor - Optional**

The indoor relative humidity sensor (A91) is an analog sensor with a 0-10VDC output over a relative humidity range of 0-100% relative humidity. The sensor is powered with 24VAC.

#### **Enthalpy Sensor - Optional**

The optional enthalpy sensors (A7 and A63) used with the economizer have an output of 4-20mA. The sensor is powered with 18VAC provided by M3 unit control.

#### **Economizer Differential Pressure Sensor - Optional**

Rooftop units installed with Smart Airflow™ will have a Pressure Transducer (PT5) present in the economizer. PT5 requires 5VDC power supply (P266-5 and {P266-6) and gives 0.25 VDC to 4 VDC output (P266-4) corresponding to 0" water column and 2" water column respectively. For all practical purposes the output should be less than 1.2" water column if not an error code is stored and service alarm output is turned on.

#### **Temperature Sensors**

The return air (RT16) and discharge air (RT6) duct probes and the outdoor air (RT17) are all two wire thermistors. The resistance vs. temperature table is shown below:

TABLE 1
Resistance vs. Temperature

Temp. °F (°C)	Resistance +/-2%	Temperature °F (°C)	Resistance +/-2%	Temp. °F (°C)	Resistance +/-2%
-40 (-40)	335,671	40 (4.4)	26,106	90 (32.2)	7,332
-20 (-28.9)	164,959	50 (10)	19,904	100 (37.8)	5,826
0 (-17.8)	85,323	60 (15.6)	15,313	120 (48.9)	3,756
20 (-6.7)	46,218	70 (21.1)	11,884	130 (54.4)	3,047
30 (-1.1)	34,566	80 (26.7)	9,298		

#### **Room Sensors**

Room sensor (A2) is a two-wire thermistor with 1k series resistor.

TABLE 2
Two-Wire Thermistor

Temp. °F (°C)	Resistance +/-2%	Temperature °F (°C)	Resistance +/-2%	Temp. °F (°C)	Resistance +/-2%
40 (4.4)	27,102	60 (15.6)	16,313	80 (26.7)	10,299
45 (7.2)	23,764	65 (18.3)	14,474	85 (29.4)	9,249
50 (10)	20,898	70 (21.1)	12,882	90 (32.2)	8,529
55 (12.8)	18,433	75 (23.9)	11,498		

#### **Carbon Dioxide Sensor**

The indoor carbon dioxide sensor (A63) is an analog sensor with a 0-10VDC output over a carbon dioxide range of 0-2000 ppm as shown in the following table. The sensor is powered with 24VAC.

TABLE 3
Carbon Dioxide Range

Carbon Dioxide PPM	DC Voltage						
0	0	600	3	1200	6	1800	9
200	1	800	4	1400	7	2000	10
400	2	1000	5	1600	8		

# 15-Second-Stage Power Exhaust Relay K231 (Staged-Blower units equipped with power exhaust)

The second power exhaust fan is controlled by K231. A133 will enable K231 only when the blower reaches 70% of full speed (adjustable ECTO). This prevents a negative building pressure when the blower is operating in low speed. Refer to the Unit Controller manual and ECTO labels on the unit.

#### 15-Fuse F61 (Higher SCCR units only)

Fuse F61 is used on units with higher SCCR rating. F61 provides overcurrent protection to compressor and other cooling components. F61 and S48 are located inside a sheet metal enclosure in the unit left front corner mullion.

#### 16-Blower Motor Overload Relay S42

The relay (S42) is connected in line with the blower motor to monitor the current flow to the motor. When the relay senses an overload condition, a set of normally closed contacts open to de-energize pin #1 in plug P299 of the A55 Unit Controller. A55 de-energizes all outputs. Units will be equipped with a relay manufactured by Telemecanique FIGURE 5 or Siemens FIGURE 6.




FIGURE 5




FIGURE 6

should pop out. Press the blue reset screw to reset the relay.




FIGURE 7




FIGURE 8

#### **B-Cooling Components**

Units use independent cooling circuits consisting of one compressor, one condenser coil, and one evaporator coil per circuit.

Six draw-through type condenser fans are used in LHT156, 180 & 240.

Cooling may be supplemented by a factory- or field-installed economizer. All units intertwined evaporators. Each evaporator uses a thermostatic expansion valve as the primary expansion device. Each evaporator is also equipped with enhanced fins and rifled tubing. In all units each compressor is protected by a crankcase heater, high pressure switch and low pressure switch.

#### 1-Compressors B1 and B2

All units use scroll compressors. All units use 2 compressors, the first stage compressor is a 2-speed and the second stage compressor is fixed speed. Compressor capacity may vary from stage to stage. In all cases, the capacity of each compressor is added to reach the total capacity of the unit. See "SPECIFICATIONS" and "ELECTRICAL DATA" (table of contents) or compressor nameplate for compressor specifications.

# **WARNING**

Electrical shock hazard. Compressor must be grounded. Do not operate without protective cover over terminals. Disconnect power before removing protective cover. Discharge capacitors before servicing unit. Failure to follow these precautions could cause electrical shock resulting in injury or death.

Each compressor is energized by a corresponding compressor contactor.

**NOTE-**Refer to the wiring diagram section for specific unit operation.

If a compressor replacement is necessary, call 1-800-453-6669.

# **A** IMPORTANT

Some scroll compressors have an internal vacuum protector that will unload scrolls when suction pressure goes below 20 psig. A hissing sound will be heard when the compressor is running unloaded. Protector will reset when low pressure in system rises above 40 psig. DO NOT REPLACE COMPRESSOR.

#### 2-Crankcase Heaters HR1 and HR2

All LHT units use insertion type heaters. Heater HR1 is installed around compressor B1 and HR2 compressor B2.

#### 3-High Pressure Switches S4 and S7

The high pressure switches is an auto-reset SPST N.C. switch which opens on a pressure rise. All units are equipped with this switch. The switch is located in the compressor discharge line and is wired in series with the compressor contactor coil through A55 unit controller or A178 compressor 3 and 4 controller.

S4 and S7 are is wired in series with B1 and B2 compressor contactors.

When discharge pressure rises to  $640 \pm 10$  psig (indicating a problem in the system) the switch opens and the respective compressor(s) is de-energized (the economizer can continue to operate). When discharge pressure drops to  $475 \pm 20$  psig the pressure switch will close re-energizing the compressor(s).

Main control A55 has a three-strike counter before locking out. This means the control allows three high pressure trips per one thermostat demand. The control can be reset by breaking and remaking the thermostat demand or manually resetting the control

#### 4-Low Pressure Switches S87 and S88

The low pressure switch is an auto-reset SPST N.O. switch (held N.C. by refrigerant pressure) which opens on a pressure drop. All units are equipped with this switch. The switch is located in the compressor suction line. See FIGURE 7.

S87 and S88 (compressor one and two) are wired in series with the contactor coils through the A55 Unit Controller

The Unit Controller A55 governs the low pressure switches by shunting the switches during start up until pressure is stabilized. After the shunt period, the control has a three-strike counter, during a single thermostat demand, before the compressor(s) is locked out. The control is reset by breaking and remaking the thermostat demand or manually resetting the control.

When suction pressure drops to  $25 \pm 5$  psig (indicating low pressure), the switch opens and the compressor(s) is de-energized. The switch automatically resets when pressure in the suction line rises to 40 + 5 psig.

#### **5-Defrost Control**

The defrost control ensures that the heat pump outdoor coil does not ice excessively during the heating mode. The defrost control uses input from the coil and ambient sensor to initiate demand defrost cycles from the M4 Board. If the system fails to calibrate or obtain readings for demand defrost, defrost will run-time at field setting. Low gas heat (LDT) or electric heat (LHT) is energized during defrost.

#### 6-Filter Drier (all units)

Units have a filter drier located in the liquid line of each refrigerant circuit at the exit of each condenser coil. The drier removes contaminants and moisture from the system.

#### 7-Condenser Fans

#### B4, B5, B21, B22, B23 and B24 (All Units)

See SPECIFICATIONS tables at the front of this manual for specifications of condenser fans used in all units. All condenser fans used have single-phase motors. The fan assembly may be removed for servicing and cleaning.

#### 8-Reversing Valve

A refrigerant reversing valve with a 24 volt solenoid coil is used to reverse refrigerant flow during unit operation in all LHT units. The reversing valve is connected in the vapor line of the refrigerant circuit. The reversing valve coil is energized during cooling demand and during defrost. Reversing valve L1 & L2 are controlled by the A55 Control board in response to a cooling demand or by defrost.

#### 9-Temperature Thermistor

Units are equipped with four factory-installed thermistors (RT46 - RT49) located on different points on the refrigerant circuit.

The thermistors provide the Unit Controller with constant temperature readings of four specific locations on the refrigeration circuit. These temperatures are used as feedback in certain modes of unit operation. In addition, the Unit Controller uses these temperatures to initiate alarms such as loss of outdoor or indoor coil airflow and loss of charge.

Each thermistor must be specifically placed for proper unit operation and to initiate valid alarms. See FIGURE 9 for indoor coil location and FIGURE 10 for outdoor coil location.




FIGURE 9




FIGURE 10

#### 10-RDS Sensors

Units are equipped with factory-installed RDS Sensors located on different points on the unit. The RDS sensors provide the Unit Controller with continuous readings for leaked refrigerant concentration levels and sensor health status (Good or Fault). These readings are used to modify unit operation to disperse the leaked refrigerant and to remove possible ignition sources. In addition, the Unit Controller uses these readings to initiate alarms to alert the operator of a refrigerant leak or faulty sensor(s).

Each sensor must be specifically placed for proper unit operation and to initiate valid alarms. To identify sensor locations see TABLE 4.

# TABLE 4 RDS Sensor Figures

Model	Qty.	Туре	Figure	
LHT/LDT156-240		INDOOR SENSOR	FIGURE 11	
	2 sensors	COMPRESSOR SENSOR	FIGURE 12	

**TABLE 5 - RDS Alarms** 

Alarm	Alarm description	RDS Sensor Location
257	Refrigerant leak sensor fault in the Indoor section (sensor #1)	Indoor compartment
258	Refrigerant leak sensor fault in the control panel/compressor section (sensor #2)	"Control/Compressor or Compressor compartment"




FIGURE 11





FIGURE 12

#### **RDS SENSOR WIRING DIAGRAM**



#### **KEY LIST** COMPONENT DESCRIPTION A55 CONTROL BOARD, MAIN RT58 SENSOR 1, REFR. LEAK DETECTION RT59 SENSOR 2, REFR. LEAK DETECTION



#### **NOTES**

REFRIGERANT LEAK SENSOR 2 (RT59), MAY NOT BE PRESENT IN ALL UNITS.

WARNING WARNING
DISCONNECT ALL POWER
BEFORE SERVICING.
ELECTRIC SHOCK HAZARD,
CAN CAUSE INJURY OR
DEATH. UNIT MUST BE
GROUNDED IN
ACCORDANCE WITH
NATIONAL AND LOCAL
CODES. CODES.
FOR USE WITH COPPER
CONDUCTORS ONLY, REFER
TO UNIT RATING PLATE FOR
MINIMUM CIRCUIT AMPACITY
AND MAXIMUM
OVERCURRENT
PROTECTION SIZE. FROTECTION SIZE.

IF ANY WIRE IN THIS

APPLIANCE IS REPLACED, IT

MUST BE REPLACED WITH

WIRE OF LIKE SIZE, RATING


AND INSULATION

THICKNESS.

MODEL: Units w/CORE Contr.

Refr. Leak Detection

VOLT:





REV	EC NO.	DATE	BY	APVD	REVISION NOTE
	CN-012295C	04-03-2024	MXR6	MXT5	ORIGINATED AT PD&R CARROLLTON, TX

FIGURE 13

#### **C-Blower Compartment**

The blower compartment is located between the evaporator coil and the compressor / control section on the opposite side of the condenser coil. The blower assembly is accessed by disconnecting the blower motor wiring (and all other plugs) and removing the screws on either side of the sliding base. The base pulls out as shown in FIGURE 15.

#### 1-Blower Wheels

All units have two 15 in. x 15 in. blower wheels. Both wheels are driven by one motor.

#### 2-Indoor Blower Motor B3

All units use three-phase single-speed blower motors. CFM adjustments are made by adjusting the motor pulley (sheave). Motors are equipped with sealed ball bearings. All motor specifications are listed in the SPECIFICATIONS (table of contents) in the front of this manual. Units may be equipped with motors manufactured by various manufacturers, therefore electrical FLA and LRA specifications will vary. See unit rating plate for information specific to your unit.

#### **OPERATION / ADJUSTMENT**

Supply Air Staged Units - The blower rotation will always be correct on units equipped with an inverter. Checking blower rotation is not a valid method of determining voltage phasing for incoming power. Supply Air Staged Units and Units Equipped With Optional Voltage or Phase Detection - The Unit Controller checks the incoming power during start-up. If the voltage or phase is incorrect, the Unit Controller will display an alarm and the unit will not start.

#### **A-Blower Operation**

Refer to the Unit Controller Setup Guide to energize blower. Use this mobile service app (the QR is located in the control area) menu:

#### SERVICE > TEST > BLOWER

Instructions provided with the thermostat may also be used to initiate blower only (G) demand. Unit will cycle on thermostat demand. The following steps apply to applications using a typical electro-mechanical thermostat.

- 1 Blower operation is manually set at the thermostat subbase fan switch. With fan switch in **ON** position, blowers will operate continuously.
- 2 With fan switch in AUTO position, the blowers will cycle with demand. Blowers and entire unit will be off when system switch is in OFF position.

# **▲** IMPORTANT

Three Phase Scroll Compressor Voltage Phasing

Three phase scroll compressors must be phased sequentially to ensure correct compressor and blower\* rotation and operation. Compressor and blower are wired in phase at the factory. Power wires are color-coded as follows: line 1-red, line 2-yellow, line 3-blue.

- 1-Observe suction and discharge pressures and blower\* rotation on unit start-up.
- 2-Suction pressure must drop, discharge pressure must rise and blower\* rotation must match rotation marking. If pressure differential is not observed or blower\* rotation is not correct:
- 3-Disconnect all remote electrical power supplies.
- 4-Reverse any two field-installed wires connected to the line side of S48 disconnect or TB13 terminal strip. Do not reverse wires at blower contactor.
- 5-Make sure the connections are tight. Discharge and suction pressures should operate at their normal start-up ranges.

\*Supply air inverter blower motors should rotate in the correct direction; verify scroll compressor rotation separately. Contact technical support if the blower is rotating incorrectly.

# **A** WARNING

- 1-Make sure that unit is installed in accordance with the installation instructions and applicable codes.
- 2-Inspect all electrical wiring, both field- and factory installed, for loose connections. Tighten as required.
- 3-Check to ensure that refrigerant lines do not rub against the cabinet or against other refrigerant lines.
- 4-Check voltage at disconnect switch. Voltage must be within range listed on nameplate. If not, consult power company and have voltage condition corrected before starting unit.
- 5-Make sure filters are new and in place before startup.

#### **B-Blower Access**

- 1 Disconnect jack/plug connector to blower motor. Also disconnect jack/plug connector heating limit switches on gas units.
- 2 Remove screws on either side of blower assembly sliding base. See FIGURE 15.
- 3 Pull base toward outside of unit.

#### **C-Determining Unit CFM**

IMPORTANT - Multi-staged supply air units are factory-set to run the blower at full speed when there is a blower (G) demand without a heating or cooling demand. Refer to the field-provided, design specified CFM for all modes of operation. Use the following procedure to adjust motor pulley to deliver the highest CFM called for in the design spec. See Inverter Start-Up section to set blower CFM for all modes once the motor pulley is set.

1 - The following measurements must be made with a dry indoor coil. Run blower (G demand) without a cooling demand. Measure the indoor blower shaft RPM. Air filters must be in place when measurements are taken. 2 - With all access panels in place, measure static pressure external to unit (from supply to return). Blower performance data is based on static pressure readings taken in locations shown in FIGURE 14.

**Note -** Static pressure readings can vary if not taken where shown.

- 3 See table of contents for Blower Data and or Optional Accessories. Use static pressure and RPM readings to determine unit CFM.
- 4 The blower RPM can be adjusted at the motor pulley. Loosen Allen screw and turn adjustable pulley clockwise to increase CFM. Turn counterclockwise to decrease CFM. See FIGURE 15. Do not exceed minimum and maximum number of pulley turns as shown in TABLE 6.

TABLE 6
MINIMUM AND MAXIMUM PULLEY ADJUSTMENT

Belt	Min Turns Open	Max Turns Open		
A Section	No Minimum	5		
B Section	1*	6		

<sup>\*</sup>No minimum number of turns open when B belt is used on pulleys 6" O.D. or larger.




FIGURE 14




FIGURE 15

#### **D-Blower Belt Adjustment**

Maximum life and wear can be obtained from belts only if proper pulley alignment and belt tension are maintained. Tension new belts after a 24-48 hour period of operation. This will allow belt to stretch and seat into pulley grooves. Make sure blower and motor pulley are aligned. See FIGURE 16 for blowers not equipped with a tensioner and FIGURE 17 for units equipped with an optional belt tensioner.

#### **Blowers Without Belt Tensioner**

- 1 Loosen four screws securing blower motor to sliding base. See FIGURE 15.
- 2 To increase belt tension -

Turn belt tension adjusting screw to the left, or counterclockwise, to tighten the belt. This increases the distance between the blower motor and the blower housing.

3 - To loosen belt tension -

Turn the adjusting screw to the right, or clockwise to loosen belt tension. 3- Tighten four screws securing blower motor to sliding base once adjustments have been made.




FIGURE 16




FIGURE 17

#### **E-Check Belt Tension**


Over tensioning belts shortens belt and bearing life. Check belt tension as follows:

- 1 Measure span length X. See FIGURE 18.
- 2 Apply perpendicular force to center of span (X) with enough pressure to deflect belt 1/64" for every inch of span length.

Example: Deflection distance of a 40" span would be 40/64" or 5/8".

3 - Measure belt deflection force. For a used belt, the deflection force should be 5 lbs. A new belt deflection force should be 7 lbs

A force below these values indicates and under tensioned belt. A force above these values indicates an over tensioned belt.



F-Field-Furnished Blower Drives

See BLOWER DATA tables for blower drives.

#### **D-OPTIONAL ELECTRIC HEAT**

See ELECTRICAL / ELECTRIC HEAT DATA and ELECTRIC HEAT CAPACITIES (table of contents) for LHT to EHA match-ups and electrical ratings.

EHA parts arrangement is shown in FIGURE 20 and FIGURE 21. All electric heat sections consist of electric heating elements exposed directly to the air stream. Two electric heat sections (first section and second section) are used in all 15kW through 90kW heaters. See FIGURE 19. Multiple-stage elements are sequenced on and off in response to thermostat demand.




FIGURE 19

#### 1-Main Control Box Components A55, K9

The main control box (FIGURE 3) houses the A55 Unit Controller and the K9 electric heat relay.

#### 2-Contactors K15, K16, K17 and K18

Contactors K15, K16, K17 and K18 are all three-pole double-break contactors located on the electric heat vestibule. K15 and K16 are located on the first electric heat section, while K17 and K18 are located on the second electric heat section. However, in the 15 and 30kW heaters, the first section houses all contactors and fuses. All contactors are equipped with a 24VAC coil. The coils in the K15, K16, K17 and K18 contactors are energized by the main panel A55. Contactors K15 and K17 energize the first stage heating elements, while K16 and K18 energize the second stage heating elements.

#### 3-High Temperature Limits S15 and S107 (Primary)

S15 and S107 are SPST N.C. auto-reset thermostats located on the back panel of the electric heat section below the heating elements. S15 is the high temperature limit for the first electric heat section, while S107 is the high temperature limit for the second electric heat section. Both thermostats are identical and are wired to the A55 Unit Controller. When either S15 or S107 opens, indicating a problem in the system, contactor K15 is de-energized. When K15 is de-energized, first stage and all subsequent stages of heat are de-energized. The thermostats used on EHA360-45-1 Y/G/J are factory set to open at 200F ± 5F on a temperature rise and automatically reset at 160F + 6F on a temperature fall. All other electric heat section thermostats are factory set to open at 170F ± 5F on a temperature rise and automatically reset at 130F+ 6F on a temperature fall. The thermostats are not adjustable.

#### 4-Terminal Strip TB3

Electric heat line voltage connections are made to terminal strip TB3 (or a fuse block on some models) located in the upper left corner of the electric heat vestibule.

#### 5-Heating Elements HE1 through HE14

Heating elements are composed of helix wound bare nichrome wire exposed directly to the air stream. Three elements are connected in a three-phase arrangement. The elements in 208/230V units are connected in a "Delta" arrangement. Elements in 460 and 575V units are connected in "Wye" arrangement.

Each stage is energized independently by the corresponding contactors located on the electric heat vestibule panel. Once energized, heat transfer is instantaneous. High temperature protection is provided by primary and redundant high temperature limits and overcurrent protection is provided by fuses.

#### 6-Fuse F3

Fuse F3 are housed in a fuse block which holds three fuses. Each F3 fuse is connected in series with each leg of electric heat. FIGURE 20, FIGURE 21 and TABLE 7 show the fuses used with each electric heat section. For simplicity, the service manual labels the fuses F3 - 1 through F3 - 8




FIGURE 20




FIGURE 21

**TABLE 7** 

ELECTRIC HEAT SECTION FUSE RATING										
EHA QUANTITY	VOLTAGES	FUSE (3 each)								
& SIZE	VOLTAGES	F3 - 1	F3 - 2	F3 - 3	F3 - 4	F3 - 5	F3 - 6	F3 - 7	F3 - 8	
	208/230V	50 Amp 250V								
(1) EHA240-7.5 & (1) EHA240S-7.5 (15 kW Total)	460V	25 Amp 600V								
(12 1111 12 1111)	575V	20 Amp 600V								
(1) EHA360-15 & (1) EHA360S-15	208/230V	60 Amp 250V	60 Amp 250V							
(30 kW Total)	460V	50 Amp 600V								
(1) EHA156-15 & (1) EHA156S-15	575V	40 Amp 600V								
(2) EHA360-22.5	208/230V	50 Amp 250V			25 Amp 250V	50 Amp 250V			25 Amp 250V	
` (45 kW Total) or	460V	25 Amp 600V			15 Amp 600V	25 Amp 600V			15 Amp 600V	
(2) EHA156-22.5	575V	20 Amp 600V			10 Amp 600V	20 Amp 600V			10 Amp 600V	
(2) EHA150-30	208/230V	50 Amp 250V			50 Amp 250V	50 Amp 250V			50 Amp 250V	
(60 kW Total) or	460V	25 Amp 600V			25 Amp 600V	25 Amp 600V			25 Amp 600V	
(2) EHA156-30	575V	20 Amp 600V			20 Amp 600V	20 Amp 600V			20 Amp 600V	
	208/230V	50 Amp 250V		60 Amp 250V	60 Amp 250V	50 Amp 250V		60 Amp 250V	60 Amp 250V	
(2) EHA360-45 (90 kW Total)	460V	25 Amp 600V			50 Amp 600V	25 Amp 600V			50 Amp 600V	
	575V	20 Amp 600V			40 Amp 600V	20 Amp 600V			40 Amp 600V	

#### **II-PLACEMENT AND INSTALLATION**

Make sure the unit is installed in accordance with the installation instructions and all applicable codes. See accessories section for conditions requiring use of the optional roof mounting frame.

#### **III-CHARGING**

A-Unit Charging - Tube & Fin Coil

# **▲ IMPORTANT**

Units equipped with a Hot Gas Reheat system MUST be charged in standard cooling mode.

**WARNING-**Do not exceed nameplate charge under any condition.

This unit is factory charged and should require no further adjustment. If the system requires additional refrigerant, reclaim the charge, evacuate the system, and add required nameplate charge.

When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice be followed and, since flammability is a consideration, the following procedure shall be adhered to:

- Safely remove refrigerant following local and national regulations,
- · Evacuate the circuit,
- Purge the circuit with inert gas,
- Evacuate,
- Purge with inert gas,
- Open the circuit

The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems. Refrigerant purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system. When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and that ventilation is available.

In addition to conventional charging procedures, the following requirements shall be followed.

- Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
- Cylinders shall be kept in an appropriate position according to the instructions.
- Ensure that the refrigerating unit is earthed prior to charging the system with refrigerant.
  - Label the system when charging is complete (if not already).
  - Extreme care shall be taken not to overfill the refrigerating unit.

Prior to recharging the system, it shall be pressure-tested with the appropriate purging gas. The system shall be leak-tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely. When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i. e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure- relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants includ-ing, when applicable, flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manu-facturer if in doubt.
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.

The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

Prior to recharging the system, it shall be pressuretested with the appropriate purging gas. The system shall be leak-tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

**NOTE -** System charging is not recommended below 60F (15C). In temperatures below 60F (15C), the charge must be weighed into the system.

# IMPORTANT - Charge unit in normal cooling mode.

If weighing facilities are not available, or to check the charge, use the following procedure:

- 1 Make sure outdoor coil is clean. Attach gauge manifolds and operate unit at full CFM in cooling mode with economizer disabled until system stabilizes (approximately five
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.
- 2 Add or remove charge in increments. Allow the system to stabilize each time refrigerant is added or removed.
- 3 Continue the process until measured liquid temperature agrees with the target liquid temperature. Do not go below the target liquid temperature when adjusting charge. Note that suction pressure can change as charge is adjusted.
- 1 Example: At 95°F outdoor ambient and a measured suction pressure of 130psig, the target liquid temperature is 97°F. For a measured liquid temperature of 106°F, add charge in increments until measured liquidtemperature agrees with the target liquid temperature minutes). Make sure all outdoor air dampers are closed.
- 2 Compare the normal operating pressures to the pressures obtained from the gauges. Check unit components if there are significant differences.
- 3 Measure the outdoor ambient temperature and the suction pressure. Refer to the charging curve to determine a target liquid temperature.

**Note -** Pressures are listed for sea level applications.

- 4 Use the same thermometer to accurately measure the liquid temperature (in the outdoor section). If measured liquid temperature is higher than the target liquid temperature, add refrigerant to the system.
- If measured liquid temperature is lower than the target liquid temperature, recover some refrigerant from the system.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i. e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt. The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.
- 5 Add or remove charge in increments. Allow the system to stabilize each time refrigerant is added or removed.

Continue the process until measured liquid temperature agrees with the target liquid temperature. Do not go below the target liquid temperature when adjusting charge. Note that suction pressure can change as charge is adjusted.

TABLE 8 LDT/LHT156 NORMAL OPERATING PRESSURES -581167-02

331137 32											
Outdoor Coil En- tering Air	Circ	uit 1	Circuit 2								
Temp⁰F	Dis. <u>+</u> 10 psig	Suc. <u>+</u> 5 psig	Dis. <u>+</u> 10 psig	Suc. <u>+</u> 5 psig							
65	223	123	226	125							
75	259	128	261	131							
85	298	132	301	134							
95	342	135	345	136							
105	389	137	392	138							
115	443	139	445	140							

TABLE 9 LDT/LHT180 NORMAL OPERATING PRESSURES -581168-02

Outdoor Coil En- tering Air	Circ	uit 1	Circuit 2		
Temp⁰F	Dis. +10 psig	Suc. +5 psig	Dis. +10 psig	Suc. +5 psig	
65	235	128	234	120	
75	273	133	272	127	
85	313	135	311	132	
95	356	136	354	133	
105	406	138	402	136	
115	461	140	456	138	

TABLE 10 LDT/LHT240 NORMAL OPERATING PRESSURES -581169-02

Outdoor Coil En- tering Air	Circ	uit 1	Circuit 2		
Temp⁰F	Dis. +10 psig	Suc. +5 psig	Dis. +10 psig	Suc. +5 psig	
65	249	129	258	123	
75	283	130	294	125	
85	323	131	334	126	
95	369	131	377	127	
105	418	133	428	130	
115	471	137	483	132	

# **B-Charge Verification - Approach Method - AHRI**

# **Testing (Fin/Tube Coil)**

- 1 1- Using the same thermometer, compare liquid temperature to outdoor ambient temperature.
- Approach Temperature = Liquid temperature (at outdoor coil outlet) minus ambient temperature.
- 2 Approach temperature should match values in TABLE 11. An approach temperature greater than value shown indicates an undercharge. An approach temperature less than value shown indicates an overcharge.
- 3 The approach method is not valid for grossly over or undercharged systems. Use TABLE 8, TABLE
   9 and TABLE 11 as a guide for typical operating pressures.

TABLE 11
APPROACH TEMPERATURES - FIN/TUBE COIL

Unit	Liquid Temp. Minus Ambient Temp.					
Unit	1st Stage	2nd Stage				
156	2.3°F +/- 1° (1.3°C +/- 0.5)	3.4°F +/- 1° (1.9°C +/- 0.5)				
180	2°F +/- 1° (1.1°C +/- 0.5)	3.5°F +/- 1° (1.9°C +/- 0.5)				
240	5°F +/- 1° (2.8°C +/- 0.5)	7°F +/- 1° (3.9°C +/- 0.5)				

#### **IV- START-UP OPERATION**

# **A-Preliminary and Seasonal Checks**

- 1 Make sure the unit is installed in accordance with the installation instructions and applicable codes.
- 2 Inspect all electrical wiring, both field and factory installed for loose connections. Tighten as required. Refer to unit diagram located on inside of unit control box cover.
- 3 Check to ensure that refrigerant lines are in good condition and do not rub against the cabinet or other refrigerant lines.
- 4 Check voltage. Voltage must be within the range listed on the nameplate. If not, consult power company and have the voltage corrected before starting the unit.
- 5 Recheck voltage and amp draw with unit running. If voltage is not within range listed on unit nameplate, stop unit and consult power company. Refer to unit nameplate for maximum rated load amps.
- 6 Inspect and adjust blower belt (see section on Blower Compartment Blower Belt Adjustment).

# **B-Cooling Start-up**

**NOTE-**Crankcase heaters must be energized 24 hours before attempting to start compressor. Set thermostat so that there is no demand to prevent compressor from cycling. Apply power to unit.

- 1 Initiate first and second stage cooling demands according to instructions provided with thermostat.
- 2 First-stage thermostat demand will energize indoor blower in Low Cooling CFM. Second-stage thermostat demand will energize indoor blower in High Cooling CFM. Both demands energize compressor 1. The remaining compressors will be energized as needed to meet cooling demand.
- 3 156, 180 and 240 units contain two refrigerant circuits or systems.
- 4 Each refrigerant circuit is separately charged with R454B refrigerant. See unit rating plate for correct amount of charge.
- 5 Refer to the Refrigerant Check and Charge section to check refrigerant charge.

#### C-Heating Startup

- 1 Set thermostat or temperature control device to initiate a first-stage heating demand.
- 2 A first-stage heating demand (W1) will energize compressor heat pump heating, the outdoor fans, and the blower.
- A second-stage heating demand (W2) will energize the electrical heaters if available.

#### V- SYSTEMS SERVICE CHECKS

# A-Cooling System Service Checks

LHT units are factory charged and require no further adjustment; however, charge should be checked periodically using the liquid temperature plots in section IIICHARG-ING.

#### VI-MAINTENANCE

The unit should be inspected once a year by a qualified service technician.





Electric shock hazard. Can cause injury or death. Before attempting to perform any service or maintenance, turn the electrical power to unit OFF at disconnect switch(es). Unit may have multiple power supplies.

# **▲** IMPORTANT

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

# WARNING

Any service personnel installing, decommissioning, or performing maintenance on the unit must be properly trained with A2L refrigerants

Prior to beginning work on systems containing refigerant to ensure the risk of ignition is minimized:

- All work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapor being present while the work is being performed.
- The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i. e. non-sparking, adequately sealed or intrinsically safe.
- If any hot work is to be conducted on the refrigerating equipment or any associated parts, the appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO2 fire extinguisher adjacent to the charging area.
- No person carrying out work in relation to a refrigerating system which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be

surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.

 Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work.

A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

- Where electrical components are being changed, service technicians shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance. The following checks shall be applied to installations using flameable refrigerants as applicable:
- 1 The actual refrigerant charge is in accordance with the room size within which the refrigerant containing parts are installed.
- 2 The ventilation machinery and outlets are operating adequately and are not obstructed.
- 3 If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant.
- 4 Markings on the equipment should be visible and legible. Markings and signs that are illegible shall be corrected.
- 5 Refrigerating pipes or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.
- For systems containing refigerant all repair and maintenance to electrical components shall include initial safety checks and component inspection procedures such as that capacitors are discharged in a safe manner to avoid possibility of sparking, that no live electrical components and wiring are exposed while charging, recovering, or purging the system, and that there is continuity of earth bonding. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used that is reported to the owner of the equipment, so all parties are advised.

**NOTE** - Sealed electrical components shall be replaced, not repaired.

**NOTE** - Intrinsically safe components must be replaced, not repaired. Under no circumstances shall


potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used. Electronic leak detectors may be used to detect refrigerant leaks but, in the case of flammable refrigerants, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed. Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work. If a leak is suspected, all naked flames shall be removed/extinguished. If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.

- When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice be followed, since flammability is a consideration. The following procedure shall be adhered to:
  - a. Safely remove refrigerant following local and national regulations,
  - b. Evacuate the circuit,
  - c. Purge the circuit with inert gas,
  - d. Evacuate,
  - e. Purge with inert gas,
  - f. Open the circuit.
- The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems. Refrigerant purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system. When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and that ventilation is available.

# **Critical Components for Refrigerant Leak Containment**

# **All Units**


# **Hinged Door Panels**



If the door panels, barrier, mullions and rubber seals (highlighted in red) must be removed for service, ensure they are returned to their proper places before starting the unit. Verify that the rubber seals on the barrier and the compressor base panel are properly aligned and tightly secured. Verify that the brackets behind the mullions are secured.

Verify that the door panel liners and bracket are tightly secured. These steps are critical to containing flammable refrigerant and preventing it from migrating to sources of ignition in the event of a leak.

# **Non-hinged Door Panels**



Verify that the door panel brackets are tightly secured. This is critical to containing flammable refrigerant and preventing it from migrating to sources of ignition in the event of a leak.

# **A-Filters**

LHT units use six 24 X 24 X 2" fiberglass throw-away type filters. Filters may be accessed through the economizer / filter access door. Filters should be checked monthly (or more frequently in severe use) and cleaned or replaced regularly. Take note of the "AIR FLOW DIRECTION" marking on the filter frame when re-installing.

#### **B-Lubrication**

All motors and blower wheels used in LHT units are lubricated; no further lubrication is required.

# **C-Supply Air Blower Wheel**

Annually inspect supply air blower wheel for accumulated dirt or dust. Turn off power before attempting to remove access panel or to clean blower wheel.

# **D-Evaporator Coil**

Inspect and clean coil at beginning of each season. Clean using mild detergent or commercial coil cleanser. Check condensate drain pan and line, if necessary. Flush coil and condensate drain with water taking care not to get insulation, filters and return air ducts wet. Check connecting lines and coil for evidence of oil and refrigerant leaks.

#### E-Condenser Coil

Clean condenser coil annually with detergent or commercial coil cleaner and inspect monthly during the cooling season. Check connecting lines and coil for evidence of oil and refrigerant leaks.

# F-Electrical

- 1 Check all wiring for loose connections.
- 2 Check for correct voltage at unit (unit operating).
- 3 Check amp-draw on both condenser fan motor and blower motor.

Fan Motor Rating Plate	_ Actual _	
Indoor Blower Motor Rating	Plate	_ Actual

#### **VII-ACCESSORIES**

The accessories section describes the application of most of the optional accessories which can be factory or field installed to the LHT units.

#### **A-Roof Curbs**

When installing the LHT units on a combustible surface for downflow discharge applications, the hybrid C1CUR-B70C-1 8-in height, C1CURB71C-1 14-in height, C1CURB72C-01 18-in height and C1CURB73C-1 24-in roof mounting frame is used. The assembled hybrid mounting frame is shown in FIGURE 22. Refer to the roof mounting frame installation instructions for details of proper assembly and mounting. The roof mounting frame MUST be squared to the roof and level before mounting. Plenum system MUST be installed before the unit is set on the mounting frame. Typical roof curbing and flashing is shown in FIGURE 23. Refer to the roof mounting frame installation instructions for proper plenum construction and attachment.

For horizontal discharge applications, use the standard C1URB14C-1 26-in or C1CURB16C-1 37-in height roof mounting frame. This frame converts unit from down-flow to horizontal air flow. The 37 inch horizontal frame meets National Roofing Code requirements. The roof mounting frames are recommended in all other applications but not required. If the LHT units are not mounted on a flat (roof) surface, they MUST be supported under all edges and under the middle of the unit to prevent sagging. The units MUST be mounted level within 1/16" per linear foot or 5mm per meter in any direction.




FIGURE 22




FIGURE 23

#### **B-Transitions**

Optional supply/return transitions C1DIFF33C-1 and C1DIFF34C-1 are available for use with LHT series units utilizing optional C1CURB roof curbs. Transition must be installed in the roof curb before mounting the unit to the frame. Refer to the manufacturer's instructions included with the transition for detailed installation procedures.

# C-C1DAMP10 & E1DAMP20 Outdoor Air Dampers

C1DAMP10C and E1DAMP20C (FIGURE 24) consist of a set of dampers which may be manually or motor operated to allow up to 25 percent outside air into the system at all times. Either air damper can be installed in LHT units. Washable filter supplied with the outdoor air dampers can be cleaned with water and a mild detergent. It should be sprayed with Filter Handicoater when dry prior to re-installation. Filter Handicoater is R.P. Products coating no. 418 and is available as Part No. P-8-5069.




FIGURE 24

# **D-Supply and Return Diffusers**

Optional flush mount diffuser/return FD11 and extended mount diffuser/return RTD11 are available for use with all LHT units. Refer to manufacturer's instructions included with transition for detailed installation procedures.

# E-E1ECON15C-2 Standard and E1ECON17C-1 High Performance Economizer (Field or Factory Installed)

The optional economizer can be used with downflow and horizontal air discharge applications. The economizer uses outdoor air for free cooling when temperature and/ or humidity is suitable. An economizer hood is furnished with the economizer.

**NOTE -** Gravity exhaust dampers are required with power exhaust.

The economizer is controlled by the A55 Unit Controller. The economizer will operate in one of four modes. Each mode requires a different A55 Unit Controller DIP switch setting. Each mode also requires different sensors. The following is a brief description. See economizer installation instruction for more detail.

# 1-"TMP" MODE (SENSIBLE TEMPERATURE)

In the "TMP" mode, the IMC uses input from the factory installed RT6 Supply Air Sensor, RT16 Return Air Sensor and RT17 Outdoor Air Sensor to determine suitability of outside air and economizer damper operation. When outdoor sensible temperature is less than return air sensible temperature, outdoor air is used for cooling. This may be supplemented by mechanical cooling to meet comfort demands. This application does not require additional optional sensors.

# 2-"ODE" MODE (OUTDOOR ENTHALPY)

The "ODE" or outdoor enthalpy mode requires a field-provided and -installed Honeywell C7400 enthalpy sensor (16K96). The sensor monitors outdoor air temperature and humidity (enthalpy). When outdoor air enthalpy is below the enthalpy control setpoint, the economizer modulates to allow outdoor air for free cooling.

# 3-"DIF" MODE (DIFFERENTIAL ENTHALPY)

The "DIF" or differential enthalpy mode requires two field-provided and -installed Honeywell C7400 enthalpy sensors (16K97). One sensor is installed in the outside air opening and the other sensor is installed in the return air opening. When the outdoor air enthalpy is below the return air enthalpy, the economizer opens to bring in out door air for free cooling.

# 4-"GLO" MODE (GLOBAL)

Global Mode - The "GLO" or global mode is used with an energy management system which includes a global control feature. Global control is used when multiple units (in one location) respond to a single outdoor air sensor. Each energy management system uses a specific type of outdoor sensor which is installed and wired by the controls contractor.

Motorized Outdoor Air Damper - The "GLO" mode is also used when a motorized outdoor air damper is installed in the system.

**NOTE -** All economizer modes of operation will modulate dampers to 55F supply air.

#### **F-Gravity Exhaust Dampers**

C1DAMP50C dampers (FIGURE 24) are used in downflow and LAGEDH are used in horizontal air discharge applications. LAGEDH gravity exhaust dampers are installed in the return air plenum . The dampers must be used any time an economizer or power exhaust fans are applied to LHT series units. An exhaust hood is furnished with the gravity exhaust damper.

Gravity exhaust dampers allow exhaust air to be discharged from the system when an economizer and/or power exhaust is operating. Gravity exhaust dampers also prevent outdoor air infiltration during unit off cycle. See installation instructions for more detail.




FIGURE 25

#### **G-C1PWRE10 Power Exhaust Fans**

C1PWRE10 power exhaust fans are used in downflow applications only. C1PWRE10 fans require optional downflow gravity exhaust dampers and E1ECON15 economizers. Power exhaust fans provide exhaust air pressure relief and also run when return air dampers are closed and supply air blowers are operating. FIGURE 25 shows the location of the power exhaust fans. See installation instructions for more detail.

# **H-Control Systems**

The A55 Unit Controller provides all control function for the rooftop unit. Default operation requires a standard room thermostat or direct digital controller (DDC). The A55 can also control the unit from a zone temperature sensor. The A55 Unit Controller is a network controller when daisy-chained to the L Connection® Network Control System. For ease of configuration, the A55 can be connected to a PC with Unit Controller PC software installed.

#### I-Smoke Detectors A171, A172, A173

Photoelectric smoke detectors are a factory- and field-installed option. The smoke detectors can be installed in the supply air section (A172), return air section (A171), or in both the supply and return air section. Smoke detection control module (A173) is located below the control panel. Wiring for the smoke detectors are shown on the temperature control section (C) wiring diagram in back of this manual.

# **J-Blower Proving Switch S52**

The blower proving switch monitors blower operation and locks out the unit in case of blower failure. The switch is N.O. and closes at .15" W.C. The switch is mounted on the middle left corner of the blower support panel. Wiring for the blower proving switch is shown on the temperature control section (C) wiring diagram in back of this manual.

# K-Dirty Filter Switch S27

The dirty filter switch senses static pressure increase indicating a dirty filter condition. The switch is N.O. and closes at 1" W.C. The switch is mounted on the top corner of the economizer. Wiring for the dirty filter switch is shown on the temperature control section (C) wiring diagram in back of this manual.

# L-Indoor Air Quality (CO2) Sensor A63

The indoor air quality sensor monitors CO2 levels and reports the levels to the A55 Unit Controller. The board adjusts the economizer dampers according to the CO2 levels. The sensor is mounted next to the indoor thermostat or in the return air duct. Refer to the indoor air quality sensor installation instructions for proper adjustment. Wiring for the indoor air quality switch is shown on the temperature control section (C) wiring diagram in back of this manual.

# M-Optional UVC Lights

The Healthy Climate germicidal light emits ultraviolet (UVC) energy that has been proven effective in reducing microbial life forms (viruses, bacteria, yeasts and molds) in the air.

UVC germicidal lamps greatly reduce the growth and proliferation of mold and other bio-aerosols (bacteria and viruses) on illuminated surfaces.

Germicidal lamps are NOT intended to be used for removal of active mold growth. Existing mold growth must be appropriately removed PRIOR to installation of the germicidal lamp.

Refer closely to UVC light installation instruction warnings when servicing units.

# N-Drain Pan Overflow Switch S149 (optional)

The overflow switch is used to interrupt cooling operation when excessive condensate collects in the drain pan. The N.C. overflow switch is connected to the M2 Unit Controller (A55) through DI-3. When the switch opens, the Unit Controller will shut off the unit. After a five-minute time out, the Unit Controller will verify the overflow switch position and restart the unit (if the switch has closed). The Unit Controller has a three-strike counter before the unit locks out. This means the Unit Controller will allow the overflow switch to open three times per thermostat demand. If the unit locks out, a reset of the Unit Controller is required after the switch has closed to restore unit operation.

# O-Indoor Air Quality Sensor

If a sensor fails, use the following procedures to physically remove the failed sensor from the unit. All units will have two IAQ sensors installed, one in the return air and the second one in the supply side. See FIGURE 26. The sensors are secured to the tray by two screws. The power cable assembly will need to be detached from the connector located on the bottom of the sensor as well.

# Removing the Sensor

- 1 Go to Menu > Network Integrations > Wireless Sensor Network Setup > Wireless Sensor Network.
- 2 From the Network Nodes list, select the IAQ sensor that is being replaced.
- 3 On the Sensor Information Screen, select the Remove Sensor option at the bottom of the screen.
- 4 Type in the sensor name that is to be removed and select Proceed.

# **Replacing the Sensor**

- Open the CORE Service App and navigate to Menu
   (Setup) Network Integration > Wireless Sensor
   Network Setup > Wireless Sensor Network.
- 2 Click Add node on the Network Nodes screen. This triggers the CORE Service App to scan for both the WIAQ Return Sensor and WIAQ Discharge Sensor.
- 3 Follow the prompts on the screen to finish the adding process.
- 4 Verify that the CORE Service App displays the "Node Provisioned" on the Provision Sensor Network.
- 5 Verify if CORE Service app is showing PM2.5 counts for both return and supply mounted sensors and TVOC counts from return mounted sensor.




FIGURE 26

# P-Bipolar Ionizer

The Needlepoint Bipolar Ionizer (NBPI) kit is specifically designed for LG/LC/LH/LD/KG/KC/KH 024-300 units. The ionizer is equipped with dry contacts which allow a Building Automation System (BAS) to interface and indicate ionizer functionality.

**Note -** The BAS will be able to monitor units equipped with M4 Unit Controllers only. Units with an M3 Unit Controller or no controller need to be connected to a separate monitoring system.

The Ionizers are also equipped with a green LED which indicates power is on. When the blower is in operation, power is delivered to the Ionizers and ions are generated. See TABLE 12 for unit application.

TABLE 12

LHT Unit	Part No.			
156/180	21U37	622688-03		
240	21U38	622688-04		

# VIII--Multi-Staged Blower

# **A-Design Specifications**

Use the TABLE 13 to fill in test and balance values when setting up the unit. If only high and low cooling design specifications are provided, set the medium cooling CFM at the high or low cooling design spec or any CFM between.

#### **B-Set Maximum CFM**

Use attached table to determine highest blower CFM for appropriate unit. Adjust the blower pulley to deliver that amount of CFM with only the blower operating. See Determining Unit CFM in the Blower Operation and Adjustment section.

# **C-Set Blower Speeds**

1 - Use the following mobile service app menu to enter the blower design specified CFM into the Unit Controller. Make sure blower CFM is within limitations shown in TABLE 13 or TABLE 14. Refer to the Unit Controller manual provided with unit.

# RTU MENU > RTU OPTIONS > BLOWER > SPEED

2 - Enter the following design specifications as shown in TABLE 13.

Blower /

Heat CFM

Cooling High CFM

Cooling Low CFM

Vent CFM

- 3 Adjust the blower RPM to deliver the target CFM based on the measured static pressure using the blower table.
- 4 Measure the static pressure again and apply the static pressure and RPM to the blower tables to determine adjusted CFM.
- 5 Repeat adjustments until design CFM is reached.

#### **D-Set Damper Minimum Position**

To maintain required minimum ventilation air volumes when the unit is in the occupied mode, two minimum damper positions must be set.

The Unit Controller will open the damper to "Min OCP Blwr High" when blower CFM is at or ABOVE the "midpoint" CFM.

The Unit Controller will open the dampers to "Min OCP Blwr Low" when blower CFM is BELOW a "midpoint" CFM.

The Unit Controller will calculate the "midpoint" CFM.

\*Available blower speeds vary by unit and thermostat stages.

#### **Set Minimum Position 1**

Use the following mobile service app menu to set "Min OCP Blwr High" for the blower CFM above the "midpoint" CFM. When navigating into this menu, the Unit Controller will run damper calibration and allow damper position adiustment.

#### RTU MENU > SETTINGS > RTU OPTIONS > DAMPER

Tap "Next" to skip tabs and complete damper position calibration until "Damper Calibration Blower Speed High" tab appears.

Measure the intake air CFM. If the CFM is lower than the design specified CFM for ventilation air, use the Unit Controller to increase the damper percent open. If the CFM is higher than specified, decrease the damper percent open.

**Note -** Intake air CFM can also be determined using the outdoor air temperature, return air temperature and mixed air temperature. Refer to the economizer or outdoor air damper installation instructions.

#### **Set Minimum Position 2**

Use the following mobile service app menu in the Unit Controller to set "Min OCP Blwr Low" for the blower CFM below the "midpoint" CFM. When navigating into this menu, the Unit Controller will run damper calibration and allow damper position adjustment.

# RTU MENU > SETTINGS > RTU OPTIONS > DAMPER

Tap "Next" to skip tabs and complete damper position calibration until "Damper Calibration Blower Speed High" tab appears.

Measure the intake air CFM. If the CFM is lower than the design specified CFM for ventilation air, use the Unit Controller to increase the damper percent open. If the CFM is higher than specified, decrease the damper percent open.

**Note -** Intake air CFM can also be determined using the outdoor air temperature, return air temperature and mixed air temperature. Refer to the economizer or outdoor air damper installation instructions.

#### E-Inverter Bypass Option

The supply air inverter is factory-set to by-pass the inverter manually. To by-pass the inverter and operate the blower in the constant air volume mode, use the following Unit Controller menu and set to "engaged":

SETTINGS > RTU OPTIONS > BLOWER > VFD BYPASS

To configure the unit to by-pass the inverter automatically, use the following Unit Controller menu.

SETUP > INSTALL

Press SAVE until the menu reads:

**CONFIGURATION ID 1** 

Change the 6th character position to "A" for automatic bypass option.

Press SAVE

**Caution -** Units not equipped with an inverter will have the 6th character set to "N", indicating the inverter is not bypassed. The blower motor could be damaged and/or result in product or property damage if the setting is changed to automatic or manual.

# **F-Unit Operation**

Use the mobile app to check unit mechanical operation. See the Service - Test section of the Unit Controller man-

# G-Manual Supply Air VFD Bypass

**IMPORTANT -** All dampers must be open to prevent damage to duct work and dampers.

**Note -** This section does not apply to units equipped with optional automatic VFD bypass. That option will automatically change from multi-stage air volume to constant air volume operation in the event of VFD failure.

Manually change blower operation to constant air volume as follows:

 Disconnect all power to unit and WAIT AT LEAST 10 MINUTES before opening the VFD cover.

# **A WARNING**

# **ELECTRICAL SHOCK HAZARD.**

STOP! Before you continue, make sure that power to the VFD has been off for at least 10 minutes. The capacitor in the VFD holds high voltage power for up to 10 minutes after power has been disconnected.

- 2 Locate P246 and P247 connectors near the VFD.See FIGURE 27.
- 3 Disconnect P246 from P246 (power in to VFD) and P247 from P247 (power out to blower). See FIGURE 28.
- 4 Connect P246 to P247. See FIGURE 29.




FIGURE 27

- 5 Restore power to unit. Blower will operate in constant air volume (CAV) mode.
  - **Note -** The indoor blower motor will start as soon as the main unit power is restored. In manual bypass, the blower will run regardless of thermostat signals until main unit power is turned off. Manual bypass is meant for emergency operation only and not long-term usage.
- 6 Check the indoor blower motor nameplate for full load amperage (FLA) value. Measure the amp readings from the indoor blower motor operating in bypass mode. If measured amps are higher than nameplate FLA value, decrease the CFM by opening (turning counterclockwise) the motor pulley. See FIGURE 15. Do not exceed minimum and maximum number of pulley turns as shown in TABLE 6.




FIGURE 28




FIGURE 29

**TABLE 13** HEATING, VENTILATION & SMOKE MINIMUM AND MAXIMUM CFM

	Unit	Нє	eating CFM		Vent CFM			Smoke CFM			
Model	Speed	Heat Code	Default	Min	Max	Default	Min	Max	Default	Min	Max
LDT156H LHT156H	Low	L		2725							
	Std	S		4325							
	Med	М	6000	4500	6250	5200	1950	6250	5200	1950	6250
	HP W/O EH	N		3900							
	15, 30, 45, 60, 90 KW	E, J, K, L,		6000							
	Low	L		2725	7200	6000	2250	7200	6000	2250	
LDT180H	Std	S		4325							
LDIIOUH	Med	М	6000	4500							7200
	High	Н	6000	5125	7200	6000					7200
LUTACOLL	HP W/O EH	N		4500							
LHT180H	15, 30, 45, 60, 90 KW	E, J, K, L, P		6000							
L DT240LL	Low, Std, Med	L, S, M		4500					8000		
LDT240H	High	Н		5125	0000	0000	3000	9600		0000	0000
111704011	HP W/O EH	N	8000	6000	9600	8000				3000	9600
LHT240H	15, 30, 45, 60, 90 KW	E, J, K, L, P		6000							


<sup>\*</sup>Use highest value between Heating and Cooling High CFM Max. \*Use highest value between Heating and Cooling High CFM Max.

**TABLE 14 COOLING MINIMUM AND MAXIMUM CFM** 


LHT	Coo	ling Low	/ CFM	Cool	ing High	CFM
Unit	De- fault	Min	Max	De- fault	Min	Max
156H	3380	1500	6250	4675	4000	6250
180H	3900	2000	7200	5400	5000	7200
240H	5200	3000	9600	7200	6250	9600

<sup>\*</sup>Use Cooling High CFM Max

# IX-Wiring Diagrams and Sequence of Operation



# ECONOMIZER BB CC DD M57110K RANGE 2-10 VDC B7 MOTOR-DAMPER-ECO D2 M524-SR RANGE 2-10 VDC B7 MOTOR-DAMPER-ECO 2 1 3 3



NOTES

A7 AND A62 NOT USED FOR SENSIBLE

1 TEMPERATURE CONTROL.

FOR UNIT DIFFERENTIAL ENTHALPY CONTROL,
ADD A62 RETURN AIR ENTHALPY SENSOR

A55


08

09

Model: LC,LG,LH,LD,SC,SG Series | CLG | ACCS | ACCS | SEC |

_		REV	EC NO.	DATE	BY	APVD	REVISION NOTE
5 x	10		CN-008594	10/15/2020	RV	MXR6	ORIGINATED AT PD&R CARROLLTON, TX
	UT N	001	CN-010356B	03/24/2022	MXR6	JAL21	UPDATED APPLICABLE MODEL NUMBERS.
	ZE	002	CN-012457P	03/06/2024	AXL	AAH	A) ADDED SC, SG TO MODELS

# EHA - 15/90 G Voltage




KEY	DESCRIPTION
A55	CONTROL, BOARD LENNOX
A178	BOARD,COMPRESSORS 3 & 4
F3	FUSE, ELECTRIC HEAT
F4	FUSE, UNIT
F42	FUSE, ELECTRIC HEAT 1 A, 2A
F43	FUSE, ELECTRIC HEAT 3, 4
F44	FUSE, ELECTRIC HEAT 5, 6
F45	FUSE, ELECTRIC HEAT 7, 8
HE1	ELEMENT, ELECTRIC HEAT 1
HE3	ELEMENT, ELECTRIC HEAT 3
HE4	ELEMENT, ELECTRIC HEAT 4
HE5	ELEMENT, ELECTRIC HEAT 5
HE7	ELEMENT, ELECTRIC HEAT 7
HE8	ELEMENT, ELECTRIC HEAT 8
K9,-1	RELAY, HEAT
K15,-1	CONTACTOR, ELECTRIC HEAT 1,2
K16,-1	CONTACTOR, ELECTRIC HEAT 1A,2A
K17,-1	CONTACTOR, ELECTRIC HEAT 3,4
K18,-1	CONTACTOR, ELECTRIC HEAT 5,6

S15	SWITCH, LIMIT PRIMARY ELECTRIC HEAT
S20	SWITCH, LIMIT SECONDARY ELECTRIC HEAT 1,2
S107	SWITCH, PRIMARY ELECTRIC HEAT
S157	SWITCH, LIMIT SECONDARY ELECTRIC HEAT 1A
S158	SWITCH, LIMIT SECONDARY ELECTRIC HEAT 2A
S159	SWITCH, LIMIT SECONDARY ELECTRIC HEAT 3,4
S160	SWITCH, LIMIT SECONDARY ELECTRIC HEAT 5,6
TB2	TERMINAL STRIP, UNIT
ТВ3	TERMINAL STRIP, ELECTRIC HEAT

J/P	DESCRIPTION	D
7	ELECTRIC HEAT CONTROL	L
37	ELECTRIC HEAT CONTROL	L

G 460/60/3


TB2 IS USED IN SOME SCCR OPTION UNITS ONLY



CHASSIS	KW	HE1	HE1A	HE2	HE2A	HE3	HE4	HE5	HE6	HE7	HE8
С	15		7.5		7.5						
D	20		10		10						
CD	30		15		15						
D	40		20		20						
CD	45	15				7.5		15		7.5	
CD	60	15				15		15		15	
D	80	20			20			20	20		
CD	90	15				15	15	15		15	15
D	120	15		15		15	15	15	15	15	15

\$ <b>[#*8</b> *# <b>19</b> }	WIRING DIAG	RAM	07/24				
§ <b>3304-17-1</b>	538126-03						
HEATING							
ELECTRIC HEAT LCT/LHT/LCX/LHX E1EH,EHA-15, 20, 30, 40, 45,60, 80, 90, 120 - G, J							
	1	REV.0					
Supersedes	New Form No	).					
538126-02	l F20	538126-03					

# **EHA-15/90 Y VOLTAGE**



#### **SEQUENCE OF OPERATION**

#### **HEAT PUMP**

- 1 A55 Unit Controller receives W1 heating demand
- 2 A55 energizes outdoor fans B4, B5 & B21 through K10 & K68 respectively.
- 3 After A55 proves N.C. lower pressure switch S87 and N.C. high pressure switch S4, contactor K1 is energized.
- 4 N.O. K1 closes energizing compressor B1, and N.C. K1-52 opens de-energizing HR1.
- 5 A55 energizes outdoor fans B22, B23 & B24 through K149 & K150 respectively.
- 6 After A55 proves N.C. lower pressure switch S88 and N.C. high pressure switch S7, contactor K2 is energized.
- 7 N.O. K2 closes energizing compressor B2, and N.C. K2-52 opens de-energizing HR2.

# EHA-15, 30, 45, 60, 90 - Y & G

**NOTE:**Two electric heat sections are used in all 15kW through 90kW heaters. The heat sections are labeled first electric heat section (left side) and second electric heat section (right side). See figure 16.

**NOTE:** In the case of EHA 15 and 30kW, the second heat section (right side) is a slave (only has electric heat elements and a limit). Line voltage is supplied to elements in both heat section one (left side) and two (right side) by the contactors in heat section one (left side).

# **HEATING ELEMENTS:**

1 - Terminal strip TB3 is energized when the unit disconnect closes. TB3 supplies line voltage to electric heat elements HE1 through HE14. Each heating element is protected by fuse F3.

#### FIRST STAGE HEAT:

- 2 Heating demand initiates at W1 in thermostat.
- 3 24VAC is routed to the main control module A55. After A55 proves N.C. primary limits S15 (heat section one, left side), S107 (heat section two, right side), the electric heat contactor K15 and heat relay K9 are energized.

- 4 N.O. contact K15-1 closes allowing the first bank of elements in heat section one (left side) to be energized.
- 5 At the same time, N.O. contacts K9-1 close. A N.O. contact in A55 closes, energizing electric heat relay K17.
- 6 N.O. contacts K17-1 close allowing the first set of elements in heat section two (right side) to be energized.

#### SECOND STAGE HEAT:

- 7 With the first stage heat operating, an additional heating demand initiates at W2 in the thermostat.
- 8 24VAC is routed through the main control module A55, which in turn energizes the electric heat contactor K16.
- 9 N.O. contacts K16-1 close allowing the second set of elements in heat section one (left side) to be energized.
- 10 Simultaneous with step eight, a N.O. contact in the A55 Unit controller closes, allowing 24VAC to energize electric heat contactor K18.
- 11 N.O. contacts K18-1 close allowing the second set of elements in heat section two (right side) to be energized.

#### **END OF SECOND STAGE HEAT:**

- 12 Heating demand is satisfied. Terminal W2 in the thermostat is de-energized.
- 13 Electric heat contactors K16 and K18 are deenergized.
- 14 The second set of electric heat elements in heat sections one (left side) and two (right side) are deenergized.

# **END OF FIRST STAGE HEAT:**

- 15 Heating demand is satisfied. Terminal W1 in the thermostat is de-energized.
- 16 Electric heat contactors K15 and K17 are deenergized.
- 17 The first set of electric heat elements in heat sections one (left side) and two (right side) are deenergized.

# **SEQUENCE OF OPERATION - MSAV® MULTI-STAGE AIR VOLUME**

**Objective:** Outline the unit functions as a result of room thermostat or zone sensor demands.

**Given:** When economizer is present, it will function as an integral part of the unit cooling system. When not present, unit will function as if economizer is present but outdoor ambient is high and sensed as not suitable.

# UNIT OPERATION WITH 2-STAGE THERMOSTAT (2 COOL AND 2 HEAT STAGES, Y1, Y2, W1, W2)

#### **SUPPLY AIR BLOWER SPEED**

Unit has following supply air blower speed setting:

- Ventilation speed
- Cooling Speed Low
- Cooling Speed High
- Heating speed
- Smoke speed (Used only in smoke removal option not discussed)

#### **COOLING**

# <sup>1</sup> Unit Features An Economizer And Outdoor Air Is Suitable

# Thermostat Mode (Y1, Y2)

#### Y1 Demand:

All compressors are off, supply air blower is on low cooling speed to minimize blower power consumption, economizer modulates (minimum to maximum open position) to maintain 55°F supply air temperature (default unit controller setting).

#### Y2 Demand:

All compressors are off, supply air blower is on high cooling speed providing higher cooling capacity, and economizer modulates to maintain 55°F supply air temperature. If economizer stays at maximum open for 3 minutes, compressor 1 is energized while supply air blower stays on high cooling speed providing maximum cooling capacity.

# Unit Does Not Feature An Economizer Or Outdoor Air Is Not Suitable

#### Y1 Demand:

Compressor 1 operates, and supply air blower operates at low cooling speed.

# Y2 Demand:

All compressors operate and supply air blower operates at high cooling speed.

<sup>&</sup>lt;sup>1</sup> Outdoor air suitability is determined by the energy state of outdoor ambient (enthalpy or sensible) and its ability to achieve the desired free cooling effects. Outdoor air suitability can also be determined by a third party controller and provided to the rooftop unit via a network connection.

# SEQUENCE OF OPERATION - MSAV® MULTI-STAGE AIR VOLUME

# <u>UNIT OPERATION WITH 3-STAGE THERMOSTAT OR ZONE SENSOR (3 COOL AND 2 HEAT STAGES, Y1, Y2, Y3 AND W1, W2)</u>

# **SUPPLY AIR BLOWER SPEED**

Unit has following supply air blower speed setting:

- Ventilation speed
- Cooling Speed Low
- Cooling Speed Medium
- Cooling Speed High
- Heating speed
- Smoke speed (Used only in smoke removal option not discussed)

# <sup>1</sup> Unit Features An Economizer And Outdoor Air Is Suitable

#### **COOLING**

# Thermostat or Zone Sensor Mode (Y1, Y2, Y3)

# Y1 Demand:

All compressors are off, supply air blower is on low cooling speed to minimize blower power consumption, economizer modulates (minimum to maximum open position) to maintain 55°F supply air temperature (default unit controller setting).

#### Y2 Demand:

All compressors are off, supply air blower is on high cooling speed providing higher cooling capacity, and economizer modulates to maintain 55°F supply air temperature. If economizer stays at maximum open for 3 minutes, compressor 1 is energized while supply air blower stays on high cooling speed providing maximum cooling capacity. After compressors are energized the economizer stays at maximum open.

#### Y3 Demand:

Compressors 1 and 2 are energized while supply air blower stays on high cooling speed.

# Unit Does Not Feature An Economizer or Outdoor Air Is Not Suitable

# Y1 Demand:

Compressor 1 operates at part load and supply air blower operates at low cooling speed.

#### Y2 Demand:

Compressor 1 operates at part load with compressor 2 ON, and supply air blower operates at medium cooling speed.

#### Y3 Demand:

All compressors operate and supply air blower operates at high cooling speed.

#### **DEFROST**

Coil Sensors (RT48 - Circuit 1 and RT49 - Circuit 2) and Ambient Sensor (RT17) provides input to the Lennox® CORE Unit Controller to initiate a defrost cycle if needed.

Coil sensors are located on a return bend for each circuit on the front of the outdoor coil.

Ambient sensor is located on the inside of the corner mullion on the back of the outdoor coil section.

If a coil sensor measures a temperature below 35°F during mechanical heating mode, defrost logic is enabled. The system will constantly monitor coil and ambient temperatures and will initiate a defrost cycle if the controller determines that the target temperature difference between the coil and ambient temperature has been satisfied, or when the accumulated run time with coil temperature below 35°F reaches 6 hours.

Defrost will not be activated on more than one circuit at the time.

If the ambient sensor fails, or the circuit is in uncalibrated state, the controller will switch to time/temperature defrost operation.

Electric heat is energized during a defrost cycle to maintain discharge air temperature.

<sup>&</sup>lt;sup>1</sup> Outdoor air suitability is determined by the energy state of outdoor ambient (enthalpy or sensible) and its ability to achieve the desired free cooling effects. Outdoor air suitability can also be determined by a third party controller and provided to the rooftop unit via a network connection.

#### SEQUENCE OF OPERATION - MSAV® MULTI-STAGE AIR VOLUME

#### **HEATING**

NOTE – HEATING MODE CAN BE SET TO TWO-STAGE IN THERMOSTAT MODE OR AT FOUR-STAGE IN ROOM SENSOR MODE CONTROL OPTIONS.

# **Two-Stage Operation (Thermostat Mode)**

# W1 Demand:

Both gas valves are open on Low Fire (stage 1 on units with 2-stage gas valves) and supply air blower operates at heating speed

#### W2 Demand:

Both gas valves are open on High Fire (stage 2 on units with 2-stage gas valves) and supply air blower operates at heating speed

# Four-Stage Operation (Room Sensor Mode)

# W1 Demand:

Left heat exchanger gas valve is open on Low Fire (stage 1 on units with 4-stage gas valves) and supply air blower operates at heating speed.

#### W2 Demand:

Both gas valves are open on Low Fire (stage 2 on units with 4-stage gas valves) and supply air blower operates at heating speed.

#### W3 Demand:

Left heat exchanger gas valve will open on High Fire and the right heat exchanger will remain open on Low Fire (stage 3 on units with 4-stage gas valves) and supply air blower operates at heating speed.

# W4 Demand:

Both gas valves are open on High Fire (stage 4 on units with 4-stage gas valves) and supply air blower operates at heating speed.

# **Heating Mode: Thermostat or Zone Sensor**

# W1/H1 Demand:

A first-stage heating demand (W1/H1) will energize compressors 1 and 2 and the outdoor fans.

NOTE - L1 & L2 reversing valves are de-energized in the heating mode.

# **Units With Optional Electric Heat:**

An increased heating demand (W2/H2) will energize electric heat.

NOTE - Compressors 1 and 2 stay energized.

# Units With Optional Two-Stage Electric Heat and Zone Sensor mode:

An increased heating demand (H2) will energize 1st stage of electric heat.

An increased heating demand (H3) will energize 2nd stage of electric heat.

NOTE - Compressors 1 and 2 stay energized.

All Electric heat modules are energized during the defrost cycle (W1).

# **ACCESSORIES**

# **Modulating Outdoor Air Damper**

The minimum damper position for "occupied low blower" and "occupied high blower" is adjusted during unit setup to provide minimum fresh air requirements per ASHRAE 62.1 at the corresponding supply air blower speeds.

- When supply air blower is off or the unit is in unoccupied mode, the outdoor air damper is closed.
- When unit is in occupied mode and supply air blower is operating at a speed below the "midpoint" blower speed, the outdoor air damper is at minimum "low blower" position.
- When unit is in occupied mode and supply air blower is operating at a speed equal to or above the "midpoint" blower speed, the outdoor air damper is at minimum "high blower" position.

NOTE - The "midpoint" blower speed is an average of the minimum and maximum blower speed (minimum speed + maximum speed divided by 2).

# **Power Exhaust Operation**

# NOTE - POWER EXHAUST OPERATION IS THE SAME FOR ALL CONTROL OPTIONS

MSAV® models are equipped with 2-stage power exhaust fans. Power exhaust fans operate when economizer outdoor air dampers are 50% open (adjustable). Power exhaust operates in 1st stage (one fan) up to 70% of supply air blower speed. 2nd stage power exhaust fans (both fans) operate when supply air blower speed is above 70% (adjustable) of full speed.

# Sequence of Operation LHT156/180/240

1 - Line voltage from TB13 energizes transformer T1 and T18. Transformer T1 and T18 provides 24VACpower to the main controller A55. The transformers also provides 24VAC power to the unit cooling, heating and blower controls and thermostat.

#### **ECONOMIZER OPERATION**

- 2 The A55 Unit Controller receives a demand and energizes exhaust fan relay K65 and K231 with 24VAC at 50% (travel) outside air damper open (adjustable).
- 3 N.O. K65-1, K65-2, K231-01 and K231-02 close, energizing exhaust fan motors B10 and B11.

#### **1ST STAGE COOLING**

- 4 First stage cooling demand energizes Y1 and G in the thermostat. G energizes blower, if blower is not already running.
- 5 24VAC is routed to the A55 Unit Controller. After A55 proves N.C. low pressure switch S87 and high pressure switch S4, compressor contactor K1 and L34 are energized.
- 6 A55 energizes outdoor fan B21 directly and fans B4 and B5 through K10.
- 7 N.O. K1 closes energizing compressor B1, and N.C. K1-52 opens denergizing HR1.

#### 2ND STAGE COOLING

- 8 Second stage cooling demand energizes Y2.
- 9 After A55 proves N.C. low pressure switch S88 and N.C. high pressure switch S7, contacotor K2 is energized.
- 10 N.O. K2 closes energizing compressor B2 and K2-52 opens de-energizing crankcase heater HR2.

#### **BLOWER OPERATION**

# With By Pass Installed - Active


- 1 Main control A55 de-energizes relays K202 and K203
- 2 K202 contacts open to interrupt power to B3 blower motor from A96 blower inverter.
- 3 Main control A55 energizes relay K203-7.
- 4 K203-1 N.C. contacts close allowing power to K3.
- 5 K3 contacts close to allow power to B3 blower motor.


# With By Pass Installed - Inactive


- 1 Main control A55 energizes relays K202 and K203.
- 2 K203-1 N.C. contacts open to de-energize K3 relay coil. K3 contacts open to interrupt power to B3 blower motor through K3 N.O. contacts.
- 3 K202 contacts close to allow power to B3 blower motor from A96 blower inverter.

# By-Pass Not Installed

1 - Control inverter A96 energizes B3.







# X-Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely.

Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before starting decommissioning.

- a) Become familiar with the equipment and its operation.
- b) Isolate system electrically.
- c) Before attempting the procedure, ensure that:
  - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
  - all personal protective equipment is available and being used correctly;
  - the recovery process is supervised at all times by a competent person;
  - recovery equipment and cylinders conform to the appropriate standards.
- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.

- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with instructions.
- h) Do not overfill cylinders (no more than 80% volume liquid charge).
- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another REFRIGERATING SYSTEM unless it has been cleaned and checked.

# **▲** IMPORTANT

Equipment shall be labelled stating that it has been decommissioned and emptied of refrigerant. The label shall be signed and dated. Ensure that there are labels on the equipment that state the flammability of the refrigerant used.