

PACKAGED UNITS KITS AND ACCESSORIES

506410-06
9/2025
Supersedes 4/2025

COLD WEATHER KIT

INSTALLATION INSTRUCTIONS FOR COLD WEATHER KIT USED ON LG/LD/KG/KD 092-300, SG/SD 092-120 GAS PACKAGED UNITS

⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a licensed professional HVAC installer or equivalent, service agency, or the gas supplier.

Shipping and Packing List

13X63, 13X64, 13X65, 22A51, 22A55, 31A65, 31A66

Package 1 of 1 contains:

- 1- Heater assembly
- 5- Wire harnesses (4 for 31A65 and 31A66)

Bag assembly containing:

- 1-Relay
- 9-#8 Screws
- 1-Wire tie

22H58, 22H59, 22V43

Package 1 of 1 contains:

- 2- Heater assemblies
- 7- Wire harnesses
 - 1- 106051-01 (LGH units)
 - 1- 604785-01 (KG Units- std. SCCR)
 - 2- 106128-01 HR6 power harnesses (KG)
 - 1- 105722-01 (LGH units - higher SCCR)
 - 1- 107210-01 (LGM/LGT/LDT/LGX units)
 - 1- 108303-01 (LGT/LDT 302-360)

Bag assembly containing:

- 2- Relays
- 18- Thread forming screws
- 24- Wire ties

⚠ WARNING

To prevent serious injury or death:

1. Lock-out/tag-out before performing maintenance.
2. If system power is required (e.g., smoke detector maintenance), disable power to blower, remove fan belt where applicable, and ensure all controllers and thermostats are set to the "OFF" position before performing maintenance.
3. Always keep hands, hair, clothing, jewelry, tools, etc., away from moving parts.

Application

The cold weather kit heats the gas heat compartment to allow gas valve operation during low outdoor temperatures. See TABLE 1 for usage.

TABLE 1

Unit	Unit Voltage	Part No.	Cat. No.
LGH/KG 092-152	Y	613930-01	13X63
LGH/KG 092-152	G, M	613930-02	13X64
LGM/LGT/LD/KG/KD 078-152	J	613930-03	13X65
LGM/LGT/LD/KD 078-152	Y	613930-07	22A51
LGM/LGT/LD/KD 078-152	G, M	613930-08	22A55
LG/LD/KG 156-360(S)	Y	613930-10	22H58
LG/LD/KG 156-360(S)	G, M	613930-11	22H59
LG/LD/KG 156-360(S)	J	613930-12	22V43
SG/SD 092-120	G	613930-14	31A65
SG/SD 092-120	J	613930-15	31A66

Installation - LGH092-150 Units



- 1 - Disconnect all power to unit and open heat access panel.
- 2 - Locate the kit harness labeled 604954-01 kit harness. Remove cold weather kit cover and connect wires labeled HR6 to the cold weather assembly. See FIGURE 1. Replace cold weather kit cover. Discard harness labeled 604956-01 provided in kit
- 3 - Install heater assembly in heat section as shown in FIGURE 2. Use existing screws.
- 4 - Route the remaining harness wires as shown in FIGURE 2. Make wire connections as shown in FIGURE 1.
- 5 - Open control access panel and install K125 as shown in FIGURE 3. Secure with #8 screws provided in kit.
- 6 - Locate existing wires in control box and connect to K125 as shown in FIGURE 3 for standard SCCR units and FIGURE 4 for high SCCR units.



⚠ CAUTION

As with any mechanical equipment, contact with sharp sheet metal edges can result in personal injury. Take care while handling this equipment and wear gloves and protective clothing.




506410-06





Installation - KG, KD 092-150 Units

- 1 - Disconnect all power to unit and open heat access panel.
- 2 - Remove six screws that are holding the unit top to the compressor area corner mullion.
- 3 - Locate the kit harness labeled 604956-01 and identify six wires labeled K1-L1, K1-L2, K125-4, K125-7, K125-A, and K125-B. Route the six wires from the heat section through the side grommet to the control box. See FIGURE 6. Discard harness labeled 604954-01 provided in kit
- 4 - Remove cold weather kit cover and connect wires labeled HR6 to the cold weather assembly. See FIGURE 7. Replace cold weather kit cover.
- 5 - Install heater assembly in heat section as shown in FIGURE 2. Use existing screws.
- 6 - Open control access panel and install K125 as shown in FIGURE 3. Secure with #8 screws provided in kit.
- 7 - Make wire connections in the control box as shown in FIGURE 5 and in the heat section as shown in FIGURE 7.
- 8 - Replace top panel and secure in place.






FIGURE 6




FIGURE 7

Installation - LGM, LGT, LDT 092-150

- 1 - Disconnect all power to unit and open heat access panel. See FIGURE 8.
- 2 - Discard harnesses labeled 604954-01 and 604956-01. Locate the kit power harness which has two 2-pin connectors labeled J/P228.
- 3 - Remove strip heater junction box cover. Route two power harness wires labeled HR6 through the junction box side grommet and connect to the strip heater terminals. See FIGURE 9. Replace junction box cover.
- 4 - Install heater assembly in heat section as shown in FIGURE 10. Use existing screws.
- 5 - Remove ignition control cover and install K125 as shown in FIGURE 10. Secure with #8 screws provided in kit.
- 6 - Disconnect unit J/P425 connectors. See FIGURE 10. Connect power harness J/P228 to J/P425. See FIGURE 11.
- 7 - Route remaining power harness wires labeled K125-4, -6, -7, -9 through the grommets in the bottom of the ignition control box. Connect to appropriate terminals.

- 8 - Locate kit control harness that has a 6-pin, 4-wire connector labeled P229. Connect P229 to J229 cold weather kit harness. See FIGURE 12.
- 9 - Route the other end of the P229 harness to the heat section and make wire connections. See FIGURE 13.




FIGURE 8

CONNECT STRIP HEATER WIRES - LGM, LGT, LD 078-150




FIGURE 9

INSTALL HEATER ASSEMBLY - LGM, LGT, LD 078-150




FIGURE 10

J/P228 POWER HARNESS - LGM, LGT, LD 078-150 K125




FIGURE 11

J/P229 CONTROL HARNESS - LGM, LGT, LD 078-150




FIGURE 12

J/P229 CONTROL HARNESS CONNECTIONS - LGM, LGT, LD 078-150

TO K125
RELAY COIL

CONTROL
HARNESS P229

1	2	3
4	5	6
7	8	9
A	B	

K125-A (10)
K125-B (11)




FIGURE 13

Installation - LGH156-300 Units

- 1 - Disconnect all power to unit and open heat access panel.
- 2 - Install both cold weather assemblies as shown in FIGURE 14. Use existing screws.
- 3 - Install both K125 relays in control area above compressors. Secure with #8 screws. See FIGURE 15.
- 4 - Locate harness labeled 106051-01 for standard SCCR units or 105722-01 for high SCCR units. Route as shown in FIGURE 15. Secure with wire ties. Discard unused harnesses.
- 5 - Make wire connections as shown in FIGURE 16.
- 6 - Use wire ties to securely route and tie harness away from gas heat manifold.




FIGURE 14

COLD WEATHER KIT WIRE ROUTING - LGH156-300S




FIGURE 15

COLD WEATHER KIT WIRING - LGH156-360

A55 - PRODIGY 2.0
M3 UNIT CONTROLLER

DISCONNECT WIRES
FROM IGNITION BOARD
A3 AND A12

--- KIT HARNESS

PWR

A3/A12

CONNECT TO A55
UNIT CONTROLLER

24VAC
24VAC-COM

K125 [1]

K125 [2]


CONNECT PREVIOUSLY
DISCONNECTED UNIT
WIRING TO KIT HARNESS

A3

A12

A3-PWR

A12-PWR



K14

A55 - PRODIGY
M2 UNIT CONTROLLER

J228 P228[1]
J229 P229

VESTIBULE
HEATER
ASSEMBLY
LEFT SIDE

J228 P228[2]
J230 P230

VESTIBULE
HEATER
ASSEMBLY
RIGHT SIDE

FIGURE 16

Installation - KG, KD 156-300 Units

- 1 - Disconnect all power to unit and open compressor access panels.
- 2 - Install both cold weather assemblies as shown in FIGURE 14. Use existing screws.
- 3 - Install both K125 relays in control area above compressors. Secure with #8 screws. See FIGURE 17.
- 4 - Locate harness labeled 604785-01 and route as shown in FIGURE 17. Secure with wire ties. Discard unused harnesses.
- 5 - Make wire connections as shown in FIGURE 18.
- 6 - Use wire ties to securely route and tie harness away from gas heat manifold.





FIGURE 17

COLD WEATHER KIT WIRING - KG, KD 156-300


DISCONNECT WIRES
FROM IGNITION BOARD
A3 AND A12

DISCONNECT WIRES
FROM K2 CONTACTOR

----- KIT HARNESS



A3/A12



K2



DISCONNECT
WIRES

S47/S69 ARE LOCATED
IN THE WIRE BUNDLE
BELOW K125 RELAYS




FIGURE 18

Installation - LDT, LGT, LGM, KG, KD 156-300 Units

- 1 - Disconnect all power to unit and open heat access panel.
- 2 - Install both cold weather assemblies as shown in FIGURE 14. Use six thread forming screws, provided.
- 3 - Install both relays as shown in FIGURE 19. Secure with #8 screws.
- 4 - Locate harness labeled 107210-01. Route as shown in C. Secure with wire ties. Discard unused harnesses.
- 5 - Make wire connections as shown in FIGURE 20.
- 6 - Use wire ties to securely route and tie harness away from gas heat manifold.




FIGURE 19

COLD WEATHER KIT WIRING - LGM156-300




FIGURE 20

COLD WEATHER KIT WIRING - (continued)
LGM156-300




FIGURE 21

Installation - LGX, LDT, LGT, LGM 156-300 A2L Units

- 1 - Disconnect all power to unit and open heat access panel.
- 2 - Install both cold weather assemblies as shown in FIGURE 14. Use six thread forming screws, provided.
- 3 - Install both relays as shown in FIGURE 19. Secure with #8 screws.

- 4 - Locate harness labeled 107210-01. Route as shown in C. Secure with wire ties. Discard unused harnesses.

NOTE - All A2L units gas harnesses routed through divider panel and tied to the manifold as shown in FIGURE 22.

- 5 - Make wire connections as shown in FIGURE 20.
- 6 - Use wire ties to securely route and tie harness away from gas heat manifold.




FIGURE 22

Installation - LGT/LDT 302-360 Units

- 1 - Disconnect all power to unit and open heat access panel.
- 2 - Install both cold weather assemblies as shown in FIGURE 14. Use six thread forming screws, provided.
- 3 - Install both relays as shown in FIGURE 23. Secure with #8 screws.
- 4 - Locate harness labeled 108303-01. Route as shown in FIGURE 23. Secure with wire ties. Discard unused harnesses.
- 5 - Make wire connections as shown in FIGURE 23.
- 6 - Use wire ties to securely route and tie harness away from hot surfaces (collector box cover, combustion blower, flue elbow, etc.).




FIGURE 23

Installation - SG/SD 092-120 Unit

- 1 - Disconnect all power to unit and open control access panel, see FIGURE 24.
- 2 - Install the heater and control assembly in the control compartment as shown in FIGURE 9. Secure with provided screws.
- 3 - Look for the harness labelled 108734-01 (already in the unit). Disconnect connector from P432.
- 4 - Make wire connection as shown in FIGURE 25.

Operation

When ambient temperature drops below 20°F (-7°C), S61 closes.

When ambient temperature drops below -10°F (-23°C), S60 closes to energize K125 and bring on HR6 heater.

When ambient temperature rises to 20°F (-7°C), S60 opens to de-energize HR6 heater.

When ambient temperature drops below -20°F (-29°C), S59 opens to disable GV1 gas valve.

S59 closes to allow heating when temperature rises to 10°F (-12°C).




FIGURE 24




FIGURE 25