

UNIT INFORMATION

SGH
3 & 5 ton

100117

Service Literature

SGH036 & 060 With R-454B

The SGH 3 and 5 ton (10.5 and 17.5 kW) units are configured to order units (CTO) with a wide selection of factory installed options. Units are available in the following heating inputs:

SGH036/060 units are available in Standard 2 Stage 53/70 kBtuh (15.5/20.5 kW) and Medium 2 Stage 81/108 kBtuh (23.7/31.6 kW) heating inputs. SGH060 units have an additional High 2 Stage 113/150 kBtuh (33.1/43.9 kW) heating input.

Information contained in this manual is intended for use by qualified service technicians only. All specifications are subject to change. Procedures outlined in this manual are presented as a recommendation only and do not supersede or replace local or state codes.

If the unit must be lifted for service, rig unit by attaching four cables to the holes located in the unit base rail (two holes at each corner). Refer to the installation instructions for the proper rigging technique.

⚠ WARNING

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance, or an operating electric heater).

Do not pierce or burn.

Be aware that refrigerants may not contain an odor.

⚠ WARNING

If this appliance is conditioning a space with an area smaller than TA min or stored in a space with an area smaller than A min as defined by this instruction, then that space must be without continuously operating open flames (e.g. an operating gas appliance) or other potential ignition sources (e.g. an operating electric heater or similar hot surface). A flame-producing device may be installed in the same space if the device is provided with an effective flame arrest system.

⚠ WARNING

Auxiliary devices which may be potential ignition sources shall not be installed in the duct work. Examples of potential ignition sources are hot surfaces with a temperature exceeding 700°C and electric switching components.



False ceilings or drop ceiling may be used as a return air plenum only if the unit being installed has a Refrigerant Detection System installed.

All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out with work in confined spaces being avoided.

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

Table of Contents

| | |
|---|---------|
| Options / Accessories | Page 2 |
| Specifications | Page 6 |
| Gas Heat Specifications / High Altitude | Page 7 |
| Blower Data | Page 9 |
| Electrical Data | Page 10 |
| Unit Parts Arrangement | Page 11 |
| I-Unit Components | Page 13 |
| Temperature Thermistor | Page 18 |
| RDS Sensors | Page 20 |
| II-Placement and Installation | Page 26 |
| III-Charging - Start Up. | Page 26 |
| IV-System Service Checks | Page 33 |
| V-Maintenance | Page 36 |
| VII-Diagrams | Page 39 |
| VIII-Decommissioning | Page 46 |

WARNING

To prevent serious injury or death:

- 1- Lock-out/tag-out before performing maintenance.
- 2- If system power is required (e.g., smoke detector maintenance), disable power to blower, remove fan belt where applicable, and ensure all controllers and thermostats are set to the "OFF" position before performing maintenance.
- 3- Always keep hands, hair, clothing, jewelry, tools, etc., away from moving parts.

WARNING

Only Manufacturer approved auxiliary devices are permitted to be installed in this unit.

CAUTION

Any service personnel installing, decommissioning, or performing maintenance on the unit must be properly trained with A2L refrigerants.

WARNING



Electric shock hazard. Can cause injury or death. Before attempting to perform any service or maintenance, turn the electrical power to unit OFF at disconnect switch(es). Unit may have multiple power supplies.

WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a licensed professional HVAC installer or equivalent, service agency, or the gas supplier.

CAUTION

As with any mechanical equipment, contact with sharp sheet metal edges can result in personal injury. Take care while handling this equipment and wear gloves and protective clothing.

IMPORTANT

The Clean Air Act of 1990 bans the intentional venting of refrigerant (CFC's and HCFC's) as of July 1, 1992. Approved methods of recovery, recycling or reclaiming must be followed. Fines and/or incarceration may be levied for non-compliance.

WARNING

- This appliance must be installed in accordance with local and national wiring regulations.
- If the appliance is not fitted with an option for full disconnection from power, a means of disconnection must be incorporated in the fixed wiring in accordance with national and local wiring regulations.

OPTIONS / ACCESSORIES

| Item Description | | Order Number | Size | |
|---|---|----------------|------|-----|
| | | | 036 | 060 |
| COOLING SYSTEM | | | | |
| Corrosion Protection | Coated indoor/outdoor coil assemblies, painted cabinet interior | Factory | O | O |
| | Coated outdoor coil assembly | Factory | O | O |
| Drain Pan Overflow Switch | | 21Z07 | OX | OX |
| HEATING SYSTEM | | | | |
| Combustion Air Intake Extension | | 20X99 | X | X |
| | | 33W62 | | |
| | | 89L97 | | |
| Gas Heat Input | Standard 2 Stage - 53/70 kBtuh input (Low NOx) | Factory | O | O |
| | Medium 2 Stage - 81/108 kBtuh input (Low NOx) | Factory | O | O |
| | High 2 Stage - 113/150 kBtuh input (Low NOx) | Factory | | O |
| | Standard 2 Stage - 84.5/130 kBtuh input | Factory | | |
| | Medium 2 Stage - 117/180 kBtuh input | Factory | | |
| | High 2 Stage - 156/240 kBtuh input | Factory | | |
| | Standard 2 Stage - 169/260 kBtuh input | Factory | | |
| | Medium 2 Stage - 234/360 kBtuh input | Factory | | |
| | High 2 Stage - 312/480 kBtuh input | Factory | | |
| | | | | |
| LPG/Propane Kits | 2 Stage Standard Heat | 21Z24 | X | X |
| | 2 Stage Medium and High Heat | 21Z23 | X | X |
| | Standard Heat | 14N28 | | |
| | Medium Heat | 14N29 | | |
| | High Heat | 14N30 | | |
| Low Temperature Vestibule Heater | 460V - 3 phase | 31A62 | X | X |
| | 575V - 3 phase | 31A63 | X | X |
| | 460V - 3 phase | 31A65 | | |
| | 575V - 3 phase | 31A66 | | |
| | 460V - 3 phase | 58W29 | | |
| | 575V - 3 phase | 58W30 | | |
| Stainless Steel Heat Exchanger | | Factory | O | O |
| Vertical Vent Extension | | 31W62 | X | X |
| | | 73M72 | | |
| | | 42W16 | | |
| BLOWER - SUPPLY AIR | | | | |
| ECM DirectPlus™, Direct Drive, MSAV® (Multi-Stage Air Volume) | | 1.5 hp Factory | O | O |
| Belt Drive, MSAV® (Multi-Stage Air Volume) | | 3 hp Factory | | |
| | | 5 hp Factory | | |
| | | 7.5 hp Factory | | |
| CABINET | | | | |
| Combination Coil/Hail Guards | | 19H54 | X | X |
| | | 19H55 | | |
| | | 13T16 | | |

¹ Order two.

NOTE - Order numbers shown are for ordering field installed accessories.

OX - Configure To Order (Factory Installed) or Field Installed

O = Configure To Order (Factory Installed)

X = Field Installed

OPTIONS / ACCESSORIES

| Item Description | | Order Number | Size | |
|---|---|--------------|------|-----|
| | | | 036 | 060 |
| CONTROLS | | | | |
| Commercial Control | LonTalk® Module | Factory | O | O |
| Dirty Filter Switch | | Factory | O | O |
| ¹ Smoke Detectors | Supply or Return (Power board and one sensor) | 10B40 | OX | OX |
| | | 10B42 | | |
| | Supply and Return (Power board and two sensors) | 10B41 | OX | OX |
| | | 10B43 | | |
| ELECTRICAL | | | | |
| Voltage 60 hz | 460V - 3 phase | Factory | O | O |
| | 575V - 3 phase | Factory | O | O |
| GFI Service Outlets (REQUIRED) | 20 amp non-powered, field-wired (all voltages) | Factory | O | O |
| Weatherproof Cover for GFI | | 10C89 | X | X |
| INDOOR AIR QUALITY | | | | |
| Air Filters | | | | |
| Standard Air Filters | MERV 8 (16 x 20 x 2 - Order 4 per unit) | 54W20 | OX | OX |
| | MERV 8 (20 x 25 x 2 - Order 4 per unit) | 50W61 | | |
| | MERV 8 (20 x 20 x 2 - Order 12 per unit) | 54W21 | | |
| Healthy Climate® High Efficiency Air Filters | MERV 13 (16 x 20 x 2 - Order 4 per unit) | 52W37 | OX | OX |
| | MERV 13 (20 x 25 x 2 - Order 4 per unit) | 52W41 | | |
| | MERV 13 (20 x 20 x 2 - Order 12 per unit) | 52W39 | | |
| Replacement Media Filter With Metal Mesh Frame 20 x 20 x 2 Order 12 per unit (includes non-pleated filter media) | | 44N60 | | |
| Indoor Air Quality (CO₂) Sensors | | | | |
| Sensor - Wall-mount, off-white plastic cover with LCD display | | 77N39 | X | X |
| Sensor - Wall-mount, off-white plastic cover, no display | | 23V86 | X | X |
| Sensor - Black plastic case, LCD display, rated for plenum mounting | | 87N52 | X | X |
| Sensor - Black plastic case, no display, rated for plenum mounting | | 23V87 | X | X |
| CO₂ Sensor Duct Mounting Kit - for downflow applications | | 23Y47 | X | X |
| Aspiration Box - for duct mounting non-plenum rated CO₂ sensors (77N39) | | 90N43 | X | X |
| HUMIDITROL® CONDENSER REHEAT OPTION | | | | |
| Humiditrol® Dehumidification Option | | Factory | O | O |
| ¹ Factory installed smoke detectors must be ordered for use with either 115V or 24V external power supply only. | | | | |
| NOTE - Order numbers shown are for ordering field installed accessories. OX - Configure To Order (Factory Installed) or Field Installed O = Configure To Order (Factory Installed) X = Field Installed | | | | |

OPTIONS / ACCESSORIES

| Item Description | Order Number | Size | |
|---|-------------------------------|------|-----|
| | | 036 | 060 |
| ECONOMIZER | | | |
| High Performance Economizer (Approved for California Title 24 Building Standards / AMCA Class 1A Certified) | | | |
| ULL Economizer - Includes Outdoor Air Hood (Global Sensor, field provided, order Barometric Relief Dampers separately) | Factory 18X87 | O | O |
| Economizer Controls | | | |
| Differential Enthalpy (Not for Title 24) | Order 2 21Z09 | OX | OX |
| Global Control | Sensor Field Provided Factory | O | O |
| Barometric Relief Dampers | | | |
| Barometric Relief Dampers (No Exhaust Hood) | Factory | O | O |
| Barometric Relief Dampers With Power Exhaust Fans (Exhaust Hood Furnished) | Factory | | |
| Barometric Relief Dampers Without Power Exhaust Fans (No Exhaust Hood) | Factory | | |
| Barometric Relief Dampers Without Power Exhaust Fans (Exhaust Hood Furnished) | Factory | | |
| POWER EXHAUST | | | |
| Standard Static | Factory | | |
| OUTDOOR AIR | | | |
| Motorized Outdoor Air Dampers with Outdoor Air Hood and Bird Screen | 18X89 | | |
| Manual Outdoor Air Damper with Outdoor Air Hood and Bird Screen | 18X88 | | |
| ROOF CURBS | | | |
| Hybrid Roof Curbs, Downflow, 14 in. height | 11F70 | X | X |
| | 11F72 | | |
| | Full Perimeter 11F74 | | |
| Hybrid Roof Curbs, Downflow 24 in. height | 11F71 | X | X |
| | 11F73 | | |
| | Full Perimeter 11F75 | | |
| Curb Alignment (Adapter plate mates new unit to existing roof curb for replacement of LGE240) | Factory | | |
| NOTE - Order numbers shown are for ordering field installed accessories. OX - Configure To Order (Factory Installed) or Field Installed O = Configure To Order (Factory Installed) X = Field Installed | | | |

| SPECIFICATIONS | | DIRECT DRIVE 3 - 5 TON | |
|---|--|---|--|
| Model | | SGH036H5E | SGH060H5E |
| Nominal Tonnage | | 3 | 5 |
| Efficiency Type | | High | High |
| Blower Type | | MSAV® (Multi-Stage Air Volume) (Direct Drive ECM) | MSAV® (Multi-Stage Air Volume) (Direct Drive ECM) |
| Cooling Performance | Gross Cooling Capacity - Btuh | 37,000 | 60,300 |
| | ¹ Net Cooling Capacity - Btuh | 35,500 | 57,900 |
| | AHRI Rated Air Flow - Cfm | 1200/850 | 1750/1300 |
| | Total Unit Power | 2.6 | 4.7 |
| | ¹ SEER2 (Btuh/Watt) - 460V/575V-3ph | 17.0 | 16.1 |
| | ¹ EER2 (Btuh/Watt) - 460V/575V-3ph | 13.5 | 12.4 |
| Refrigerant Charge | Refrigerant Type | R-454B | R-454B |
| | Without Reheat Option | 5 lbs. 2 oz. | 5 lbs. 6 oz. |
| | With Reheat Option | 5 lbs. 8 oz. | 5 lbs. 5 oz. |
| ² Sound Rating Number | dBA | 67 | 78 |
| Gas Heating Options Available - See page 23 | | Standard (2 Stage) Medium (2 Stage) | Standard (2 Stage) Medium (2 Stage) High (2 Stage) |
| Compressor Type (Number) | | Two-Stage Scroll (1) | Two-Stage Scroll (1) |
| Condenser Coil | Net face area - ft. ² | 18.7 | 18.7 |
| | Rows | 1 | 1 |
| | Fins - in. | 23 | 23 |
| Condenser Fan(s) | Motor (number) HP (type) | (2) 1/3 (ECM) | (2) 1/3 (ECM) |
| | Rpm | 340-560 | 340-860 |
| | Watts | 90-136 | 90-354 |
| | Diameter (Number) - in. | (2) 24 | (2) 24 |
| | Blades | 3 | 3 |
| | Total air volume - Cfm | 3900 | 6300 |
| | | | |
| Evaporator Coil | Net face area - ft. ² | 7.02 | 7.02 |
| | Rows | 1 | 1 |
| | Fins - in. | 20 | 20 |
| | Condensate drain size (NPT) - in. | (1) 1 | (1) 1 |
| | Expansion device type | Balance Port TXV, removable head | |
| ³ Indoor Blower | Nominal motor HP (type) | 1.5 (ECM) | 1.5 (ECM) |
| | Wheel nominal diameter x width - in. | (1) 14 x 5 | (1) 14 x 5 |
| Filters | Type of filter | MERV 8 or 13 | |
| | Number and size - in. | (4) 16 x 20 x 2 | (4) 16 x 20 x 2 |
| Line voltage data (Volts-Phase-Hz) | | 460-3-60, 575-3-60 | |

NOTE - Net capacity includes evaporator blower motor heat deduction. Gross capacity does not include evaporator blower motor heat deduction.

¹ AHRI Certified to AHRI Standard 210/240; 95°F outdoor air temperature and 80°F db/67°F wb entering evaporator air; minimum external duct static pressure.

² Sound Rating Number rated in accordance with test conditions included in AHRI Standard 270-95.

³ Using total air volume and system static pressure requirements determine from blower performance tables rpm and motor output required. Maximum usable output of motors furnished are shown. In Canada, nominal motor output is also maximum usable motor output. If motors of comparable output are used, be sure to keep within the service factor limitations outlined on the motor nameplate.

SPECIFICATIONS - GAS HEAT

3 TON | 5 TON

| Model | | 036 060 | 036 060 | 060 |
|--------------------------------------|---------------------|--------------------------|---------------------|-------------------|
| Heat Input Type | | Standard (2 Stage) | Medium (2 Stage) | High (2 Stage) |
| Input Btuh | 1st Stage | 53,000 | 81,000 | 113,000 |
| | 2nd Stage | 70,000 | 108,000 | 150,000 |
| Output Btuh | 2nd Stage | 57,000 | 87,000 | 121,000 |
| Temperature Rise Range - °F | | 15 - 45 | 25 - 55 | 40 - 70 |
| ¹ Thermal Efficiency | | 81% | 81% | 81% |
| Gas Supply Connections | | 3/4 in. NPT | 3/4 in. NPT | 3/4 in. NPT |
| Rec. Gas Supply Pressure - Nat./ LPG | | 7 in. w.g. / 11 in. w.g. | | |
| Gas Supply Pressure | Min./Max. (Natural) | 4.5 - 10.5 in. w.g. | | |
| Range | Min./Max. (LPG) | 10.8 - 13.5 in. w.g. | | |

¹ Thermal Efficiency at full input.

HIGH ALTITUDE DERATE

NOTE - Units may be installed at altitudes up to 2000 ft. above sea level without any modifications.

At altitudes above 2000 ft. units must be derated to match information in the table shown.

036-060 Models - At altitudes above 4500 ft. unit must be derated 2% for each 1000 ft. above sea level..

NOTE - This is the only permissible derate for these units.

| Model | Heat Input Type | Altitude Feet | Gas Manifold Pressure - in. w.g. (min./max.) | | Input Rate Natural Gas Btuh (min./max.) | Input Rate LPG/Propane Btuh (min./max.) |
|------------|--------------------|---------------|---|-------------|---|---|
| | | | Natural Gas | LPG/Propane | | |
| 036 060 | Standard (2 Stage) | 0 - 2000 | 2.0/3.5 | 5.9/10.5 | 53,000 / 70,000 | 53,000 / 70,000 |
| | | 2001 - 4500 | 1.7/3.0 | 5.1/9.0 | 49,000 / 65,000 | 49,000 / 65,000 |
| | Medium (2 Stage) | 0 - 2000 | 2.0/3.5 | 5.9/10.5 | 81,000 / 108,000 | 81,000 / 108,000 |
| | | 2001 - 4500 | 1.7/3.0 | 5.19.0 | 75,000 / 100,000 | 75,000 / 100,000 |
| 060 only | High (2 Stage) | 0 - 2000 | 2.0/3.5 | 5.9/10.5 | 113,000 / 150,000 | 113,000 / 150,000 |
| | | 2001 - 4500 | 1.7/3.0 | 5.1/9.0 | 104,000 / 139,000 | 104,000 / 139,000 |

MINIMUM R454B SPACE AND CFM REQUIREMENTS

| Minimum Airflow ¹ | | |
|------------------------------|------------------------|------------------------|
| Unit | Q _{min} (CFM) | Q _{min} (m³h) |
| SGH036 | 135 | 230 |
| /SGH060 | 142 | 241 |
| SGH036 W/ Humidrol | 145 | 247 |
| SGH060 W/ Humidrol | 140 | 238 |

¹The minimum airflow is the lowest cfm allowed during venting option (leak mitigation)

| Minimum Room Area of Conditioned Space ² | | |
|---|-------------------------|------------------------|
| Unit | TA _{min} (ft²) | TA _{min} (m²) |
| SGH036 | 75.07 | 6.97 |
| SGH060 | 78.74 | 7.31 |
| SGH036 W/ Humidrol | 80.57 | 7.49 |
| SGH060 W/ Humidrol | 77.64 | 7.21 |

² The minimum room area of conditioned space is the smallest area the unit can service.

| Refrigerant Charge R-454B | | |
|---------------------------|----------------------|---------------------|
| Unit | M _c (lbs) | M _c (kg) |
| SGH036 | 5.13 | 2.32 |
| SGH060 | 5.38 | 2.44 |
| SGH036 W/ Humidrol | 5.50 | 2.49 |
| SGH060 W/ Humidrol | 5.30 | 2.40 |

| Altitude Adjustment Factor ³ | | | | | | | | | |
|---|------|------|------|------|------|------|------|------|------|
| Halt | 0 | 200 | 400 | 600 | 800 | 1000 | 1200 | 1400 | 1600 |
| AF | 1 | 1 | 1 | 1 | 1.02 | 1.05 | 1.04 | 1.1 | 1.12 |
| Halt | 1600 | 1800 | 2000 | 2200 | 2400 | 2600 | 2800 | 3000 | 3200 |
| AF | 1.12 | 1.15 | 1.18 | 1.21 | 1.25 | 1.28 | 1.32 | 1.36 | 1.4 |

³ Use the Altitude Adjustment Factor to adjust the values in the table above to different altitudes. Find the relevant altitude above sea level in two "Halt" rows and then multiply the value from the table above by the factor number. Example for a SGH036 at 1000 ft. above sea level, multiply 135 by 1.05 to get 141.75_{min}

BLOWER DATA

DIRECT DRIVE | 3 - 5 TON

SGH036H5E / SGH060H5E BLOWER PERFORMANCE

NOTE - Blower Table Includes Resistance For Base Unit With Gas Heat, Wet Indoor Coil And Air Filters In Place.

MINIMUM AIR VOLUME REQUIRED FOR USE WITH SGH036H MODELS WITH MEDIUM 2 STAGE HEAT OPTION - 1475 CFM

| Air Volume cfm | EXTERNAL STATIC PRESSURE - In. w.g. | | | | | | | | | | | | | | | | | | | |
|----------------------|-------------------------------------|-------|------|-------|------|-------|------|-------|------|-------|------|-------|------|-------|------|-------|------|-------|------|-------|
| | 0.1 | | 0.2 | | 0.3 | | 0.4 | | 0.5 | | 0.6 | | 0.7 | | 0.8 | | 0.9 | | 1.0 | |
| | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts |
| 900 | 1163 | 129 | 1253 | 148 | 1341 | 165 | 1428 | 181 | 1512 | 191 | 1587 | 206 | 1653 | 232 | 1714 | 266 | 1775 | 301 | 1835 | 333 |
| 1000 | 1315 | 129 | 1396 | 152 | 1475 | 174 | 1552 | 195 | 1626 | 216 | 1692 | 242 | 1752 | 277 | 1810 | 316 | 1870 | 351 | 1928 | 382 |
| 1100 | 1463 | 131 | 1531 | 164 | 1599 | 197 | 1666 | 229 | 1730 | 261 | 1791 | 295 | 1850 | 331 | 1907 | 367 | 1964 | 400 | 2021 | 432 |
| 1200 | 1576 | 173 | 1640 | 210 | 1705 | 247 | 1769 | 283 | 1832 | 319 | 1893 | 353 | 1952 | 387 | 2010 | 420 | 2067 | 452 | 2124 | 485 |
| 1300 | 1683 | 225 | 1749 | 263 | 1814 | 300 | 1878 | 337 | 1941 | 372 | 2002 | 407 | 2061 | 441 | 2119 | 474 | 2176 | 507 | 2235 | 538 |
| 1400 | 1796 | 279 | 1862 | 317 | 1927 | 354 | 1991 | 391 | 2054 | 427 | 2114 | 463 | 2173 | 497 | 2231 | 530 | 2289 | 563 | 2345 | 595 |
| 1500 | 1912 | 332 | 1977 | 371 | 2042 | 409 | 2105 | 446 | 2168 | 482 | 2228 | 517 | 2287 | 552 | 2345 | 585 | 2401 | 618 | 2453 | 652 |
| 1600 | 2037 | 368 | 2100 | 410 | 2163 | 452 | 2224 | 492 | 2284 | 532 | 2343 | 570 | 2399 | 607 | 2454 | 643 | 2507 | 679 | 2553 | 716 |
| 1700 | 2161 | 403 | 2221 | 453 | 2280 | 502 | 2338 | 548 | 2393 | 594 | 2445 | 637 | 2496 | 678 | 2545 | 718 | 2592 | 757 | 2633 | 798 |
| 1800 | 2271 | 463 | 2329 | 519 | 2384 | 574 | 2437 | 625 | 2487 | 674 | 2533 | 721 | 2578 | 765 | 2621 | 808 | 2663 | 851 | 2701 | 892 |
| 1900 | 2372 | 545 | 2429 | 602 | 2482 | 657 | 2533 | 709 | 2579 | 758 | 2623 | 805 | 2665 | 850 | 2705 | 893 | 2745 | 936 | 2782 | 977 |
| 2000 | 2475 | 631 | 2530 | 687 | 2582 | 741 | 2631 | 792 | 2676 | 840 | 2718 | 886 | 2758 | 930 | 2797 | 973 | 2836 | 1015 | 2872 | 1056 |
| 2100 | 2582 | 719 | 2635 | 774 | 2684 | 827 | 2731 | 876 | 2774 | 923 | 2814 | 968 | 2853 | 1011 | 2892 | 1054 | 2928 | 1095 | 2964 | 1136 |
| 2200 | 2694 | 811 | 2742 | 863 | 2789 | 914 | 2833 | 962 | 2874 | 1007 | 2913 | 1051 | 2951 | 1094 | 2987 | 1136 | 3023 | 1176 | 3058 | 1216 |
| 2300 | 2807 | 904 | 2852 | 954 | 2896 | 1002 | 2937 | 1048 | 2976 | 1093 | 3013 | 1136 | 3050 | 1177 | 3085 | 1218 | 3119 | 1258 | 3153 | 1298 |
| 2400 | 2921 | 998 | 2963 | 1045 | 3003 | 1091 | 3042 | 1136 | 3079 | 1179 | 3114 | 1220 | 3149 | 1261 | 3183 | 1301 | 3216 | 1341 | 3249 | 1379 |
| Air Volume cfm | 1.1 | | 1.2 | | 1.3 | | 1.4 | | 1.5 | | 1.6 | | 1.7 | | 1.8 | | 1.9 | | 2.0 | |
| | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts | RPM | Watts |
| 900 | 1892 | 364 | 1946 | 393 | 1997 | 422 | 2047 | 449 | 2095 | 476 | 2141 | 501 | 2186 | 524 | 2229 | 546 | 2271 | 569 | 2313 | 592 |
| 1000 | 1983 | 413 | 2036 | 442 | 2086 | 471 | 2136 | 498 | 2184 | 525 | 2232 | 550 | 2278 | 575 | 2322 | 600 | 2364 | 625 | 2403 | 653 |
| 1100 | 2076 | 462 | 2128 | 492 | 2179 | 521 | 2229 | 549 | 2279 | 576 | 2328 | 603 | 2375 | 630 | 2418 | 659 | 2456 | 689 | 2489 | 721 |
| 1200 | 2180 | 516 | 2233 | 546 | 2285 | 575 | 2336 | 604 | 2386 | 632 | 2434 | 660 | 2477 | 690 | 2515 | 721 | 2547 | 755 | 2574 | 791 |
| 1300 | 2291 | 569 | 2343 | 600 | 2392 | 632 | 2437 | 663 | 2482 | 694 | 2524 | 726 | 2562 | 759 | 2595 | 793 | 2623 | 829 | 2648 | 866 |
| 1400 | 2397 | 628 | 2440 | 663 | 2477 | 701 | 2511 | 739 | 2549 | 775 | 2585 | 810 | 2619 | 845 | 2651 | 880 | 2680 | 916 | 2709 | 952 |
| 1500 | 2496 | 690 | 2529 | 732 | 2554 | 776 | 2580 | 820 | 2614 | 858 | 2648 | 895 | 2682 | 931 | 2715 | 965 | 2747 | 1000 | 2779 | 1034 |
| 1600 | 2589 | 758 | 2616 | 803 | 2638 | 851 | 2662 | 895 | 2696 | 932 | 2735 | 958 | 2775 | 977 | 2814 | 996 | 2852 | 1018 | 2887 | 1046 |
| 1700 | 2667 | 841 | 2694 | 886 | 2720 | 931 | 2747 | 974 | 2782 | 1008 | 2825 | 1022 | 2870 | 1026 | 2913 | 1035 | 2951 | 1056 | 2982 | 1096 |
| 1800 | 2736 | 933 | 2769 | 974 | 2801 | 1014 | 2833 | 1054 | 2869 | 1087 | 2911 | 1102 | 2952 | 1115 | 2988 | 1143 | 3015 | 1195 | 3031 | 1277 |
| 1900 | 2818 | 1017 | 2852 | 1055 | 2887 | 1094 | 2921 | 1132 | 2955 | 1167 | 2991 | 1197 | 3023 | 1238 | 3045 | 1303 | 3055 | 1400 | 3053 | 1529 |
| 2000 | 2907 | 1095 | 2942 | 1134 | 2976 | 1173 | 3010 | 1211 | 3043 | 1248 | 3072 | 1295 | 3092 | 1366 | 3100 | 1469 | 3094 | 1608 | 3076 | 1780 |
| 2100 | 2999 | 1175 | 3033 | 1214 | 3067 | 1252 | 3100 | 1290 | 3132 | 1330 | 3155 | 1394 | 3163 | 1494 | 3156 | 1635 | 3134 | 1817 | 3100 | 2032 |
| 2200 | 3092 | 1255 | 3125 | 1294 | 3158 | 1331 | 3191 | 1369 | 3222 | 1411 | 3238 | 1492 | 3235 | 1622 | 3213 | 1801 | 3175 | 2026 | 3124 | 2283 |
| 2300 | 3186 | 1336 | 3218 | 1373 | 3250 | 1411 | 3283 | 1448 | 3312 | 1493 | 3321 | 1590 | 3307 | 1750 | 3270 | 1967 | 3215 | 2234 | 3147 | 2535 |
| 2400 | 3280 | 1417 | 3311 | 1453 | 3342 | 1490 | 3374 | 1526 | 3402 | 1574 | 3405 | 1689 | 3379 | 1878 | 3327 | 2134 | 3256 | 2443 | 3171 | 2787 |

BLOWER DATA

| FACTORY INSTALLED OPTIONS/FIELD INSTALLED ACCESSORY AIR RESISTANCE - in. w.g. | | | |
|---|-------------------------------------|------------|--------------------|
| Air Volume cfm | Humiditrol Dehumidification Coil | Economizer | Filters MERV 13 |
| 036, 060 Size | | | |
| 800 | 0.00 | 0.04 | 0.05 |
| 1000 | 0.00 | 0.04 | 0.07 |
| 1200 | 0.01 | 0.04 | 0.07 |
| 1400 | 0.02 | 0.04 | 0.07 |
| 1600 | 0.03 | 0.04 | 0.07 |
| 1800 | 0.04 | 0.05 | 0.07 |
| 2000 | 0.04 | 0.05 | 0.08 |

ELECTRICAL DATA

DIRECT DRIVE | 3 - 5 TON

| Model | | SGH036H5E | | SGH060H5E | |
|---|------------------------|--------------|--------------|--------------|--------------|
| ¹ Voltage - 60Hz | | 460V-3ph | 575V-3ph | 460V-3ph | 575V-3ph |
| Compressor (Non-Inverter) | Rated Load Amps | 4.6 | 3.5 | 6.5 | 4.8 |
| | Locked Rotor Amps | 39 | 28.9 | 60 | 41 |
| Outdoor Fan Motor | Full Load Amps (2 ECM) | 0.3 | 0.3 | 0.7 | 0.7 |
| | Total | 0.6 | 0.6 | 1.4 | 1.4 |
| Service Outlet 115V GFI (Amps) | | 20 | 20 | 20 | 20 |
| Indoor Blower Motor | HP | 1.5 | 1.5 | 1.5 | 1.5 |
| | Type | Direct (ECM) | Direct (ECM) | Direct (ECM) | Direct (ECM) |
| | Full Load Amps | 2.3 | 2.3 | 2.3 | 2.3 |
| ² Maximum Overcurrent Protection (MOCP) | | 15 | 15 | 15 | 15 |
| ³ Minimum Circuit Ampacity (MCA) | | 9 | 8 | 12 | 10 |

NOTE - All units have a minimum Short Circuit Current Rating (SCCR) of 35kA.

¹ NOTE - Extremes of operating range are plus and minus 10% of line voltage.

² HACR type breaker or fuse.

³ Refer to National or Canadian Electrical Code manual to determine wire, fuse and disconnect size requirements.

SGH036/060 Parts Arrangement




FIGURE 1

SGH036/060 Control Box




FIGURE 2




FIGURE 3

I-UNIT COMPONENTS

| ELECTROSTATIC DISCHARGE (ESD) Precautions and Procedures | |
|---|---|
| ⚠ CAUTION | |
|  | Electrostatic discharge can affect electronic components. Take precautions to neutralize electrostatic charge by touching your hand and tools to metal prior to handling the control. |

SGH units are configured to order units (CTO). The SGH unit components are shown in figure 1 and 2. L1, L2, and L3 wiring is color coded; L1 is red/pink, L2 is yellow, and L3 is blue.

A-Control Box Components

SGH control box components are shown in FIGURE 2. The control box is located in the upper portion of the compressor compartment.

1-Circuit Breaker CB10

All units are equipped with circuit breaker CB10. Circuit breaker CB10 is a toggle switch which can be used by the service technician to disconnect power to the unit.

2-Control Transformer T1 (all units)

All SGH series units use a single line voltage to 24VAC leadless transformer mounted in the control box. Trans-

former supplies power to control circuits in the unit. The transformer is rated at 70VA and is protected by a 3.5 amp circuit breaker (CB8). The 208/230 (Y) voltage transformers use two primary voltage taps, while 460 (G) and 575 (J) voltage transformers use a single primary voltage tap.

3-CAI Transformers T3 (J Voltage units)

All 575 (J) voltage units use one auto voltage to 230VAC transformer mounted in the compressor compartment. The transformer has an output rating of 0.75A. T3 transformer supplies 230 VAC power to combustion air inducer motor (B6).

4-Transformer T43 (all units)

All reheat units and units with phase detection components are equipped with T43 located in the control box. Transformer is rated at 70VA. T43 is connected to line voltage and is powered at all times.

5-Compressor Contactor K1 (all units)

K1 energizes compressor B3 in response to Unit Controller demand. Units use three pole double break contactors with a 24 volt coil.

NOTE-Contactor K1 is energized by the A55 Unit Controller. Refer to the operation sequence for the control system installed. There may be a 5 minute delay depending on the system installed.

6-Transformer T5 (G, J Voltage)

All 460 (G) and 575 (J) voltage units use transformer T5 mounted in the control box. T5 is a line voltage to 230V transformer to power the outdoor fan motors. It is connected to line voltage and is powered at all times.

7-Transformer T4 (J Voltage)

All 575 (J) voltage units use transformer T4 mounted in the control box. T4 is a line voltage to 460V transformer to power the indoor blower. It is connected to line voltage and is powered at all times.

8-Gas Relay K72 (two-stage units)

Relay K72 is normally closed and controls combustion air inducer B6. K72 switches the inducer B6 to high speed in response to two-stage heat demand.

9-Combustion Air Prove Switch S18

The combustion air prove switch S18 is a SPST N.O. pressure switch located in the vestibule area. S18 monitors combustion air inducer operation. Switch S18 is wired to the ignition control A3. The switch closes on a negative pressure fall. This negative pressure fall and switch actuation allows the ignition sequence to continue (proves, by closing, that the combustion air inducer is operating before allowing the gas valve to open.) The combustion air prove switch is factory set and not adjustable. The switch will automatically open on a pressure rise at 0.10 ± 0.05 (24.8 \pm 12.4) (less negative pressure) and close at 0.25 ± 0.05 (62.3 \pm 12.4) The combustion air prove switch is factory set and not adjustable.

10-Unit Controller A55 (all units)

The Unit Controller provides all unit control functions, unit status information, unit diagnostics, programmable parameters, and USB verification and profile sharing. Refer to the Unit Controller guide provided with the unit. Thermostat wires are connected to J297 on the Unit Controller

11- Fuse F57

Fuse F57 is housed in a fuse block which holds two fuses. F57 provides short circuit protection to the T5 transformer

12- Fuse F27

Fuse F27 is housed in a fuse block which holds three fuses. F27 provides short circuit protection to the T4 transformer.

13- Fuse F10

Fuse F10 is housed in a fuse block which holds two fuses. F10 provides Short Circuit Current Rating protection up to 35kA to components connected to F10.

14- Terminal Strip TB13

TB13 terminal block distributes line voltage power to the line voltage items in the unit.

15-Burner Ignition Control A3

The ignition control provides three main functions: gas valve control, ignition and flame sensing. The unit will usually ignite on the first attempt; however, the ignition attempt sequence provides three trials for ignition before locking out. The lockout time is 5 minutes. After lockout the ignition control automatically resets and provides three more attempts at ignition. Manual reset after lockout requires breaking and remaking power to the ignition control. See FIGURE 4 for a normal ignition sequence and FIGURE 5 for the ignition attempt sequence with retries (nominal timings given for simplicity). Specific timings for the ignition controls are shown in FIGURE 6.

Flame rectification sensing is used on all SGH units. Loss of flame during a heating cycle is indicated by an absence or low flame signal (0.09 or less microamps). If this happens, the control will immediately restart the ignition sequence and then lock out if ignition is not gained after the third trial.

The control shuts off gas flow immediately in the event of a power failure. Upon restoration of gas and power, the control will restart the ignition sequence and continue until flame is established or system locks out.

On a heating demand, the ignition control is energized by the Unit Controller A55. The ignition control then allows 30 seconds for the combustion air blower to vent exhaust gases from the burners. When the combustion air blower is purging the exhaust gases, the combustion air prove switch is closing proving that the combustion air blower is operating before allowing the ignition control to energize.

When the combustion air prove switch is closed and the delay is over, the ignition control activates gas valve, the spark electrode and the flame sensing electrode. Sparking stops immediately after flame is sensed. The combustion air blower continues to operate throughout the heating demand. If the flame fails or if the burners do not ignite, the ignition control will attempt to ignite the burners up to two more times. If ignition cannot be obtained after the third attempt, the control will lock out. The ignition control is not adjustable. The main control box houses the burner control A3. See FIGURE 2.




FIGURE 4




FIGURE 5




FIGURE 6




FIGURE 7

The ignition control provides three main functions: gas valve control, ignition, and flame sensing. The control has a green LED to show control status (TABLE 1).

TABLE 1

| LED Flashes | Indicates |
|-------------|--|
| Steady Off | No power or control hardware fault. |
| Steady On | Power applied. Control OK. |
| 3 Flashes | Ignition lockout from too many trials. |
| 4 Flashes | Ignition lockout from too many flame losses within single call for heat. |
| 5 Flashes | Control hardware fault detected. |

Flame rectification sensing is used on all SGH units. Loss of flame during a heating cycle is indicated by an absence of flame signal (0 microamps). If this happens, the control will immediately restart the ignition sequence and then lock out if ignition is not gained after the third trial. See System Service Checks section for flame current measurement.

The control shuts off gas flow immediately in the event of a power failure. Upon restoration of gas and power, the control will restart the ignition sequence and continue until flame is established or system locks out.

Operation

On a heating demand, the ignition control checks for a closed limit switch. Once this check is complete and conditions are correct, the ignition control then allows 30 seconds for the combustion air inducer to vent exhaust gases from the burners. When the combustion air inducer is purging the exhaust gases, the combustion air prove switch closes proving that the combustion air inducer is operating before allowing the ignition control to energize. When the combustion air prove switch is closed and the delay is over, the ignition control activates the gas valve, the spark electrode and the flame sensing electrode. At the start of the ignition sequence, the adjustable 40 second (default) indoor blower delay period begins. Sparking stops immediately after flame is sensed or at the end of the 8 second trial for ignition. If flame is not sensed, the ignition control will wait 5 minutes before attempting ignition again. The unit will usually ignite on the first trial and A3 allows three trials for ignition before locking out. The lockout time is 1 hour. After lockout, the ignition control automatically resets and provides three more attempts at ignition.

Manual reset after lockout requires holding the A55 Unit Controller left arrow key until the Unit Controller resets. See the Unit Controller manual provided with the unit. Once the flame is sensed, the ignition control then proceeds to “steady state” mode where all inputs are monitored to ensure the limit switch, rollout switch and prove switch are closed as well as flame is present. When the heat call is satisfied the gas valve and combustion air inducer are de-energized. An adjustable 120-second (default) blower off delay begins.

B-Cooling Components

See FIGURE 8 for compressor and cooling components. Units are equipped with a draw-through type condenser fan. All units are equipped with direct drive blowers which draw air across the evaporator during unit operation.

Cooling may be supplemented by a factory- or field-installed economizer. The evaporator is slab type and uses a thermostatic expansion valve as the primary expansion device. In all units each compressor is protected by a crankcase heater, high pressure switch and low pressure switch. Additional protection is provided by the low ambient switch and diagnostic sensor.




FIGURE 8

1-Compressors B1 (all units)

SCH units are equipped with with one two-stage scroll compressor. Compressors are supplied by various manufacturers. Compressor electrical specifications vary by manufacturer and type. See SPECIFICATIONS and ELECTRICAL DATA in this manual.

WARNING

Electrical shock hazard. Compressor must be grounded. Do not operate without protective coverover terminals. Disconnect power before removing protective cover. Discharge capacitors before servicing unit. Failure to follow these precautions could cause electrical shock resulting in injury or death.

Compressor B1 is energized by a corresponding compressor contactor.

NOTE-*Refer to the wiring diagram section for specific unit operation.*

2-High Pressure Switch S4

The high pressure switch is an auto-reset SPST N.C. switch which opens on a pressure rise. All SCH units are equipped with this switch. The switch is located in the compressor discharge line. S4 is wired in series with the compressor contactor coil.

When discharge pressure rises to 640 ± 10 psig (4413 ± 69 kPa) (indicating a problem in the system) the switch opens and the compressor is de-energized (the economizer can continue to operate). When discharge pressure drops to 475 ± 20 psig (3275 ± 138 kPa) the pressure switch will close.

Main control A55 has a three-strike counter before locking out. This means the control will allow three high pressure trips per one thermostat demand. The control can be reset by breaking and remaking the thermostat demand or manually resetting the control.

3-Low Pressure Switch S87

The low pressure switch is an auto-reset SPST N.O. switch (held N.C. by refrigerant pressure) which opens on a pressure drop. All units are equipped with this switch. The switch is located in the compressor suction line. S87 is wired directly to the main control module A55. The main control module A55 governs the low pressure switches by shunting the switches during start up until pressure is stabilized.

After the shunt period, the control has a three-strike counter during first thermostat demand before the compressor is locked out. The control is reset by breaking and remaking the thermostat demand or manually resetting the control.

When suction pressure drops to 40 ± 5 psig (276 ± 34 kPa) (indicating low pressure), the switch opens and the compressor is de-energized. The switch automatically resets when pressure in the suction line rises to 90 ± 5 psig (620 ± 34 kPa).

4-Filter Drier

SGH units have a filter drier located in the liquid line of the refrigerant circuit upstream of the TXV in the blower compartment. The drier removes contaminants and moisture from the system.

5-Condenser Fans B4 & B5

Units are equipped with electronically commutated condenser fan motors (ECM). The ECM motors are wired directly to 230VAC power. The motors do not operate until a pulse width modulated (PWM) control signal is sent from the A55 Unit Controller. The PWM signal determines the condenser fan speed. Fans B4 and B5 run on low speed with a Y1 demand and on high speed with a Y2 demand. Both low and high voltage plugs are located in the control compartment in the indoor section of the unit. Condenser fan motors B4 & B5 high voltage plugs are J86 & J87 respectively. Low voltage plugs are J336 & J337 respectively. Refer to wiring diagrams to identify plugs.

If an ECM fan is not operating

- 1 - Using a VAC meter, check the high voltage at the appropriate motor plug (J86 or J87). High voltage must be present before checking for low voltage.
- 2 - Using the duty cycle (%) or a VDC meter setting, check for low voltage (J336 or J337) from the unit controller.

NOTE - *The VDC reading may fluctuate. This is normal for a PWM signal.*

6-Crankcase Heater HR1 & Thermostat S40

The compressor is protected by a crankcase heater HR1 and thermostat S40. The purpose of the crankcase heater is to prevent liquid from accumulating in the compressor. The crankcase heater and compressor never run at the same time. Thermostat S40 is located on the compressor discharge line and will open when discharge line temperature reaches 94° , de-energizing HR1. Once temperature drops down to 74° the thermostat closes energizing HR1.

7-Temperature Thermistor

RT46 and RT48

Units are equipped with two factory-installed thermistors (RT46 and RT48) located on different points on the refrigerant circuit.

The thermistors provide the Unit Controller with constant temperature readings of two specific locations on the refrigeration circuit. These temperatures are used as feedback in certain modes of unit operation. In addition, the Unit Controller uses these temperatures to initiate alarms such as loss of condenser or evaporator airflow and loss of charge.

The SGH036 and 060 units use the RT46 sensor on the indoor evaporator coil, and the RT48 sensor on the outdoor condenser coil. Each thermistor must be specifically placed for proper unit operation and to initiate valid alarms. See TABLE 2 for proper locations.

TABLE 2

| THERMISTOR LOCATION | | |
|-----------------------|--------|-----------|
| Unit | Sensor | Figure |
| 036, 060 Indoor Coil | RT46 | FIGURE 9 |
| 036, 060 Outdoor Coil | RT48 | FIGURE 10 |




FIGURE 9

SGH/SCH036, 060
CONDENSER COIL
RT48




FIGURE 10

8-RDS Sensors RT58, RT59

Units are equipped with factory-installed RDS Sensors located on different points on the unit. The RDS sensors provide the Unit Controller with continuous readings for leaked refrigerant concentration levels and sensor health status (Good or Fault). These readings are used to modify unit operation to disperse the leaked refrigerant and to remove possible ignition sources. In addition, the Unit Controller uses these readings to initiate alarms to alert the operator of a refrigerant leak or faulty sensor(s). Refrigerant Sensors and Detection Systems shall only be replaced with approved parts from the manufacturer.

Each sensor must be specifically placed for proper unit operation and to initiate valid alarms. To identify sensor locations see TABLE 3.

TABLE 3
RDS Sensor Figures

| Model | Qty. | Type | Figure |
|------------|-----------|------------------------|-----------|
| SGH036/060 | 2 sensors | RT58 INDOOR SENSOR | FIGURE 11 |
| | | RT59 COMPRESSOR SENSOR | FIGURE 12 |




FIGURE 11




FIGURE 12

C-Blower Compartment

The blower housing can be removed for cleaning and inspection. In addition, removing blower allows access to the heat exchanger tubes for inspection.

Line and low voltage make-up in all models is located in the upper corner of the blower compartment. Electrical entrance is made through the base pan of the unit or through the corner mullion for horizontal position units. Low voltage connections can be accessed by removing the blower compartment front panel. High voltage can be accessed through the makeup box cover on corner mullion.

In all models, the evaporator coil, expansion valve and drain pan can be accessed by removing the blower compartment end panel.

1-Blower Wheel (all units)

Units are equipped with a direct drive blower assembly with a backward inclined blower wheel.

2-Indoor Blower Motor B3 (all units)

Units are equipped with a direct drive blower assembly with a three-phase, variable speed, direct drive blower motor.

IMPORTANT

Three phase scroll compressors must be phased sequentially for correct compressor and blower rotation.

Follow "COOLING START-UP" section of installation instructions to ensure proper compressor and blower operation.

A-Blower Operation

Direct Drive Units - To check for proper voltage phasing, measure compressor suction and discharge pressures. Make sure suction pressure decreases and discharge pressure increases on start-up. Checking blower rotation is not a valid method of determining voltage phasing for incoming power.

Units Equipped With Factory-Installed Voltage or Phase Detection -

The Unit Controller checks the incoming power during start-up (A55 P394-1 and P394-02). If the voltage, phase, or frequency is incorrect, the Unit Controller will display an alarm and the unit will not start. After line voltage is corrected, the Unit Controller will energize the unit after five (default) minutes.

While line voltage is continually checked by the Unit Controller, the voltage phasing is not. If one or more phases is interrupted, power to one or more transformers is interrupted and the unit is shut down by either the Unit Controller or the corresponding transformer.

Initiate blower demand at thermostat according to instructions provided with thermostat. Unit will cycle on thermostat demand.

- 1 - Blower operation is manually set at the thermostat subbase fan switch. With fan switch in ON position, blowers will operate continuously.
- 2 - With fan switch in AUTO position, the blowers will cycle with demand. Blowers and entire unit will be off when system switch is in OFF position.

B-Blower Access

- 1 - Loosen the reusable wire tie which secures the controls and high voltage blower wiring to the blower housing.
- 2 - Remove and retain screws in front and on either side of blower housing. Pull frame toward outside of unit. See FIGURE 13.
- 3 - Slide frame back into original position when finished servicing. Reattach the blower wiring in the previous location on the blower housing using the wire tie.
- 4 - Replace retained screws in front and on either side of the blower housing.

C-Determining Unit CFM

- 1 - Measure the indoor blower motor RPM. Air filters must be in place when measurements are taken.
- 2 - With all access panels in place, measure static pressure external to unit (from supply to return). Blower performance data is based on static pressure taken in locations shown in FIGURE 14.

NOTE - Static pressure readings can vary if not taken where shown.

- 3 - Referring to BLOWER DATA tables (table of contents), use static pressure and RPM readings to determine unit CFM.

DIRECT DRIVE BLOWER ASSEMBLY (SG / SC 036 & 060)





FIGURE 13

LOCATION OF STATIC PRESSURE READINGS

INSTALLATIONS WITH DUCTWORK



INSTALLATIONS WITH CEILING DIFFUSERS




FIGURE 14

D-GAS HEAT COMPONENTS

SGH036/060 units are available in Standard 2 Stage - 70 kBtuh and Medium 2 Stage - 108 kBtuh heat sizes. SGH060 has an additional High 2 Stage - 150 kBtuh heat size. All heat sizes come standard with Low NOx inserts

1-Heat Exchanger (FIGURE 15)

SGH units use aluminized steel inshot burners with matching tubular aluminized or optional stainless steel heat exchangers and a two-stage redundant gas valve. SGH036 units use either a 3 (70 kBtuh) or 5 (108 kBtuh) tube/burner assembly. SGH060 units use either a 3 (70 kBtuh), 5 (108 kBtuh), or 7 (150 kBtuh) tube/burner assembly. Each burner uses a burner venturi to mix gas and air for proper combustion. Combustion takes place at each tube entrance. As hot combustion gases are drawn upward through each tube by the combustion air blower, exhaust gases are drawn out the top and fresh air/gas mixture is drawn in at the bottom. Heat is transferred to the air stream from all surfaces of the heat exchanger tubes. The supply air blower, controlled by the main control panel A55, force air across all surfaces of the tubes to extract the heat of combustion.

The shape of the tubes ensures maximum heat exchange. The gas valve accomplishes staging by allowing more or less gas to the burners as called for by heating demand.

2-Primary High Temperature Limit S10

S10 is the primary high temperature limits for gas heat. Primary limit S10 is wired in series to the main control panel A55 which energizes burner control (A3). Its N.C. contacts open to de-energize the ignition control when excessive temperature is reached in the blower compartment.

3-Flame Rollout Limit S47

Flame rollout limit S47 is a SPST N.C. high temperature limit located just above the burner air intake opening in the burner enclosure. See figure 14. S47 is wired to the main control panel A55. When S47 senses flame rollout (indicating a blockage in the combustion air passages), the flame rollout limit trips, and the ignition control immediately closes the gas valve.

Limit S47 is factory preset to open at $350F \pm 14F$ ($177C \pm 7.7C$) on a temperature rise. All flame rollout limits are manual reset.




FIGURE 15

4-Burner Assembly (FIGURE 16)

The burners are controlled by the spark electrode, flame sensing electrode, gas valve and combustion air blower. The spark electrode, flame sensing electrode and gas valve are directly controlled by ignition control. Ignition control and combustion air blower is controlled by main control panel A55.




FIGURE 16

Burners

All units use inshot burners. Burners are factory set and do not require adjustment. A peep hole with cover is furnished in the heating access panel for flame viewing. Always operate the unit with the access panel in place. Burners can be removed individually for service. Burner maintenance and service is detailed in the SERVICE CHECKS sections of this manual.

Orifice

Each burner uses an orifice which is precisely matched to the burner input. The orifice is threaded into the manifold and supports the burner. Remove the two screws securing the burner and slide off of the orifice for service.

NOTE- Do not use thread sealing compound on the orifices. Using thread sealing compound may plug the orifices.

Each orifice and burner are sized specifically to the unit. Refer to Lennox Repair Parts Listing for correct sizing information.

5-Combustion Air Inducer B6

Combustion air inducer B6 provides fresh air to the burners while clearing the combustion chamber of exhaust gases. The inducer begins operating immediately upon receiving a thermostat demand and is de-energized immediately when thermostat demand is satisfied.

On a heating demand (W1), the A55 Unit Controller through the ignition control A3 initiates the heating cycle. A3 then allows 30 seconds for the combustion air inducer to vent exhaust gases from the burners. When the combustion air inducer is purging the exhaust gases, the combustion air prove switch closes, proving that the combustion air inducer is operating before allowing the ignition sequence to continue.

When the combustion air prove switch is closed (See Control Panel Components for S18 Prove Switch) and the delay is over, the A55 Unit Controller through the ignition control activates the appropriate stage operator of the gas valve, the spark and the flame sensing electrode. Sparking stops immediately after flame is sensed or at the end of the eight second trial for ignition. On two stage natural gas units the inducer will operate on low speed for first stage heat (W1) and ramp up to high speed for second stage heat (W2).

The inducer uses a 208/230V or 460V single-phase PSC motor and a 5.24in. x 0.96in. (120mm x 33.3mm) blower wheel. The motor operates at 3300RPM and is equipped with auto-reset overload protection. Two-speed units have reduced RPM for low speed.

Blowers are supplied by various manufacturers. Ratings may vary by manufacturer. Specific blower electrical ratings can be found on the unit rating plate.

The combustion air inducer motors in all SGH units require run capacitors. Capacitor C3 is connected to combustion air inducer B6. Ratings will be on side of capacitor or combustion air motor nameplate.

All inducer motors are sealed and cannot be oiled. The blower cannot be adjusted but can be disassembled for cleaning.

6-Gas Valve GV1

Gas valve GV1 is a two stage redundant gas valve used in all SGH units.. First stage (low fire) is quick opening (on and off in less than 3 seconds). Second stage is quick opening. On a call for first stage heat (low fire), the valve is energized by the ignition control simultaneously with the spark electrode. On a call for second stage heat (high fire), the second stage operator is energized directly from A55. The valve is adjustable for both high fire and low fire. A manual shut-off lever is provided on the valve for shut-off. Manual shut-off lever immediately closes both stages without delay. FIGURE 17 shows gas valve components..




FIGURE 17

7-Spark Electrodes

An electrode assembly is used for ignition spark. The electrode is mounted through holes on the right end of the burner support. The electrode tip protrudes into the flame envelope of the adjacent burner. The electrode assembly is fastened to burner supports and can be removed for service without removing any part of the burners.

During ignition the spark electrode ignites the right burner. See FIGURE 18. Flame travels from burner to burner until all are lit.

The spark electrode is connected to the ignition control by a 8 mm silicone-insulated stranded high voltage wire. The wire uses 1/4" (6.35 mm) female quick connect on the electrode end and female spark plug-type terminal on the ignition control end.

NOTE- In order to maximize spark energy to electrode, high voltage wire should touch unit cabinet as little as possible.

8-Flame Sensors

A flame sensor is located on the left side of the burner box. See FIGURE 19. The sensor is mounted through a hole in the burner support and the tip protrudes into the flame envelope of the right most burner. The sensor assembly is fastened to burner supports and can be removed for service without removing any part of the burners.




FIGURE 18




FIGURE 19

When flame is sensed by the flame sensor (indicated by microamp signal through the flame) sparking stops immediately. During operation, flame is sensed by current passed along the ground electrode (located on the spark electrode), through the flame and into the sensing electrode. The ignition control allows the gas valve to stay open as long as a flame signal (current passed through the flame) is sensed.

II-PLACEMENT AND INSTALLATION

Make sure the unit is installed in accordance with the installation instructions and all applicable codes. See accessories section for conditions requiring use of the optional roof mounting frame (S1CURB1101).

III-CHARGING and START UP

A-Preliminary and Seasonal Checks

- 1 - Make sure that unit is installed in accordance with the installation instructions and applicable codes.
- 2 - Inspect all electrical wiring, both field and factory installed, for loose connections. Tighten as required.
- 3 - Check to ensure that refrigerant lines do not rub against the cabinet or against other refrigerant lines.
- 4 - Check voltage at disconnect switch. Voltage must be within range listed on nameplate. If not, consult power company and have voltage condition corrected before starting unit.
- 5 - Refer to unit diagram located on inside of compressor access door for unit wiring.
- 6 - Adjust blower belt according to "Blower Operation and Adjustments" section.
- 7 - Make sure filters are in place before start-up.

B-Refrigerant Charge and Check - All-Aluminum Coil

WARNING-Do not exceed nameplate charge under any condition.

This unit is factory charged and should require no further adjustment. If the system requires additional refrigerant, reclaim the charge, evacuate the system, and add required nameplate charge.

| Refrigerant Charge R-454B | | |
|---------------------------|----------------------|---------------------|
| Unit | M _c (lbs) | M _c (kg) |
| SGH036 | 5.13 | 2.32 |
| SGH060 | 5.38 | 2.44 |
| SGH036 W/ Humidrol | 5.50 | 2.49 |
| SGH060 W/ Humidrol | 5.30 | 2.40 |

When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice be followed and, since flammability is a consideration, the following procedure shall be adhered to:

- Safely remove refrigerant following local and national regulations,
- Evacuate the circuit,
- Purge the circuit with inert gas,
- Evacuate,
- Purge with inert gas,
- Open the circuit

The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems. Refrigerant purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system. When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and that ventilation is available.

In addition to conventional charging procedures, the following requirements shall be followed.

- Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
- Cylinders shall be kept in an appropriate position according to the instructions.
- Ensure that the refrigerating unit is earthed prior to charging the system with refrigerant.
 - Label the system when charging is complete (if not already).
 - Extreme care shall be taken not to overfill the refrigerating unit.

Prior to recharging the system, it shall be pressure-tested with the appropriate purging gas. The system shall be leak-tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely. When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i. e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

NOTE - System charging is not recommended below 60°F (15°C). In temperatures below 60°F (15°C), the charge must be weighed into the system.

If weighing facilities are not available, or to check the charge, use the following procedure:

IMPORTANT - Charge unit in standard cooling mode.

- 1 - Make sure outdoor coil is clean. Attach gauge manifolds and operate unit at full CFM in cooling mode with economizer disabled until system stabilizes (approximately five minutes). Make sure all outdoor air dampers are closed.
- 2 - Compare the normal operating pressures to the pressures obtained from the gauges. Check unit components if there are significant differences.
- 3 - Measure the outdoor ambient temperature and the suction pressure. Refer to the charging curve to determine a target liquid temperature.

Note - Pressures are listed for sea level applications.

- 4 - Use the same thermometer to accurately measure the liquid temperature (in the outdoor section).
 - If measured liquid temperature is higher than the target liquid temperature, add refrigerant to the system.
 - If measured liquid temperature is lower than the target liquid temperature, recover some refrigerant from the system.
- 5 - Add or remove charge in increments. Allow the system to stabilize each time refrigerant is added or removed.
- 6 - Continue the process until measured liquid temperature agrees with the target liquid temperature. Do not go below the target liquid temperature when adjusting charge. Note that suction pressure can change as charge is adjusted.
- 7 - Example: At 95°F outdoor ambient and a measured suction pressure of 130psig, the target liquid temperature is 97°F. For a measured liquid temperature of 106°F, add charge in increments until measured liquid temperature agrees with the target liquid temperature.

TABLE 4


| SG/SC 036 Normal Operating Pressures - No Reheat - 581193-01 | | | | | | | | | | | |
|---|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| Outdoor Coil Entering Air Temperature | | | | | | | | | | | |
| 65°F | | 75°F | | 85°F | | 95°F | | 105°F | | 115°F | |
| Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) |
| 107 | 220 | 110 | 256 | 112 | 297 | 114 | 342 | 116 | 392 | 117 | 447 |
| 116 | 222 | 118 | 259 | 121 | 300 | 123 | 345 | 125 | 396 | 126 | 451 |
| 134 | 227 | 136 | 264 | 139 | 306 | 141 | 352 | 143 | 403 | 145 | 459 |
| 153 | 232 | 155 | 270 | 158 | 312 | 160 | 359 | 163 | 411 | 165 | 467 |

TABLE 5

| SG/SC 036 Normal Operating Pressures - Reheat - 581194-01 | | | | | | | | | | | |
|--|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| Outdoor Coil Entering Air Temperature | | | | | | | | | | | |
| 65°F | | 75°F | | 85°F | | 95°F | | 105°F | | 115°F | |
| Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) |
| 107 | 220 | 110 | 256 | 112 | 297 | 114 | 342 | 116 | 392 | 117 | 447 |
| 116 | 222 | 118 | 259 | 121 | 300 | 123 | 345 | 125 | 396 | 126 | 451 |
| 134 | 227 | 136 | 264 | 139 | 306 | 141 | 352 | 143 | 403 | 145 | 459 |
| 153 | 232 | 155 | 270 | 158 | 312 | 160 | 359 | 163 | 411 | 165 | 467 |

SG/SC 036 - No Reheat

OD Temp (°F)



SC/SG 036 - Reheat

OD Temp (°F)






TABLE 6

| SG/SC 060 Normal Operating Pressures - No Reheat - 581195-01 | | | | | | | | | | | |
|--|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| Outdoor Coil Entering Air Temperature | | | | | | | | | | | |
| 65°F | | 75°F | | 85°F | | 95°F | | 105°F | | 115°F | |
| Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) |
| 100 | 229 | 103 | 265 | 106 | 306 | 108 | 352 | 110 | 404 | 112 | 462 |
| 107 | 230 | 110 | 266 | 114 | 308 | 116 | 354 | 119 | 406 | 121 | 464 |
| 122 | 236 | 127 | 272 | 130 | 313 | 134 | 360 | 137 | 412 | 140 | 470 |
| 139 | 243 | 144 | 280 | 149 | 322 | 153 | 369 | 157 | 421 | 161 | 479 |

TABLE 7

| SG/SC 060 Normal Operating Pressures - Reheat - 581196-01 | | | | | | | | | | | |
|---|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| Outdoor Coil Entering Air Temperature | | | | | | | | | | | |
| 65°F | | 75°F | | 85°F | | 95°F | | 105°F | | 115°F | |
| Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) | Suct (psig) | Disc (psig) |
| 100 | 229 | 103 | 265 | 106 | 306 | 108 | 352 | 110 | 404 | 112 | 462 |
| 107 | 230 | 110 | 266 | 114 | 308 | 116 | 354 | 119 | 406 | 121 | 464 |
| 122 | 236 | 127 | 272 | 130 | 313 | 134 | 360 | 137 | 412 | 140 | 470 |
| 139 | 243 | 144 | 280 | 149 | 322 | 153 | 369 | 157 | 421 | 161 | 479 |





C-Cooling Start Up

IMPORTANT-The crankcase heater must be energized for 24 hours before attempting to start compressor. Set thermostat so there is no demand to prevent compressor from cycling. Apply power to unit.

- 1 - Set fan switch to AUTO or ON and move system selection switch to cool. Adjust thermostat to a setting below room temperature to bring on the compressor. Compressor will start and cycle on demand from thermostat.
- 2 - The refrigerant circuit is charged with R-454B refrigerant. See unit rating plate for type of refrigerant and correct amount of charge.
- 3 - Refer to Cooling Operation and Adjustment section for proper method to check refrigerant charge.

Three Phase Scroll Compressor Voltage Phasing

Three phase scroll compressors must be phased sequentially to ensure correct compressor and blower rotation and operation. Compressor and blower are wired in phase at the factory

- 1 - Observe suction and discharge pressures and blower rotation on unit start-up.
- 2 - Suction pressure must drop, discharge pressure must rise, and blower rotation must match rotation marking.

If pressure differential is not observed or blower rotation is not correct:

- 3 - Disconnect all remote electrical power supplies

- 4 - Reverse any two field-installed wires connected to the line side of S48 disconnect, CB10 circuit breaker, or TB2 terminal strip.

- 5 - Make sure the connections are tight.

Discharge and suction pressures should operate at their normal start-up ranges.

R-454B Refrigerant

Units charged with R-454B refrigerant operate at much higher pressures than R-22. The expansion valve and liquid line drier provided with the unit are approved for use with R-454B. Do not replace them with components designed for use with R-22.

R-454B refrigerant is stored in a *blank* cylinder.

Manifold gauge sets used with systems charged with R-454B refrigerant must be capable of handling the higher system operating pressures. The gauges should be rated for use with pressures of 0-800 on the high side and a low side of 30" vacuum to 250 psi with dampened speed to 500 psi. Gauge hoses must be rated for use at up to 800 psi of pressure with a 4000 psi burst rating.

IMPORTANT

Mineral oils are not compatible with R-454B. If oil must be added, it must be a polyol ester oil.

D-Heating Start-Up

FOR YOUR SAFETY READ BEFORE LIGHTING

BEFORE LIGHTING smell all around the furnace area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

Use only your hand to push the gas control lever. Never use tools. If the lever will not move or turn by hand, do not try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.

This unit is equipped with an automatic spark ignition system. There is no pilot. In case of a safety shutdown, move thermostat switch to OFF and return the thermostat switch to HEAT to reset ignition control.

⚠ WARNING

Danger of explosion. Can cause injury or death. Do not attempt to light manually. Unit has a direct spark ignition system.

⚠ WARNING

Danger of explosion. Can cause injury or product or property damage. Should the gas supply fail to shut off or if overheating occurs, shut off the gas valve to the furnace before shutting off the electrical supply.

⚠ WARNING

Do not use this furnace if any part has been under water. A flood-damaged furnace is extremely dangerous. Attempts to use the furnace can result in fire or explosion. A qualified service agency should be contacted to inspect the furnace and to replace all gas controls, control system parts, electrical parts that have been wet or the furnace if deemed necessary.

⚠ WARNING

SMOKE POTENTIAL

The heat exchanger in this unit could be a source of smoke on initial firing. Take precautions with respect to building occupants and property. Vent initial supply air outside when possible.

Placing Unit In Operation

⚠ WARNING

Danger of explosion and fire. Can cause injury or product or property damage. You must follow these instructions exactly.

Gas Valve Operation for Honeywell VR8305Q (FIGURE 20)




FIGURE 20

- 1 - Set thermostat to lowest setting.
- 2 - Turn off all electrical power to furnace.
- 3 - This furnace is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.
- 4 - Open or remove the heat section access panel.
- 5 - Move the lever on the gas valve to OFF. Do not force.
- 6 - Wait five (5) minutes to clear out any gas. If you then smell gas, STOP! Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions. If you do not smell gas, go to the next step.
- 7 - Move the lever on the gas valve to ON. Do not force.
- 8 - Close or replace the heat section access panel.
- 9 - Turn on all electrical power to furnace.
- 10 - Set thermostat to desired setting.
- 11 - The combustion air inducer will start. The burners will light within 40 seconds.
- 12 - If the furnace does not light the first time (gas line not fully purged), it will attempt up to two more ignitions before locking out.
- 13 - If lockout occurs, repeat steps 1 through 10.
- 14 - If the furnace will not operate, follow the instructions "Turning Off Gas to Furnace" and call your service technician or gas supplier.

Turning Off Gas to Furnace

- 1 - If using an electromechanical thermostat, set to the lowest setting.
- 2 - Before performing any service, turn off all electrical power to the furnace.
- 3 - Open or remove the heat section access panel.
- 4 - Move the lever on the gas valve to OFF.
- 5 - Replace heat section access panel.

IV- SYSTEMS SERVICE CHECKS

A-SGH Heating System Service Checks

All SGH units are ETL and CSA design certified without modification.

Before checking piping, check with gas company or authorities having jurisdiction for local code requirements. Refer to the SGH Installation, Operation and Adjustments instruction for more information.




FIGURE 21

1-Gas Piping

Gas supply piping must not allow more than 0.5"W.C. (124.3 Pa) drop in pressure between the gas meter and the unit. Supply gas pipe must not be smaller than the unit gas connection. Refer to installation instructions for details.

2-Testing Gas Piping

NOTE-In case emergency shutdown is required, turn off the main manual shut-off valve and disconnect the main power to the unit. These controls should be properly labeled by the installer.

When pressure testing gas lines, the gas valve must be disconnected and isolated. Gas valves can be damaged if subjected to more than 0.5 psig [14"W.C. (3481 Pa)]. See FIGURE 21.

When checking piping connection for gas leaks, use the preferred means. Common kitchen detergents can cause harmful corrosion on various metals used in gas piping. The use of specialty Gas Leak Detector is strongly recommended. It is available through Lennox under part number 31B2001.

Do not use matches, candles, flame or any other source of ignition to check for gas leaks.

3-Testing Gas Supply Pressure

When testing gas supply pressure, connect test gauge to the inlet pressure tap (field provided - FIGURE 21). Test supply gas pressure with unit firing at maximum rate (both stages energized).

Make sure the reading falls within the range of the following values. Low pressure may result in erratic operation or "underfire." High pressure can result in permanent damage to the gas valve or "overfire." Operating pressure at the unit gas connection must be within ranges shown in TABLE 8.

TABLE 8

| Operating Pressures @ Unit Gas Connection | |
|---|------------|
| Natural Gas | LP/Propane |
| 4.7"-10.5 | 11.0"-13.0 |

On multiple unit installations, each unit should be checked separately while operating at maximum rate, beginning with the one closest to the supply gas main and progressing to the one furthest from the main. Multiple units should also be tested with and without the other units operating. Supply pressure must fall within the range listed in the previous paragraph.

4-Check and Adjust Manifold Pressure

After line pressure has been checked and adjusted, check manifold pressure. Move test gauge to the manifold outlet pressure tap located on unit gas valve GV1. See FIGURE 20 for location of pressure tap on the gas valve.

The manifold pressure is factory set and should not require adjustment. If manifold pressure is incorrect and attempts to adjust fail, the valve must be replaced. Refer to FIGURE 20 for location of gas valve (manifold pressure) adjustment screw.

See TABLE 9 for normal operating manifold pressure. The valve is adjustable for both high fire and low fire.

All gas valves are factory adjusted. The gas valve should complete and immediately cycle off in the event of gas or power failure. The manual shut-off knob can be used to immediately shut off gas supply.

TABLE 9

| Operating Manifold Pressure | | | |
|-----------------------------|--------------------|--------------------|---------------------|
| Natural | | LP | |
| Low | High | Low | High |
| 2.0 ± 0.3" W.C. | 3.5 ± 0.3" W.C. | 5.9 ± 0.3" W.C. | 10.5 ± 0.5" W.C. |

⚠ CAUTION

For safety, connect a shut-off valve between the manometer and the gas tap to permit shut off of gas pressure to the manometer.

Manifold Adjustment Procedure

- 1 - Connect test gauge to the outlet pressure tap on the gas valve. Start the unit (call for second stage heat) and allow five minutes for the unit to reach steady state.
- 2 - While waiting for the unit to stabilize, notice the flame. The flame should be stable without flashback and should not lift from the burner heads. Natural gas should burn basically blue with some clear streaks. L.P. gas should burn mostly blue with some clear yellow streaks.
- 3 - After allowing the unit to stabilize for five minutes, record the manifold pressure and compare to the values given for gas supply pressure (above).

⚠ IMPORTANT

Disconnect heating demand as soon as an accurate reading has been obtained.

5-Proper Gas Flow

- 1 - Operate unit at least 15 minutes before checking gas flow. Determine the time in seconds for two revolutions of gas through the meter. (Two revolutions assures a more accurate time).
- 2 - Divide the number of seconds by two and compare to the time in TABLE 10. If manifold pressure is correct and rate is incorrect, check gas orifices for proper size and restriction.
- 3 - Remove temporary gas meter if installed.

NOTE- To obtain accurate reading, shut off all other gas appliances connected to meter.

6-High Altitude Derate

NOTE - Units may be installed at altitudes up to 2000 ft. above sea level without any modifications.

At altitudes above 2000 ft. units must be derated to match information in TABLE 11. At altitudes above 4500 ft. unit must be derated 2% for each 1000 ft. above sea level.

NOTE- This is the only permissible derate for these units.

7-Inshot Burner

Periodically examine burner flames for proper appearance during the heating season. Before each heating season examine the burners for any deposits or blockage which may have occurred.

- 1 - Turn off both electrical power and gas supply to unit.
- 2 - Open burner compartment access panel.
- 3 - Remove and retain screws securing burner box top cap.

TABLE 10

| GAS METER CLOCKING CHART | | | | |
|--------------------------|----------------------------|-------------------|--------------|--------------|
| Unit Input Rate (Btuh) | Seconds for One Revolution | | | |
| | Natural | | LP/Propane | |
| | 1 cu ft Dial | 2 cu ft Dial | 1 cu ft Dial | 2 cu ft Dial |
| 75,000 | 48 | 96 | 120 | 240 |
| 105,000 | 34 | 69 | 86 | 171 |
| 125,000 | 29 | 58 | 72 | 144 |
| 130,000 | 28 | 55 | 69 | 138 |
| 150,000 | 24 | 48 | 60 | 120 |
| 180,000 | 20 | 40 | 50 | 100 |
| 240,000 | 15 | 30 | 38 | 75 |
| 260,000 | 14 | 28 | 35 | 69 |
| 360,000 | 10 | 20 | 25 | 50 |
| 480,000 | 8 | 15 | 19 | 38 |
| Natural-1000 btu/cu ft | | LP-2500 btu/cu ft | | |

Note: Table assumes standard temperature (60°F), pressure (30in.Hg.) and fuel heating values (Btuh/Ft.3). Apply pressure corrections in altitudes above 2000 ft.

TABLE 11

| Model | Altitude-ft. | Gas Manifold Pressure in. w.g. | |
|-------|--------------|--------------------------------|------------|
| | | Natural | LP/Propane |
| 036 | 2001-4500 | 3.4 | 9.0 |
| 060 | 2001-4500 | 1.6 - 3.4 | 5.5-9.0 |

8-Heat Exchanger

To Access or Remove Heat Exchanger From Unit:

- 1 - Turn off gas and electric power.
- 2 - Remove access panel(s) and unit center mullions.
- 3 - Disconnect combustion air blower. Draw wires through divider panel to allow for clearance of vest panel. Remove access panel(s) and unit center mullions.
- 4 - Remove screws supporting heat exchanger.
- 5 - To install heat exchanger, reverse procedure. Be sure to secure all wires and check plumbing and burner plate for airtight seal. Screws must be torqued to 35 in.-lbs. (4N.m) to ensure proper operation. Re-caulk corners of vest panel

9-Flame Sensing

Flame current is an electrical current which passes from the ignition control through the sensor electrode during unit operation.

The current passes from the sensor through the flame to the ground to complete a safety circuit. The electrodes should be located so the tips are at least 1/2" (12.7 mm) inside the flame envelope. Do not bend electrodes. To measure flame current, follow the procedure below:

WARNING



Electric shock hazard. Electrodes are not field-adjustable. Any alterations to the electrode can cause injury, death, or property damage.

- 1 - Disconnect power to unit.
- 2 - Remove lead from sensing electrode and install a 0-50 DC microamp meter in series between the sensing electrode and the sensing lead.
- 3 - Reconnect power and adjust thermostat for heating demand.
- 4 - After flame is established signal should be 0.5 to 1.0 . Drop out signal is 0.09.
- 5 - Disconnect power to unit before disconnecting meter. Make sure sensor wire is securely reconnected before reconnecting power to unit.

NOTE-If the meter scale reads 0, the leads are reversed. Disconnect power and reconnect leads for proper polarity.

10-Combustion Air Inducer

A combustion air proving switch checks combustion air inducer operation before allowing power to the gas controller.

Gas controller will not operate if inducer is obstructed. Under normal operating conditions, the combustion air blower wheel should be checked and cleaned prior to the heating season.

However, it should be examined periodically during the heating season to establish an ideal cleaning schedule. With power supply disconnected, the condition of the blower wheel can be determined by looking through the vent opening.

Cleaning Combustion Air Inducer

- 1 - Shut off power supply and gas to unit.
- 2 - Disconnect pressure switch air tubing from combustion air inducer port.
- 3 - Remove and retain screws securing combustion air inducer to flue box. Remove and retain two screws from bracket supporting vent connector. See FIGURE 22.
- 4 - Clean blower wheel blades with a small brush and wipe off any dust from housing. Clean accumulated dust from front of flue box cover.
- 5 - Return combustion air blower motor and vent connector to original location and secure with retained screws. It is recommended that the combustion air inducer gasket be replaced during reassembly.
- 6 - Clean combustion air inlet louvers on heat access panel using a small brush.

COMBUSTION AIR INDUCER CLEANING




FIGURE 22

E-Flue Passageway and Flue Box

- 1 - Remove combustion air inducer assembly as described in the previous section.
- 2 - Remove flue box cover. Clean with a wire brush as required.
- 3 - Clean tubes with a wire brush.
- 4 - Reassemble the unit. The flue box cover gasket and combustion air inducer gasket should also be replaced during reassembly.


Prior to beginning work on systems containing refrigerant, checking that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects, taking into account the effects of aging or continual vibration from sources such as compressors or fans.

B-Cooling System Service Checks

SGH units are factory charged and require no further adjustment; however, charge should be checked periodically. See section III.

V-MAINTENANCE

The unit should be inspected once a year by a qualified service technician.

| | |
|---|---|
| ⚠ WARNING | |
|  | Electric shock hazard. Can cause injury or death. Before attempting to perform any service or maintenance, turn the electrical power to unit OFF at disconnect switch(es). Unit may have multiple power supplies. |

| | |
|--|--|
| ⚠ IMPORTANT | |
| Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing. | |

| | |
|---|--|
| ⚠ WARNING | |
| Any service personnel installing, decommissioning, or performing maintenance on the unit must be properly trained with A2L refrigerants | |

Prior to beginning work on systems containing refrigerant to ensure the risk of ignition is minimized:

- All work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapor being present while the work is being performed.
- The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i. e. non-sparking, adequately sealed or intrinsically safe.
- If any hot work is to be conducted on the refrigerating equipment or any associated parts, the appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO2 fire extinguisher adjacent to the charging area.
- No person carrying out work in relation to a refrigerating system which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.

- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work.

A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

- Where electrical components are being changed, service technicians shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance. The following checks shall be applied to installations using flameable refrigerants as applicable:
 - 1 - The actual refrigerant charge is in accordance with the room size within which the refrigerant containing parts are installed.
 - 2 - The ventilation machinery and outlets are operating adequately and are not obstructed.
 - 3 - If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant.
 - 4 - Markings on the equipment should be visible and legible. Markings and signs that are illegible shall be corrected.
 - 5 - Refrigerating pipes or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.
- For systems containing refrigerant all repair and maintenance to electrical components shall include initial safety checks and component inspection procedures such as that capacitors are discharged in a safe manner to avoid possibility of sparking, that no live electrical components and wiring are exposed while charging, recovering, or purging the system, and that there is continuity of earth bonding. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used that is reported to the owner of the equipment, so all parties are advised.

NOTE - Sealed electrical components shall be replaced, not repaired.

NOTE - Intrinsically safe components must be replaced, not repaired

- Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used. Electronic leak detectors may be used to detect refrigerant leaks but, in the case of flammable refrigerants, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed. Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work. If a leak is suspected, all naked flames shall be removed/extinguished. If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.
- When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice be followed, since flammability is a consideration. The following procedure shall be adhered to:
 - a. Safely remove refrigerant following local and national regulations,
 - b. Evacuate the circuit,
 - c. Purge the circuit with inert gas,
 - d. Evacuate,
 - e. Purge with inert gas,
 - f. Open the circuit.
- The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems. Refrigerant purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system. When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and that ventilation is available.

A-Filters

SCH units are equipped with (4) 16" X 20" X 2" filters and can accept 4" filters. Filters should be checked monthly and replaced when necessary with filters of like kind and size. Take note of air flow direction marking on filter frame when reinstalling filters.

NOTE - Filters must be U.L.C. certified or equivalent for use in Canada.

B-Lubrication

All motors used in SCH units are prelubricated; no further lubrication is required.

C-Supply Air Blower Wheel

Annually inspect supply air blower wheel for accumulated dirt or dust. Turn off power before attempting to remove access panel or to clean blower wheel.

D-Evaporator Coil

Inspect and clean coil at beginning of each season. Clean using mild detergent or commercial coil cleanser. Check condensate drain pan and line, if necessary. Flush coil and condensate drain with water taking care not to get insulation, filters and return air ducts wet. Check connecting lines and coil for evidence of oil and refrigerant leaks.

E-Condenser Coil

Clean condenser coil annually with detergent or commercial coil cleaner and inspect monthly during the cooling season. Check connecting lines and coil for evidence of oil and refrigerant leaks.

NOTE-If owner complains of insufficient cooling, the units refrigerant charge should be checked. See section III.

F-Electrical

- 1 - Check all wiring for loose connections.
- 2 - Check for correct voltage at unit (unit operating).
- 3 - Check amp-draw on both condenser fan motor and blower motor.

Fan Motor Rating Plate ____ Actual ____

Indoor Blower Motor Rating Plate ____ Actual ____

VI-ACCESSORIES

A-S1CURB Mounting Frame

When installing either the SCH units on a combustible surface for downflow discharge applications, the Lennox S1CURB71101 14-inch or S1CURB73101 24-inch height roof mounting frame is used. The roof mounting frames are recommended in all other applications but not required. If the SCH units are not mounted on a flat (roof) surface, they **MUST** be supported under all edges and under the middle of the unit to prevent sagging. The units **MUST** be mounted level within 1/16" per linear foot or 5mm per meter in any direction.

The assembled mounting frame is shown in FIGURE 23. Refer to the roof mounting frame installation instructions for details of proper assembly and mounting. The roof mounting frame **MUST** be squared to the roof and level before mounting. Plenum system **MUST** be installed before the unit is set on the mounting frame. Typical roof curbing and flashing is shown in FIGURE 24. Refer to the roof mounting frame installation instructions for proper plenum construction and attachment.




FIGURE 23




FIGURE 24

B-Outdoor Air Dampers

Dampers are manually operated to allow up to 25 percent outside air into the system at all times. See FIGURE 25.




FIGURE 25

C-Economizer (Factory Installed)

Units may contain an optional economizer. The economizer uses outdoor air for free cooling when the outdoor temperature and/or humidity is suitable. The economizer is controlled by the A55 Unit Controller.

D- Gravity Exhaust Dampers

Gravity exhaust dampers may be used in downflow and horizontal air discharge applications. Gravity exhaust dampers are installed in the return air duct.

The dampers allow exhaust air to be discharged from the system when an economizer and/or power exhaust is operating. Gravity exhaust dampers also prevent outdoor air infiltration during unit off cycle. See installation instructions for more detail.

E-Control Systems

The A55 Unit Controller provides all control function for the rooftop unit. Default operation requires a standard room thermostat or direct digital controller (DDC). The A55 can also control the unit from a zone temperature sensor. The A55 Unit Controller is a network controller when daisy-chained to the L Connection® Network Control System. For ease of configuration, the A55 can be connected to a PC with Unit Controller PC software installed.

F-Smoke Detectors A171, A172, A173

Photoelectric smoke detectors are a factory- and field-installed option. The smoke detectors can be installed in the supply air section (A172), return air section (A171), or in both the supply and return air section. Smoke detection control module (A173) is located below the control panel. Wiring for the smoke detectors are shown on the temperature control section (C) wiring diagram in back of this manual.

The Smoke Detector Transformer T31 a 120VAC to 24VAC transformer that supplies power to the smoke detector board A173.

G-Blower Proving Switch S52

The blower proving switch monitors blower operation and locks out the unit in case of blower failure. The switch is N.O. and closes at 0.14" W.C. (34.9 Pa) The switch is mounted on the side of the front of the blower enclosure.

H-Indoor Air Quality (CO2) Sensor A63

The indoor air quality sensor monitors CO2 levels and reports the levels to the main control module A55. The board adjusts the economizer dampers according to the CO2 levels. The sensor is mounted next to the indoor thermostat or in the return air duct. Refer to the indoor air quality sensor installation instructions for proper adjustment.

I-Drain Pan Overflow Switch S149 (optional)

The overflow switch is used to interrupt cooling operation when excessive condensate collects in the drain pan. The N.O. overflow switch is controlled by A55 Prodigy board located in the unit control panel. When the overflow switch closes, 24VAC power is interrupted and after a five-second delay unit compressors are de-energized.

Once the condensate level drops below the set level, the switch will open. After a five-minute delay the compressor will be energized.

J-Dirty Filter Switch S27

The dirty filter switch senses static pressure increase indicating a dirty filter condition. The switch is N.O. and closes at 1" W.C. (248.6 Pa) The switch is mounted on the side of the economizer. Wiring for the dirty filter switch is shown on the temperature control section (C) wiring diagram in back of this manual.

K-LP / Propane Kit

A natural to LP / propane gas changeover kit is required for gas conversion on SGH036/060 series units. The kit includes a gas valve and burner orifices.

L-Factory Installed Hot Gas Reheat (option)

General

Hot gas reheat units provide a dehumidifying mode of operation. These units contain a reheat coil adjacent to and downstream of the evaporator coil. Reheat coil solenoid valve L14, routes hot discharge gas from the compressor to the reheat coil. Return air pulled across the evaporator coil is cooled and dehumidified; the reheat coil adds heat to supply air.

See FIGURE 26 for reheat refrigerant routing.

L14 Reheat Coil Solenoid Valve

When Unit Controller input (Unit Controller J298-5 or J299-8) indicates room conditions require dehumidification, L14 reheat valve is energized (Unit Controller P394-3 or P394-) and refrigerant is routed to the reheat coil.

Reheat Setpoint

Reheat is factory-set to energize when indoor relative humidity rises above 60% (default). The reheat setpoint can be adjusted by changing Unit Controller Settings - Control menu. A setting of 100% will operate reheat from an energy management system digital output.

Reheat will terminate when the indoor relative humidity falls 3% (57% default) or the digital output de-energizes. The reheat deadband can be adjusted at Settings - Control menu.

Check-Out

Test reheat operation using the following procedure.

- 1 - Make sure reheat is wired as shown in wiring section.
- 2 - Make sure unit is in local thermostat mode.
- 3 - Use Unit Controller key pad to elect SERVICE > TEST > DEHUMIDIFIER.

The blower and compressor (reheat) should be operating. DEHUMIDIFIER 1 ON will be appear on the Unit Controller display.

- 4 - Press BACK on the Unit Controller display to stop the testing mode.

Default Reheat Operation

During reheat mode free cooling is locked out.

No Y1 demand but a call for dehumidification:

Compressor is operating, blower is on, and the reheat valve is energized.

Y1 demand:

Compressor is operating, blower is on, and the reheat valve is energized.

Y2 demand:

Compressor is operating, blower is on, and the reheat valve is de-energized.

IMPORTANT - Free cooling does not operate during reheat.

For other reheat control options, refer to the Unit Controller manual.

Additional Cooling Stages

Units are shipped from the factory to provide two stages of cooling.

Three stages of cooling is available in zone sensor mode. Three stages of cooling is also available by installing a transfer relay and a three-stage thermostat. Refer to the Main Control Operation section in the Unit Controller manual when using the transfer relay

REHEAT MODE REFRIGERANT ROUTING 036/060





FIGURE 26

VII- WIRING DIAGRAMS / SEQUENCE OF OPERATION

SGH036 / 060 COOLING



SGH036 / 060 Sequence of Operation

Power:

- 1 - Line voltage from unit disconnect energizes transformer T1. T1 provides 24VAC power to the A55 Unit Controller. A55 provides 24VAC to the unit cooling, heating and blower controls.
- 2 - Line voltage from unit disconnect provides voltage to compressor crankcase heaters HR1 (through discharge line thermostat) and compressor contactor K1. Voltage is distributed directly to blower motor B3 and outdoor fan motors B4 and B5.

Blower Operation:

The A55 Unit Controller receives a demand from thermostat terminal G. A55 energizes blower motor circuit follows:


- 3 - A55, through motor control board energizes blower B3 via programmed motor settings. Motor settings are fieldadjustable.

First-Stage Cooling

- 4 - A55 Unit Controller receives a Y1 and G cooling demand and energizes blower B3 in low speed.
- 5 - After A55 proves n.c. low pressure switch S87, n.c. freeze stat S49, and n.c. high pressure switch S4, compressor contactor K1 is energized.
- 6 - N.O. contacts K1-1 close energizing the compressor B1. On two-speed systems (3, 4, and 5 tons) compressor is energized on low speed.
- 7 - S11 n.o. contact close below 62°F. A55 energizes outdoor fan motors B4 and B5 on low speed.

Second-Stage Cooling

- 8 - A55 receives a Y2 and G cooling demand and energizes blower B3 in high speed.
- 9 - A55 energizes compressor solenoid L34, switching compressor to high speed.
- 10 - A55 energizes outdoor fan motors B4 and B5 on high speed.




Heat Call

- Heating demand initiates at W1 in the thermostat.
- 24VAC is routed through TB34 to the Unit Controller A55. After A55 proves N.C. primary limit S10, the combustion air blower relay K13 is energized.
- N.O. K13-1 contacts close allowing line voltage to energize combustion air blower B6.
- After the combustion air blower B6 has reached full speed, the combustion air proving switch S18 contacts close. The A55 routes 24VAC through N.C. burner flame rollout switch S47 and the closed contacts of combustion air proving switch S18 to energize the ignition module A3.
- After a 30 second delay A3 energizes the ignitor and gas valve GV1.

End of Heat Call

- Ignition A3 is de-energized by control module A55 in turn de-energizing GV1. Combustion air blower relay K13 is also de-energized.

THERMOSTAT




| KEY LIST | | |
|----------|------|-------------------------------|
| LOCATION | | COMPONENT DESCRIPTION |
| FF05 | A2 | SENSOR, ELECTRONIC THERMOSTAT |
| AA05 | A55 | CONTROL BOARD, MAIN |
| DD04/05 | A63 | SENSOR, CO2 (IAQ) |
| DD04/05 | A91 | SENSOR, HUMIDITY |
| AA01 | F/A | FIRE ALARM CONTACT |
| DD01 | S27 | SWITCH, FILTER |
| DD01 | S52 | SWITCH, AIRFLOW |
| EE01 | S149 | SWITCH, OVERFLOW ONE |

| NOTES | |
|-------|--|
| 1 | P297-10 (SR) IS SERVICE RELAY OUTPUT (24VAC) IF USED CONNECT TO AN INDICATOR LIGHT |
| 2 | CORE CONTROLLER SETTINGS MUST BE MODIFIED WHEN S27, S149 ARE INSTALLED |
| 3 | REMOVE JUMPER TO INSTALL S149 |

Model: SC, SG Series RTU
Thermostat and LonTalk
Voltage: All Voltages
Supersedes: N/A Form No: 538391- 01 Rev: 0


ECONOMIZER



| NOTES | |
|-------|--|
| 1 | A7 AND A62 NOT USED FOR SENSIBLE TEMPERATURE CONTROL |
| 2 | FOR UNIT DIFFERENTIAL ENTHALPY CONTROL, ADD A62 RETURN AIR ENTHALPY SENSOR |

| KEY LIST | | |
|----------|-----------------------|------------------------------|
| LOCATION | COMPONENT DESCRIPTION | |
| CC05 | A7 | SENSOR, SOLID STATE ENTHALPY |
| AA06 | A55 | CONTROL BOARD, MAIN |
| DD05 | A62 | SENSOR, ENTHALPY INDOOR |
| BB02 | B7 | MOTOR, DAMPER ECONOMIZER |
| CC05 | RT16 | SENSOR, RETURN AIR TEMP |

Model: LC,LG,LH,LD,SC,SG Series
Economizer & Motorized OAD
Voltage: All Voltages
Supersedes: N/A



WIRING DIAGRAM FLOW

OPERATION:

- 1 - The main control module A55 along with outdoor enthalpy sensor A7 and indoor enthalpy sensor A62 (if differential enthalpy is used) communicates to the economizer control module A56 when to power the damper motor B7.
- 2 - The economizer control module A56 supplies B7 with 0 - 10 VDC to control the positioning of economizer.
- 3 - The damper actuator provides 2 to 10 VDC position feedback.

VIII-Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.

Steps to ensure this are:

- Become familiar with the equipment and its operation,
- Isolate the system electrically,
- Ensure that before attempting the procedure that mechanical handling equipment is available, if required, for handling refrigerant cylinders, and that all personal protective equipment is available and being used correctly while the recovery process is supervised at all times by a competent person and that the recovery equipment and cylinders conform to the appropriate standards.

Additionally, pump down refrigerant system, if possible, and if a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system. Make sure that cylinders are situated on the scales before recovery takes place. Start the recovery machine and operate in accordance with instructions. Do not overfill cylinders (no more than 80 % volume liquid charge). Do not exceed the maximum working pressure of the cylinder, even temporarily. When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off. Recovered refrigerant shall not be charged into another refrigerating system unless it has been cleaned and checked.

Equipment shall be labeled stating that it has been decommissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing flammable refrigerants, ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used. Electronic leak detectors may be used to detect refrigerant leaks but, in the case of flammable refrigerants, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area).

Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed. Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work. If a leak is suspected, all naked flames shall be removed/extinguished. If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.

When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice be followed, since flammability is a consideration. The following procedure shall be adhered to:

- Safely remove refrigerant following local and national regulations,
- Evacuate the circuit,
- Purge the circuit with inert gas,
- Evacuate,
- Purge with inert gas,
- Open the circuit.

The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems. Refrigerant purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system. When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and that ventilation is available.