

# INSTALLATION INSTRUCTIONS

## ⚠ WARNING

To prevent serious injury or death:

- 1- Lock-out/tag-out before performing maintenance.
- 2- If system power is required (e.g., smoke detector maintenance), disable power to blower, remove fan belt where applicable, and ensure all controllers and thermostats are set to the "OFF" position before performing maintenance.
- 3- Always keep hands, hair, clothing, jewelry, tools, etc., away from moving parts.

<b>KGC/KCC 180S</b>	(15 Ton)
<b>KGC/KCC 210S</b>	(17.5 Ton)
<b>KGC/KCC 240S</b>	(20 Ton)
<b>KGC/KCC 300S</b>	(25 Ton)


### Table Of Contents

Dimensions .....	Page 2
Parts Arrangements .....	Page 4
Shipping and Packing List .....	Page 5
General .....	Page 5
Safety .....	Page 5
Unit Support .....	Page 6
Duct Connection .....	Page 6
Rigging Unit For Lifting .....	Page 7
Condensate Drains .....	Page 7
Gas Piping .....	Page 7
Pressure Test Gas Piping .....	Page 8

**GAS AND COOLING PACKAGED UNITS**  
 507198-09  
 3/2023  
 Supersedes 8/2022

High Altitude Derate .....	Page 8
Electrical Connections .....	Page 8
Unit Power-Up .....	Page 10
Blower Operation and Adjustments .....	Page 10
Cooling Start-Up .....	Page 15
Gas Heat Start-Up .....	Page 32
Heating Operation and Adjustments .....	Page 34
Electric Heat .....	Page 34
Supply Air Inverter .....	Page 35
Hot Gas Reheat Operation and Start-Up .....	Page 37
Service .....	Page 40

**RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE**



KGC240S SHOWN




# ⚠️ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a licensed professional HVAC installer or equivalent, service agency, or the gas supplier

# ⚠️ CAUTION




As with any mechanical equipment, contact with sharp sheet metal edges can result in personal injury. Take care while handling this equipment and wear gloves and protective clothing.

## KG/KC 180S, 210S DIMENSIONS - Electric heat section shown




**KG/KC 240S, 300S DIMENSIONS - Electric heat section shown**


Note: 240S have four condenser fans.



# KG PARTS ARRANGEMENT



# KC PARTS ARRANGEMENT



## Shipping and Packing List

### Package 1 of 1 contains:

1- Assembled unit

Check unit for shipping damage. Receiving party should contact last carrier immediately if shipping damage is found.

## General

These instructions are intended as a general guide and do not supersede local codes in any way. Authorities having jurisdiction should be consulted before installation.

The KG 180-300 is available in three Btuh heating inputs. The KC cooling packaged rooftop unit is the same basic design as the KG unit except for the heating section. KG and KC units have identical refrigerant circuits with respective 15, 17-1/2, 20, and 25 ton cooling capacities.

Units are equipped with a supply air inverter (variable frequency drive or VFD). The blower will operate at lower speeds when cooling demand is low and increase to higher speeds when cooling demand is high. Refer to Inverter Start-Up section.

All units come default with a lightweight, all-aluminum condenser coil. Standard units are available with an optional, factory-installed fin/tube condenser coil.

Standard efficiency units equipped with fin/tube outdoor coils are available with an optional hot gas reheat coil which provides a dehumidifying mode of operation. Refer to Reheat Operation section.

Availability of units and options varies by brand.

## Safety

See figure 1 for unit clearances.

Use of this unit as a construction heater or air conditioner is not recommended during any phase of construction. Very low return air temperatures, harmful vapors and operation of the unit with clogged or misplaced filters will damage the unit.

If this unit has been used for heating or cooling of buildings or structures under construction, the following conditions must be met or the warranty will be void:

- The vent hood must be installed per these installation instructions.
- A room thermostat must control the unit. The use of fixed jumpers that will provide continuous heating or cooling is not allowed.




FIGURE 1

<sup>1</sup> Unit Clearance	A in.(mm)	B in.(mm)	C in.(mm)	D in.(mm)	Top Clearance
Service Clearance	60 (1524)	36 (914)	36 (914)	66 (1676)	Unob- structed
Clearance to Combustibles	36 (914)	1 (25)	1 (25)	1 (25)	Unob- structed
Minimum Operation Clearance	45 (1143)	36 (914)	36 (914)	41 (1041)	Unob- structed

Note - Entire perimeter of unit base requires support when elevated above mounting surface.

<sup>1</sup>Service Clearance - Required for removal of serviceable parts.

**Clearance to Combustibles** - Required clearance to combustible material (gas units). On KC units, see clearance to combustible materials as outlined on heater rating plate.

**Minimum Operation Clearance** - Required clearance for proper unit operation.

- A pre-filter must be installed at the entry to the return air duct.
- The return air duct must be provided and sealed to the unit.
- Return air temperature range between 55°F (13°C) and 80°F (27°C) must be maintained.
- Air filters must be replaced and pre-filters must be removed upon construction completion.
- The input rate and temperature rise must be set per the unit rating plate.
- The heat exchanger, components, duct system, air filters and evaporator coil must be thoroughly cleaned following final construction clean-up.
- The unit operating conditions (including airflow, cooling operation, ignition, input rate, temperature rise and venting) must be verified according to these installation instructions.

This appliance is not to be used by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.

This appliance should not be used by children. Children should be supervised to ensure they do not play with the appliance.

## ⚠ WARNING



Electric shock hazard and danger of explosion. Can cause injury, death or product or property damage. Turn off gas and electrical power to unit before performing any maintenance or servicing operations on the unit. Follow lighting instructions attached to unit when putting unit back into operation and after service or maintenance.

## ⚠ NOTICE

### Roof Damage!

This system contains both refrigerant and oil. Some rubber roofing material may absorb oil, causing the rubber to swell. Bubbles in the rubber roofing material can cause leaks. Protect the roof surface to avoid exposure to refrigerant and oil during service and installation. Failure to follow this notice could result in damage to roof surface.

## ⚠ IMPORTANT

The Clean Air Act of 1990 bans the intentional venting of refrigerant (CFC's and HCFC's) as of July 1, 1992. Approved methods of recovery, recycling or reclaiming must be followed. Fines and/or incarceration may be levied for non-compliance.

### Unit Support

In downflow discharge installations, install the unit on a non-combustible surface only. Unit may be installed on combustible surfaces when used in horizontal discharge applications or in downflow discharge applications when installed on an LARMF18/36 roof mounting frame.

*NOTE - Securely fasten roof frame to roof per local codes.*

## ⚠ CAUTION

To reduce the likelihood of supply / return air bypass and promote a proper seal with the RTU, duct work / duct drops / diffuser assemblies must be supported independently to the building structure.

### A-Downflow Discharge Application

#### Roof Mounting with LARMF18/36

- 1- The LARMF roof mounting frame must be installed, flashed and sealed in accordance with the instructions provided with the frame.
- 2- The LARMF roof mounting frame should be square and level to 1/16" per linear foot (5mm per linear meter) in any direction.

- 3- Duct must be attached to the roof mounting frame and not to the unit; supply and return plenums must be installed before setting the unit.

#### Installer's Roof Mounting Frame

Many types of roof frames can be used to install the unit depending upon different roof structures. Items to keep in mind when using the building frame or supports are:

- 1- The base is fully enclosed and insulated, so an enclosed frame is not required.
- 2- The frames or supports must be constructed with non-combustible materials and should be square and level to 1/16" per linear foot (5mm per linear meter) in any direction.
- 3- Frame or supports must be high enough to prevent any form of moisture from entering unit. Recommended minimum frame height is 14" (356mm).
- 4- Duct must be attached to the roof mounting frame and not to the unit. Supply and return plenums must be installed before setting the unit.
- 5- Units require support along all four sides of unit base. Supports must be constructed of steel or suitably treated wood materials.

*NOTE-When installing a unit on a combustible surface for downflow discharge applications, a LARMF roof mounting frame is required.*

### B-Horizontal Discharge Applications

- 1- Units installed in horizontal airflow applications must use an LARMF horizontal roof mounting frame. The supply air duct connects to the LARMF horizontal supply air opening. The return air duct connected to the unit horizontal return air opening. Refer to unit dimensions.
- 2- Specified installation clearances must be maintained when installing units. Refer to figure 1.
- 3- Top of support slab should be approximately 4" (102mm) above the finished grade and located so no run-off water from higher ground can collect around the unit.
- 4- Units require support along all four sides of unit base. Supports must be constructed of steel or suitably treated wood materials.

### Duct Connection

All exterior ducts, joints and openings in roof or building walls must be insulated and weather-proofed with flashing and sealing compounds in accordance with applicable codes. Any duct passing through an unconditioned space must be insulated.

## ⚠ CAUTION

In downflow applications, do not drill or punch holes in base of unit. Leaking in roof may occur if unit base is punctured.

### Rigging Unit For Lifting

Rig unit for lifting by attaching four cables to holes in unit base rail. See figure 2.

- 1- Detach wooden base protection before rigging.
- 2- Connect rigging to the unit base using both holes in each corner.
- 3- All panels must be in place for rigging.
- 4- Place field-provided H-style pick in place just above top edge of unit. Frame must be of adequate strength and length. (H-style pick prevents damage to unit.)

### RIGGING

Unit	*Weight	
	Lbs.	Kg.
KG 180S KC 180S, 210S	2460	1112
KG 210S KC 240S	2651	1203
KG 240S, 300S KC 300S	3015	1368

\*Maximum weight with all accessories.




FIGURE 2

### Condensate Drains

Remove plug and make drain connection to the 1" N.P.T. drain coupling provided on unit. A trap must be installed between drain connection and an open vent for proper condensate removal. See figure 3. It is sometimes

acceptable to drain condensate onto the roof or grade; however, a tee should be fitted to the trap to direct condensate downward. The condensate line must be vented. Check local codes concerning condensate disposal. Refer to pages 1 and 2 for condensate drain location.

*Note - The drain pan is made with a glass reinforced engineered plastic capable of withstanding typical joint torque but can be damaged with excessive force. Tighten pipe nipple hand tight and turn an additional quarter turn.*

### CONDENSATE DRAIN CONNECTION

#### CAULK AROUND CONDENSATE COUPLING

*NOTE - Allow clearance to open doors when installing condensate piping.*

Minimum Pitch  
1" (25 mm) per  
10' (3 m) of line




FIGURE 3

### Connect Gas Piping (Gas Units)

Before connecting piping, check with gas company or authorities having jurisdiction for local code requirements. When installing gas supply piping, length of run from gas meter must be considered in determining pipe size for 0.5" w.c. (.12kPa) maximum pressure drop. Do not use supply pipe smaller than unit gas connection. For natural gas units, operating pressure at the unit gas connection must be a minimum of 4.7" w.c. (1.19kPa) and a maximum of 10.5" (2.60kPa) w.c. For LP/propane gas units, operating pressure at the unit gas connection must be a minimum of 10.8" w.c. (2.69kPa) and a maximum of 13.5" w.c. (3.36kPa).

When making piping connections a drip leg should be installed on vertical pipe runs to serve as a trap for sediment or condensate. A 1/8" N.P.T. plugged tap is located on gas valve for test gauge connection. Refer to Heating Start-Up section for tap location. Install a ground joint union between the gas control manifold and the main manual shut-off valve.

See figure 4 for gas supply piping entering outside the unit. A kit is required when gas supply piping enters through the bottom of the unit.

Compounds used on threaded joints of gas piping shall be resistant to the action of liquified petroleum gases.




FIGURE 4




FIGURE 5

**Pressure Test Gas Piping (Gas Units)**

When pressure testing gas lines, the gas valve must be disconnected and isolated. Gas valves can be damaged if subjected to more than 0.5 psig (3.48kPa). See figure 5.

NOTE-Codes may require that manual main shut-off valve and union (furnished by installer) be installed in gas line external to unit. Union must be of the ground joint type.

After all connections have been made, check all piping connections for gas leaks. Also check existing unit gas connections up to the gas valve; loosening may occur during installation. Use a leak detection solution or other preferred means. Do not use matches candles or other sources of ignition to check for gas leaks.

**⚠ CAUTION**

Some soaps used for leak detection are corrosive to certain metals. Carefully rinse piping thoroughly after leak test has been completed. Do not use matches, candles, flame or othe sources of ignition to check for gas leaks.

**⚠ WARNING**

 Danger of explosion. Can cause injury or product or property damage. Do not use matches, candles, flame or other sources of ignition to check for leaks.

NOTE-In case emergency shut down is required, turn off the main manual shut-off valve and disconnect main power to unit. These devices should be properly labeled by the installer.

**High Altitude Derate**

Locate the high altitude conversion sticker in the unit literature bag. Fill out the conversion sticker and affix next to the unit nameplate. High altitude kits are available for field-installation.

Refer to table 1 for high altitude adjustments.

**TABLE 1  
HIGH ALTITUDE DERATE**

Altitude Ft.*	Gas Manifold Pressure
2000-4500	See Unit Nameplate
4500 And Above	Derate 2% / 1000 Ft. Above Sea Level

\*Units installed at 0-2000 feet do not need to be modified.

NOTE - This is the only permissible derate for these units.

**Electrical Connections**

Refer to inside of access panels for wiring diagrams.

**POWER SUPPLY**

**A-Wiring**

Do not apply power or close disconnect switch until installation is complete. Refer to start-up directions. Refer closely to unit wiring diagram.

Refer to unit nameplate for minimum circuit ampacity and maximum fuse size.

- Units are factory-wired for 240/460/575 volt supply. **For 208V supply**, remove the insulated terminal cover from the 208V terminal on the control transformer. Move the wire from the transformer 240V terminal to the 208V terminal. Place the insulated terminal cover on the unused 240V terminal.
- Route power through the bottom power entry area. On KG units, connect wiring to L1, L2, and L3 on TB13 in the control area. On KC units, connect wiring to TB2 in the incoming power enclosure.

Secure power wiring with wire ties provided in control box. See unit wiring diagram.

**3- Units With Optional 120v GFCI Outlet -**

Route and connect separate 120v wiring to GFCI outlets which do not have factory-installed wiring. Route field wiring in conduit between bottom power entry and GFCI. See figure 6.

**B-Unbalanced Three-Phase Voltage - VFD Units**

Units equipped with an inverter (VFD) are designed to operate on balanced, three-phase power. Operating units on unbalanced three-phase power will reduce the reliability of all electrical components in the unit. Unbalanced power is a result of the power delivery system supplied by the local utility company.

Factory-installed inverters are sized to drive blower motors with an equivalent current rating using balanced three-phase power. When unbalanced three-phase power is supplied; the installer must replace the existing factory-installed inverter with an inverter that has a higher current rating to allow for the imbalance. Use table 2 to determine the appropriate replacement inverter.

**TABLE 2  
INVERTER UP-SIZING**

Factory-Installed Inverter HP	Replacement Inverter HP
2	5
3	7-1/2
5	10
7-1/2	15
10	20

**CONTROL WIRING**

**A-Thermostat Location**


Room thermostat mounts vertically on a standard 2" X 4" handy box or on any non-conductive flat surface.

Locate thermostat approximately 5 feet (1524mm) above the floor in an area with good air circulation at average temperature. Avoid locating the room thermostat where it might be affected by:

- drafts or dead spots behind doors and in corners
- hot or cold air from ducts
- radiant heat from sun or appliances
- concealed pipes and chimneys

**B-Thermostat Wiring**

- 1- Route thermostat cable or wires from subbase to TB1 in control box (refer to unit dimensions to locate bottom and side power entry and parts arrangement for location of TB1).
- 2- On hot gas reheat units, route wires from the A20 dehumidistat switch to TB1 and TB37 in the control box.



**FIGURE 6**

**IMPORTANT -** Unless field thermostat wires are rated for maximum unit voltage, they must be routed away from line voltage wiring. Use wire ties located in control area to secure thermostat cable.

Use 18 AWG wire for all applications using remotely installed electro-mechanical and electronic thermostats.

- 3- Install in accordance with instructions provided with thermostat.
- 4- Connect thermostat wiring to TB1 terminal as shown in figure 7 for electro-mechanical and electronic thermostats. If using other temperature control devices or energy management systems see instructions and wiring diagram provided by manufacturer.

**IMPORTANT-** Terminal connections at the subbase and TB1 must be made securely. Loose control wire connections may allow unit to operate but not with proper response to room demand.

**C-Hot Gas Reheat Units Only**

Units require a dehumidify demand to initiate operation. A 24V input at TB37-L1 is required to energize reheat. A standalone dehumidistat (A20) and/or a room thermostat / energy management system with humidity sensing may be used. Refer to device manual for setup details.

- 1- When a dehumidistat is used, route wires from the A20 dehumidistat switch to the control box. Install dehumidistat assembly in accordance with instructions provided with the dehumidistat.

## 24 VOLT FIELD WIRING WITH ELECTRONIC AND ELECTRO-MECHANICAL THERMOSTATS

*IMPORTANT - Remove jumper between terminals R and OC when thermostat has a night setback mode. If reheat operation is desired during night setback, move dehumidistat wire from OC to R.*




FIGURE 7

- 2- Connect dehumidistat and/or thermostat wiring to TB1 and TB37 as shown in figure 7.

*IMPORTANT - Remove jumper between terminals R (24V) and OC when thermostat has a night setback mode. If reheat operation is desired during night setback, move dehumidistat wire from OC to R.*

*Note - When initially setting up some thermostats, a dehumidification mode must be enabled. When prompted by thermostat menus, select RTU/AUX DEHUMIDIFIER mode.*

### Unit Power-Up

- 1- Make sure that unit is installed in accordance with the installation instructions and applicable codes.
- 2- Inspect all electrical wiring, both field- and factory-installed, for loose connections. Tighten as required.
- 3- Check to ensure that refrigerant lines do not rub against the cabinet or against other refrigerant lines.
- 4- Check voltage at disconnect switch. Voltage must be within range listed on nameplate. If not, consult power company and have voltage condition corrected before starting unit.
- 5- Make sure filters are in place before start-up.
- 6- Apply power to unit.

## Blower Operation and Adjustments

### A-Three Phase Scroll Compressor Voltage Phasing

Three phase scroll compressors must be phased sequentially to ensure correct compressor and blower rotation and operation. Compressor and blower are wired in phase at the factory. Power wires are color-coded as follows: line 1-red, line 2-yellow, line 3-blue.

- 1- Observe suction and discharge pressures and blower rotation on unit start-up.
- 2- Suction pressure must drop, discharge pressure must rise, and blower rotation must match rotation marking.

If pressure differential is not observed or blower rotation is not correct:

- 3- Disconnect all remote electrical power supplies.
- 4- Reverse any two field-installed wires connected to the line side of TB2. Do not reverse wires at blower contactor.
- 5- Make sure the connections are tight.

Discharge and suction pressures should operate at their normal start-up ranges.

**Supply Air Inverter Units** - These units are equipped with a phase monitor located in the control compartment. The phase monitor will detect the phasing of incoming power. If the incoming power is out of phase or if any of the three phases are lost, the indicating LED on the phase monitor will turn red and the unit will not start. In normal operation with correct incoming power phasing, the LED will be green.

*Note - The phase monitor is also offered as a field-installed option.*

### B-Blower Operation

Initiate blower demand at thermostat according to instructions provided with thermostat. Unit will cycle on thermostat demand. The following steps apply to applications using a typical electro-mechanical thermostat.

- 1- Blower operation is manually set at the thermostat subbase fan switch. With fan switch in **ON** position, blowers will operate continuously.
- 2- With fan switch in **AUTO** position, the blowers will cycle with heating or cooling demand. Blowlers and entire unit will be off when system switch is in **OFF** position.

### C-Blower Access

The blower assembly is secured to a sliding base which allows the entire assembly to be pulled out of the unit. See figure 8.

- 1- Remove the clamp which secures the blower wiring to the blower motor base.
- 2- Remove and retain screws on either side of sliding base. Pull base toward outside of unit. When pulling the base out further than 12" (305mm), disconnect wiring to K3 blower contactor T1, T2, and T3. Pull wiring toward blower to allow enough slack to slide the base out further.
- 3- Slide base back into original position when finished servicing. Replace the clamp and blower wiring in the previous location on the blower motor base. Reconnect wiring to K3 if it was disconnected.
- 4- Replace retained screws on either side of the sliding base.

### D-Determining Unit CFM

**IMPORTANT** - Supply air inverter units are factory-set to run the blower at full speed when there is a blower (G) demand without a heating or cooling demand. Use the following procedure to adjust motor pulley to deliver the full load cooling or heating CFM. See Inverter Start-Up section to set blower CFM for all modes once the motor pulley is set.

1- The following measurements must be made with a dry indoor coil. Run blower without a cooling demand. Measure the indoor blower shaft RPM. Air filters must be in place when measurements are taken.

2- With all access panels in place, measure static pressure external to unit (from supply to return). Blower performance data is based on static pressure readings taken in locations shown in figure 9.

*Note - Static pressure readings can vary if not taken where shown.*


3- Referring to page 13, use static pressure and RPM readings to determine unit CFM. Use page 14 when installing units with any of the optional accessories listed.

4- The blower RPM can be adjusted at the motor pulley. Loosen Allen screw and turn adjustable pulley clockwise to increase RPM. Turn counterclockwise to decrease RPM. See figure 8. Tighten Allen screw after adjusting. Do not exceed minimum and maximum number of pulley turns as shown in table 3.


**TABLE 3  
MINIMUM AND MAXIMUM PULLEY ADJUSTMENT**

Belt	Min. Turns Open	Max. Turns Open
A Section	No minimum	5
B Section	1*	6

\*No minimum number of turns open when B belt is used on pulleys 6" O.D. or larger.




**FIGURE 8**



**FIGURE 9**

**E-Blower Belt Adjustment**

Maximum life and wear can be obtained from belts only if proper pulley alignment and belt tension are maintained. Tension new belts after a **24-48** hour period of operation. This will allow belt to stretch and seat into pulley grooves. Make sure blower and motor pulley are aligned as shown in figure 10.



**FIGURE 10**

- 1- Loosen four bolts securing motor base to mounting frame. See figure 8.
- 2- *To increase belt tension -*  
Turn adjusting bolt to the left, or counterclockwise, to move the motor outward and tighten the belt. This increases the distance between the blower motor shaft and the blower housing shaft.  
*To loosen belt tension -*  
Turn the adjusting bolt to the right, or clockwise to loosen belt tension.
- 3- Tighten two bolts on motor pulley side.

**IMPORTANT** - Align top edges of blower motor base and mounting frame base parallel before tightening two bolts on the other side of base. Motor shaft and blower shaft must be parallel.


- 4- Tighten two bolts on other side of base.

**F-Check Belt Tension**

Overtensioning belts shortens belt and bearing life. Check belt tension as follows:

- 1- Measure span length X. See figure 11.
- 2- Apply perpendicular force to center of span (X) with enough pressure to deflect belt 1/64" for every inch of span length or 1.5mm per 100mm of span length.  
Example: Deflection distance of a 40" span would be 40/64" or 5/8".  
Example: Deflection distance of a 400mm span would be 6mm.
- 3- Measure belt deflection force. For a used belt, the deflection force should be 5 lbs. (35kPa). A new belt deflection force should be 7 lbs. (48kPa).

A force below these values indicates an undertensioned belt. A force above these values indicates an overtensioned belt.



**FIGURE 11**

**G-Field-Furnished Blower Drives**

For field-furnished blower drives, use page 13 to determine BHP and RPM required. Reference page 14 to determine the drive number and table 4 to determine the manufacturer's model number

## BLOWER DATA

BLOWER TABLE INCLUDES RESISTANCE FOR BASE UNIT ONLY WITH DRY INDOOR COIL & AIR FILTERS IN PLACE FOR ALL UNITS ADD:

- 1 - Wet indoor coil air resistance of selected unit.
- 2 - Any factory installed options air resistance (electric heat, economizer, etc.)
- 3 - Any field installed accessories air resistance (electric heat, duct resistance, diffuser, etc.)

Then determine from blower table blower motor output and drive required.

See page 14 for wet coil and option/accessory air resistance data. See page 14 for factory installed drive kit specifications.

**MINIMUM AIR VOLUME REQUIRED FOR DIFFERENT GAS HEAT SIZES - Standard (S) and Medium Heat (M) - 4500 cfm minimum. High Heat (H) - 5125 cfm minimum.**

**MINIMUM AIR VOLUME REQUIRED FOR USE WITH OPTIONAL ELECTRIC HEAT - KC units require 6000 cfm minimum air with electric heat.**

### TOTAL STATIC PRESSURE - Inches Water Gauge (Pa)

Air Volume cfm	0.20		0.40		0.60		0.80		1.00		1.20		1.40		1.60		1.80		2.00		2.20		2.40		2.60																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																									
	RPM	BHP																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																
2750	385	0.30	505	0.50	600	0.70	680	0.90	755	1.10	820	1.30	885	1.50	950	1.70	1005	1.90	1060	2.10	1115	2.30	1170	2.50	1225	2.70	1280	2.90	1335	3.10	1390	3.30	1445	3.50	1500	3.70	1555	3.90	1610	4.10	1665	4.30	1720	4.50	1775	4.70	1830	4.90	1885	5.10	1940	5.30	1995	5.50	2050	5.70	2105	5.90	2160	6.10	2215	6.30	2270	6.50	2325	6.70	2380	6.90	2435	7.10	2490	7.30	2545	7.50	2600	7.70	2655	7.90	2710	8.10	2765	8.30	2820	8.50	2875	8.70	2930	8.90	2985	9.10	3040	9.30	3095	9.50	3150	9.70	3205	9.90	3260	10.10	3315	10.30	3370	10.50	3425	10.70	3480	10.90	3535	11.10	3590	11.30	3645	11.50	3700	11.70	3755	11.90	3810	12.10	3865	12.30	3920	12.50	3975	12.70	4030	12.90	4085	13.10	4140	13.30	4195	13.50	4250	13.70	4305	13.90	4360	14.10	4415	14.30	4470	14.50	4525	14.70	4580	14.90	4635	15.10	4690	15.30	4745	15.50	4800	15.70	4855	15.90	4910	16.10	4965	16.30	5020	16.50	5075	16.70	5130	16.90	5185	17.10	5240	17.30	5295	17.50	5350	17.70	5405	17.90	5460	18.10	5515	18.30	5570	18.50	5625	18.70	5680	18.90	5735	19.10	5790	19.30	5845	19.50	5900	19.70	5955	19.90	6010	20.10	6065	20.30	6120	20.50	6175	20.70	6230	20.90	6285	21.10	6340	21.30	6395	21.50	6450	21.70	6505	21.90	6560	22.10	6615	22.30	6670	22.50	6725	22.70	6780	22.90	6835	23.10	6890	23.30	6945	23.50	7000	23.70	7055	23.90	7110	24.10	7165	24.30	7220	24.50	7275	24.70	7330	24.90	7385	25.10	7440	25.30	7495	25.50	7550	25.70	7605	25.90	7660	26.10	7715	26.30	7770	26.50	7825	26.70	7880	26.90	7935	27.10	7990	27.30	8045	27.50	8100	27.70	8155	27.90	8210	28.10	8265	28.30	8320	28.50	8375	28.70	8430	28.90	8485	29.10	8540	29.30	8595	29.50	8650	29.70	8705	29.90	8760	30.10	8815	30.30	8870	30.50	8925	30.70	8980	30.90	9035	31.10	9090	31.30	9145	31.50	9200	31.70	9255	31.90	9310	32.10	9365	32.30	9420	32.50	9475	32.70	9530	32.90	9585	33.10	9640	33.30	9695	33.50	9750	33.70	9805	33.90	9860	34.10	9915	34.30	9970	34.50	10025	34.70	10080	34.90	10135	35.10	10190	35.30	10245	35.50	10300	35.70	10355	35.90	10410	36.10	10465	36.30	10520	36.50	10575	36.70	10630	36.90	10685	37.10	10740	37.30	10795	37.50	10850	37.70	10905	37.90	10960	38.10	11015	38.30	11070	38.50	11125	38.70	11180	38.90	11235	39.10	11290	39.30	11345	39.50	11400	39.70	11455	39.90	11510	40.10	11565	40.30	11620	40.50	11675	40.70	11730	40.90	11785	41.10	11840	41.30	11895	41.50	11950	41.70	12005	41.90	12060	42.10	12115	42.30	12170	42.50	12225	42.70	12280	42.90	12335	43.10	12390	43.30	12445	43.50	12500	43.70	12555	43.90	12610	44.10	12665	44.30	12720	44.50	12775	44.70	12830	44.90	12885	45.10	12940	45.30	12995	45.50	13050	45.70	13105	45.90	13160	46.10	13215	46.30	13270	46.50	13325	46.70	13380	46.90	13435	47.10	13490	47.30	13545	47.50	13600	47.70	13655	47.90	13710	48.10	13765	48.30	13820	48.50	13875	48.70	13930	48.90	13985	49.10	14040	49.30	14095	49.50	14150	49.70	14205	49.90	14260	50.10	14315	50.30	14370	50.50	14425	50.70	14480	50.90	14535	51.10	14590	51.30	14645	51.50	14700	51.70	14755	51.90	14810	52.10	14865	52.30	14920	52.50	14975	52.70	15030	52.90	15085	53.10	15140	53.30	15195	53.50	15250	53.70	15305	53.90	15360	54.10	15415	54.30	15470	54.50	15525	54.70	15580	54.90	15635	55.10	15690	55.30	15745	55.50	15800	55.70	15855	55.90	15910	56.10	15965	56.30	16020	56.50	16075	56.70	16130	56.90	16185	57.10	16240	57.30	16295	57.50	16350	57.70	16405	57.90	16460	58.10	16515	58.30	16570	58.50	16625	58.70	16680	58.90	16735	59.10	16790	59.30	16845	59.50	16900	59.70	16955	59.90	17010	60.10	17065	60.30	17120	60.50	17175	60.70	17230	60.90	17285	61.10	17340	61.30	17395	61.50	17450	61.70	17505	61.90	17560	62.10	17615	62.30	17670	62.50	17725	62.70	17780	62.90	17835	63.10	17890	63.30	17945	63.50	18000	63.70	18055	63.90	18110	64.10	18165	64.30	18220	64.50	18275	64.70	18330	64.90	18385	65.10	18440	65.30	18495	65.50	18550	65.70	18605	65.90	18660	66.10	18715	66.30	18770	66.50	18825	66.70	18880	66.90	18935	67.10	18990	67.30	19045	67.50	19100	67.70	19155	67.90	19210	68.10	19265	68.30	19320	68.50	19375	68.70	19430	68.90	19485	69.10	19540	69.30	19595	69.50	19650	69.70	19705	69.90	19760	70.10	19815	70.30	19870	70.50	19925	70.70	19980	70.90	20035	71.10	20090	71.30	20145	71.50	20200	71.70	20255	71.90	20310	72.10	20365	72.30	20420	72.50	20475	72.70	20530	72.90	20585	73.10	20640	73.30	20695	73.50	20750	73.70	20805	73.90	20860	74.10	20915	74.30	20970	74.50	21025	74.70	21080	74.90	21135	75.10	21190	75.30	21245	75.50	21300	75.70	21355	75.90	21410	76.10	21465	76.30	21520	76.50	21575	76.70	21630	76.90	21685	77.10	21740	77.30	21795	77.50	21850	77.70	21905	77.90	21960	78.10	22015	78.30	22070	78.50	22125	78.70	22180	78.90	22235	79.10	22290	79.30	22345	79.50	22400	79.70	22455	79.90	22510	80.10	22565	80.30	22620	80.50	22675	80.70	22730	80.90	22785	81.10	22840	81.30	22895	81.50	22950	81.70	23005	81.90	23060	82.10	23115	82.30	23170	82.50	23225	82.70	23280	82.90	23335	83.10	23390	83.30	23445	83.50	23500	83.70	23555	83.90	23610	84.10	23665	84.30	23720	84.50	23775	84.70	23830	84.90	23885	85.10	23940	85.30	23995	85.50	24050	85.70	24105	85.90	24160	86.10	24215	86.30	24270	86.50	24325	86.70	24380	86.90	24435	87.10	24490	87.30	24545	87.50	24600	87.70	24655	87.90	24710	88.10	24765	88.30	24820	88.50	24875	88.70	24930	88.90	24985	89.10	25040	89.30	25095	89.50	25150	89.70	25205	89.90	25260	90.10	25315	90.30	25370	90.50	25425	90.70	25480	90.90	25535	91.10	25590	91.30	25645	91.50	25700	91.70	25755	91.90	25810	92.10	25865	92.30	25920	92.50	25975	92.70	26030	92.90	26085	93.10	26140	93.30	26195	93.50	26250	93.70	26305	93.90	26360	94.10	26415	94.30	26470	94.50	26525	94.70	26580	94.90	26635	95.10	26690	95.30	26745	95.50	26800	95.70	26855	95.90	26910	96.10	26965	96.30	27020	96.50	27075	96.70	27130	96.90	27185	97.10	27240	97.30	27295	97.50	27350	97.70	27405	97.90	27460	98.10	27515	98.30	27570	98.50	27625	98.70	27680	98.90	27735	99.10	27790	99.30	27845	99.50	27900	99.70	27955	99.90	28010	100.10	28065	100.30	28120	100.50	28175	100.70	28230	100.90	28285	101.10	28340	101.30	28395	101.50	28450	101.70	28505	101.90	28560	102.10	28615	102.30	28670	102.50	28725	102.70	28780	102.90	28835	103.10	28890	103.30	28945	103.50	29000	103.70	29055	103.90	29110	104.10	29165	104.30	29220	104.50	29275	104.70	29330	104.90	29385	105.10	29440	105.30	29495	105.50	29550	105.70	29605	105.90	29660	106.10	29715	106.30	29770	106.50	29825	106.70	29880	106.90	29935	107.10	29990	107.30	30045	107.50	30100	107.70	30155	107.90	30210	108.10	30265	108.30	30320	108.50	30375	108.70	30430	108.90	30485	109.10	30540	109.30	30595	109.50	30650	109.70	30705	109.90	30760	110.10	30815	110.30	30870	110.50	30925	110.70	30980	110.90	31035	111.10	31090	111.30	31145	111.50	31200	111.70	31255	111.90	31310	112.10	31365	112.30	31420	112.50	31475	112.70	31530	112.90	31585	113.10	31640	113.30	31695	113.50	31750	113.70	31805	113.90	31860	114.10	31915	114.30	31970	114.50	32025	114.70	32080	114.90	32135	115.10	32190	115.30	32245	115.50</

## BLOWER DATA

### FACTORY INSTALLED BELT DRIVE KIT SPECIFICATIONS

Motor Efficiency	Nominal hp	Maximum hp	Drive Kit Number	RPM Range
Standard or High	2	2.30	1	535 - 725
Standard or High	2	2.30	2	710 - 965
Standard	3	3.45	1	535 - 725
Standard	3	3.45	2	710 - 965
Standard	5	5.75	3	685 - 856
Standard	5	5.75	4	850 - 1045
Standard	5	5.75	5	945 - 1185
Standard	7.5	8.63	6	850 - 1045
Standard	7.5	8.63	7	945 - 1185
Standard	7.5	8.63	8	1045 - 1285
Standard	10	11.50	7	945 - 1185
Standard	10	11.50	10	1045 - 1285
Standard	10	11.50	11	1135 - 1365

NOTE - Using total air volume and system static pressure requirements determine from blower performance tables rpm and motor output required. Maximum usable output of motors furnished are shown. In Canada, nominal motor output is also maximum usable motor output. If motors of comparable output are used, be sure to keep within the service factor limitations outlined on the motor nameplate.

### FACTORY INSTALLED OPTIONS/FIELD INSTALLED ACCESSORY AIR RESISTANCE - in. w.g.

Air Volume cfm	Wet Indoor Coil		Condenser Reheat Coil	Gas Heat Exchanger			Electric Heat	Economizer	Filters		Horizontal Roof Curb	
	180S, 210S	240S, 300S		Standard Heat	Medium Heat	High Heat			MERV 8	MERV 13	180S- 240S	300S
2750	.01	.02	.01	.02	.04	.05	---	---	.01	.03	.03	---
3000	.01	.02	.01	.03	.04	.05	---	---	.01	.03	.04	---
3250	.01	.03	.01	.03	.05	.06	---	---	.01	.04	.04	.01
3500	.01	.03	.02	.03	.05	.06	---	---	.01	.04	.05	.01
3750	.01	.03	.02	.04	.06	.07	---	---	.01	.04	.05	.01
4000	.02	.04	.02	.04	.06	.07	---	---	.01	.04	.06	.02
4250	.02	.04	.02	.04	.06	.08	---	---	.01	.05	.07	.02
4500	.02	.05	.02	.05	.07	.09	---	---	.01	.05	.07	.02
4750	.02	.05	.02	.05	.08	.10	---	---	.02	.05	.08	.03
5000	.02	.05	.02	.05	.09	.11	---	---	.02	.06	.08	.03
5250	.02	.06	.03	.06	.10	.12	---	---	.02	.06	.09	.04
5500	.02	.07	.03	.06	.10	.13	---	---	.02	.06	.10	.04
5750	.03	.07	.03	.06	.11	.14	---	---	.02	.07	.11	.05
6000	.03	.08	.03	.07	.12	.15	.01	---	.03	.07	.11	.06
6250	.03	.08	.03	.07	.12	.16	.01	.01	.03	.07	.12	.07
6500	.03	.09	.04	.08	.13	.17	.01	.02	.03	.08	.13	.08
6750	.04	.10	.04	.08	.14	.18	.01	.03	.03	.08	.14	.08
7000	.04	.10	.04	.09	.15	.19	.01	.04	.04	.08	.15	.09
7250	.04	.11	.04	.09	.16	.20	.01	.05	.04	.09	.16	.10
7500	.05	.12	.05	.10	.17	.21	.01	.06	.04	.09	.17	.11
8000	.05	.13	.05	.11	.19	.24	.02	.09	.05	.10	.19	.13
8500	.06	.15	.05	.12	.20	.26	.02	.11	.05	.10	.21	.15
9000	.07	.16	.06	.13	.23	.29	.04	.14	.06	.11	.24	.17
9500	.08	.18	.07	.14	.25	.32	.05	.16	.07	.12	.26	.19
10,000	.08	.20	.07	.16	.27	.35	.06	.19	.07	.12	.29	.21
10,500	.09	.22	.08	.17	.30	.38	.09	.22	.08	.13	.31	.24
11,000	.11	.24	.08	.18	.31	.40	.11	.25	.09	.14	.34	.27

**TABLE 4  
MANUFACTURER'S NUMBERS**

Drive No.	H.P.	DRIVE COMPONENTS									
		RPM		ADJUSTABLE SHEAVE		FIXED SHEAVE		BELTS		SPLIT BUSHING	
		Min	Max	Supplier No.	OEM Part No.	Supplier No.	OEM Part No.	Supplier No.	OEM Part No.	Supplier No.	OEM Part No.
1	2, 3	535	725	1VP40x7/8	79J0301	BK95X1-3/16	105617-02	BX59	59A5001	N/A	N/A
2	2, 3	710	965	1VP40x7/8	79J0301	BK72x1-3/16	105617-01	BX55	63K0501	N/A	N/A
3	5	685	865	1VP50x1-1/8	P-8-1977	BK100x1-3/16	105617-03	BX61	93J9801	N/A	N/A
4	5	850	1045	1VP65x1-1/8	100239-03	BK110H	100788-06	BX65	100245-08	H-1-3/16	105616-02
5	5	945	1185	1VP60x1-1/8	41C1301	BK90H	100788-04	BX72	57A7701	H-1-3/16	105616-02
6	7.5	850	1045	1VP65x1-3/8	78M7101	BK110H	100788-06	BX66	97J5901	H-1-3/16	105616-02
7	7.5, 10	945	1185	1VP60x1-3/8	78L5501	BK90H	100788-04	BX63	97J5501	H-1-3/16	105616-02
8	7.5	1045	1285	1VP65x1-3/8	78M7101	BK90H	100788-04	BX64	97J5801	H-1-3/16	105616-02
10	10	1045	1285	1VP65x1-3/8	78M7101	1B5V86	78M8301	5VX670	100245-21	B-1-3/16	105616-01
11	10	1135	1365	1VP65x1-3/8	78M7101	1B5V80	100240-05	5VX660	100245-20	B-1-3/16	105616-01

### Cooling Start-Up

**IMPORTANT-***The crankcase heater must be energized for 24 hours before attempting to start compressor. Set thermostat so there is no demand to prevent compressors from cycling. Apply power to unit.*

**NOTE -** *These units must not be used as a "construction heater" at any time during any phase of construction. Very low return air temperatures, harmful vapors and misplacement of the filters will damage the unit and its efficiency. Additionally, a unit which will be subject to cold temperatures when not in operation must have a vapor barrier installed to seal the duct connections. Failure to protect the unit from moisture laden air or harmful vapors (generated from the construction process and temporary combustion heating equipment) will cause corrosive condensation within the unit. Failure to properly protect the unit in this situation will cause electrical and electronic component failure and could affect the unit warranty status.*

### A-Operation

*Supply Air Inverter Units - Refer to the Inverter Start-Up section.*

- 1- Remove coil covers before starting unit.
- 2- Initiate first and second stage cooling demands according to instructions provided with thermostat.
- 3- Compressor Operation

*180S, 210S, 240S, Units -*

First-stage thermostat demand will energize compressors 1 & 2; a second-stage thermostat demand will energize compressor 3.

*300S Units -*

First-stage thermostat demand will energize compressors 1 & 2. Second-stage thermostat demand will energize compressors 3 & 4.

On units with an economizer, when outdoor air is acceptable, a first-stage demand will energize the economizer; a second-stage demand will energize compressors 1 and 2.



### 4- Refrigerant Circuits


*180S, 210S, 240S, Units-*

Units contain three refrigerant circuits or systems. Evaporator and condenser coil refrigerant circuits 1 and 2 make up stage 1 cooling. Evaporator and condenser refrigerant circuit 3 makes up stage 2 cooling. See figure 12 for 180S, and 210S units. See figure 13 for 240S units.

*300S units-*

Units contain four refrigerant circuits or systems. Evaporator and condenser coil refrigerant circuits 1 and 2 make up stage 1 cooling. Evaporator and condenser refrigerant circuits 3 and 4 make up stage 2 cooling. See figure 14.





**FIGURE 14**


**5- Condenser Fan Operation**

*180S, 210S -*


First-stage thermostat demand will energize condenser fans 1, 2 and 3. Fans will continue to operate with additional thermostat demands. See figure 15.

*240S-*

First-stage thermostat demand will energize condenser fans 1, 2, 3 and 4. See figure 16. Fans will continue to operate with additional thermostat demands.



**FIGURE 15**



**FIGURE 16**

300S-

First-stage thermostat demand will energize condenser fans 1, 2 and 3. Second-stage cooling demand will energize condenser fans 4, 5 and 6. See figure 17 .




FIGURE 17

6- Each refrigerant circuit is separately charged with R-410A refrigerant. See unit rating plate for correct amount of charge.

7- Refer to Cooling Operation and Adjustment section for proper method to check refrigerant charge.

### B-R410A Refrigerant

Units charged with R410A refrigerant operate at much higher pressures than R22. The expansion valve and liquid line drier provided with the unit are approved for use with R410A. Do not replace them with components designed for use with R22.

R410A refrigerant is stored in a pink cylinder.

## ⚠ IMPORTANT

**Mineral oils are not compatible with R410A. If oil must be added, it must be a polyol ester oil.**

Manifold gauge sets used with systems charged with R410A refrigerant must be capable of handling the higher system operating pressures. The gauges should be rated for use with pressures of 0-800 on the high side and a low side of 30" vacuum to 250 psi with dampened speed to 500 psi. Gauge hoses must be rated for use at up to 800 psi of pressure with a 4000 psi burst rating.

### C-Refrigerant Charge and Check - All-Aluminum Coils

**WARNING-Do not exceed nameplate charge under any condition.**

This unit is factory charged and should require no further adjustment. If the system requires additional refrigerant, reclaim the charge, evacuate the system, and add required nameplate charge.

*NOTE - System charging is not recommended below 60°F (15°C). In temperatures below 60°F (15°C), the charge **must** be weighed into the system.*

If weighing facilities are not available, or to check the charge, use the following procedure:

### IMPORTANT - Charge unit in standard cooling mode.

- 1- Make sure outdoor coil is clean. Attach gauge manifolds and operate unit at full CFM in cooling mode with economizer disabled until system stabilizes (approximately five minutes). Make sure all outdoor air dampers are closed.
- 2- Check each system separately with all stages operating. Compare the normal operating pressures (see tables 5 -7) to the pressures obtained from the gauges. Check unit components if there are significant differences.
- 3- Measure the outdoor ambient temperature and the suction pressure. Refer to the appropriate circuit charging curve to determine a target liquid temperature.

*Note - Pressures are listed for sea level applications.*


- 4- Use the same thermometer to accurately measure the liquid temperature (in the outdoor section).
  - If measured liquid temperature is higher than the target liquid temperature, add refrigerant to the system.
  - If measured liquid temperature is lower than the target liquid temperature, recover some refrigerant from the system.
- 5- Add or remove charge in increments. Allow the system to stabilize each time refrigerant is added or removed.
- 6- Continue the process until measured liquid temperature agrees with the target liquid temperature. Do not go below the target liquid temperature when adjusting charge. Note that suction pressure can change as charge is adjusted.
- 7- Example KG/KC 180S units, Circuit 1: At 95°F outdoor ambient and a measured suction pressure of 130psig, the target liquid temperature is 99.5°F. For a measured liquid temperature of 106°F, add charge in increments until measured liquid temperature agrees with the target liquid temperature.

**TABLE 5  
KGC/KCC 180S ALL-ALUMINUM COIL NORMAL OPERATING PRESSURES - 581137-01**

	Outdoor Coil Entering Air Temperature											
	65 °F		75 °F		85 °F		95 °F		105 °F		115 °F	
	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)
Circuit 1	117	239	119	279	121	324	123	375	125	431	127	493
	126	242	128	282	130	327	132	376	134	433	137	493
	144	250	146	288	149	333	151	383	154	437	156	498
	161	259	165	297	168	341	173	390	175	444	178	504
Circuit 2	116	239	118	279	120	324	121	374	123	431	125	486
	124	242	126	282	128	327	130	375	132	433	134	489
	143	250	145	288	147	333	150	381	152	437	154	493
	161	259	165	297	168	341	171	390	174	444	177	500
Circuit 3	115	249	117	289	119	334	121	384	122	439	124	499
	124	252	126	292	128	337	130	386	132	441	134	501
	142	260	144	300	147	344	149	393	152	448	154	507
	159	270	163	310	167	354	171	403	173	457	176	515


**KGC/KCC 180S CHARGING CURVE CIRCUIT 1 - 581136-01**

Outdoor Temperature (°F)




### KGC/KCC 180S CHARGING CURVE CIRCUIT 2 - 581136-01

Outdoor Temperature (°F)




### KGC/KCC 180S CHARGING CURVE CIRCUIT 3 - 581136-01

Outdoor Temperature (°F)




**TABLE 6  
KGC/KCC 210S ALL-ALUMINUM OD COIL, NORMAL OPERATING PRESSURES - 581139-01**

	Outdoor Coil Entering Air Temperature											
	65 °F		75 °F		85 °F		95 °F		105 °F		115 °F	
	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)
Circuit 1	110	250	112	292	113	346	115	405	117	484	120	576
	118	252	120	290	122	341	123	397	126	475	128	558
	134	260	137	294	140	340	143	401	146	464	148	538
	150	272	155	307	158	348	163	405	166	462	170	533
Circuit 2	110	250	113	292	115	340	117	393	119	456	122	527
	119	253	121	293	123	340	125	393	128	454	130	518
	134	263	137	300	141	344	144	395	147	454	149	520
	151	276	156	314	159	357	164	408	167	462	170	524
Circuit 3	110	261	112	303	114	352	116	407	119	467	122	534
	118	264	120	307	123	355	125	408	128	469	131	534
	135	276	138	317	141	364	144	418	147	475	150	539
	153	292	157	331	160	377	164	427	167	484	171	547




### KGC/KCC 210S CHARGING CURVE CIRCUIT 2 - 581138-01

Outdoor Temperature (°F)



### KGC/KCC 210S CHARGING CURVE CIRCUIT 3 - 581138-01


Outdoor Temperature (°F)



**TABLE 7  
KGC/KCC 240S ALL-ALUMINUM OD COIL NORMAL OPERATING PRESSURES - 581141-01**


	Outdoor Coil Entering Air Temperature											
	65 °F		75 °F		85 °F		95 °F		105 °F		115 °F	
	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)
Circuit 1	106	250	108	293	111	347	113	413	116	490	119	579
	114	248	117	288	119	339	122	402	125	476	128	562
	133	255	135	288	138	334	141	391	144	459	147	540
	155	276	157	304	160	344	162	395	165	458	168	532
Circuit 2	108	250	110	291	112	339	114	393	116	453	117	521
	117	252	119	292	121	339	123	392	125	452	127	518
	135	260	138	298	140	343	143	394	145	452	148	517
	155	273	159	309	162	352	165	401	168	457	171	519
Circuit 3	104	260	107	303	109	353	111	408	113	470	116	539
	113	262	115	304	117	352	120	407	122	468	124	535
	131	271	133	310	136	356	139	409	141	468	144	533
	152	285	154	323	157	367	160	417	163	474	166	537

**KGC/KCC 240S CHARGING CURVE CIRCUIT 1 - 581140-01** Outdoor Temperature (°F)




### KGC/KCC 240S CHARGING CURVE CIRCUIT 2 - 581140-01

Outdoor Temperature (°F)




### KGC/KCC 240S CHARGING CURVE CIRCUIT 3 - 581140-01

Outdoor Temperature (°F)




**TABLE 8**  
**KGC/KCC 300S ALL-ALUMINUM OD COIL, NO REHEAT NORMAL OPERATING PRESSURES - 581143-01**


	Outdoor Coil Entering Air Temperature											
	65 °F		75 °F		85 °F		95 °F		105 °F		115 °F	
	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)
Circuit 1	112	260	113	302	115	349	117	401	119	459	121	523
	120	264	122	305	124	352	126	404	128	462	131	525
	137	273	140	313	142	359	145	410	147	467	150	529
	155	283	158	322	161	367	164	417	167	473	171	535
Circuit 2	114	245	116	285	117	329	119	379	121	434	123	494
	121	249	124	289	126	333	128	383	130	438	133	497
	137	257	140	297	144	341	147	390	150	445	153	505
	154	265	158	304	161	348	165	397	169	451	173	511
Circuit 3	95	259	97	300	99	346	102	398	104	454	107	515
	102	264	105	306	107	352	110	403	113	459	115	520
	118	274	121	315	124	362	127	413	130	469	134	530
	135	282	138	323	142	370	146	421	149	478	153	539
Circuit 4	98	251	100	294	102	341	104	393	106	450	108	511
	105	259	107	301	110	347	112	399	115	456	117	517
	121	269	124	310	127	357	130	408	133	464	136	524
	137	274	141	315	145	360	148	411	152	466	156	526




**KGC/KCC 300S NO REHEAT CHARGING CURVE CIRCUIT 2 - 581142-01** Outdoor Temperature (°F)



**KGC/KCC 300S NO REHEAT CHARGING CURVE CIRCUIT 3 - 581142-01** Outdoor Temperature (°F)




KGC/KCC 300S NO REHEAT CHARGING CURVE CIRCUIT 4 - 581142-01 Outdoor Temperature (°F)



**TABLE 9  
KGC/KCC 300S ALL-ALUMINUM OD COIL, REHEAT NORMAL OPERATING PRESSURES - 581175-01**


	Outdoor Coil Entering Air Temperature											
	65 °F		75 °F		85 °F		95 °F		105 °F		115 °F	
	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)	Suct (psig)	Disc (psig)
Circuit 1	111	270	113	310	115	355	117	405	119	461	121	522
	120	274	122	314	124	358	126	408	128	463	130	524
	137	285	140	323	142	367	145	416	147	470	150	529
	155	298	158	335	161	378	165	425	168	478	171	537
Circuit 2	111	260	114	297	117	340	119	389	121	443	123	502
	120	268	123	306	126	349	128	398	131	452	133	512
	137	280	140	319	143	363	147	413	150	468	153	529
	153	287	158	326	161	372	165	422	169	479	172	540
Circuit 3	95	263	97	304	100	350	102	401	104	458	106	519
	102	266	105	307	108	353	110	405	112	461	115	522
	118	274	122	315	125	361	128	412	130	468	133	529
	136	284	140	324	143	370	147	421	150	477	153	537
Circuit 4	97	258	99	300	101	346	103	398	105	456	108	518
	105	263	107	304	109	351	112	402	114	459	117	521
	120	272	123	312	126	358	129	409	132	466	136	527
	137	280	141	320	145	365	148	416	152	472	156	532

**KGC/KCC 300S REHEAT CHARGING CURVE CIRCUIT 1 - 581170-01** Outdoor Temperature (°F)




**KGC/KCC 300S REHEAT CHARGING CURVE CIRCUIT 2 - 581170-01**

Outdoor Temperature (°F)




**KGC/KCC 300S REHEAT CHARGING CURVE CIRCUIT 3 - 581170-01**

Outdoor Temperature (°F)



## KGC/KCC 300S REHEAT CHARGING CURVE CIRCUIT 4 - 581170-01

Outdoor Temperature (°F)



### D-Refrigerant Charge and Check - Fin/Tube Coil

**WARNING-Do not exceed nameplate charge under any condition.** This unit is factory charged and should require no further adjustment. If the system requires additional refrigerant, reclaim the charge, evacuate the system and add required nameplate charge.

**NOTE - System charging is not recommended below 60°F (15°C). In temperatures below 60°F (15°C), the charge *must* be weighed into the system.**

If weighing facilities are not available, or to check the charge, use the following procedure:

#### **IMPORTANT - Charge unit in normal cooling mode.**

- 1- Attach gauge manifolds and operate unit in cooling mode with economizer disabled until system stabilizes (approximately five minutes). Make sure all outdoor air dampers are closed.
- 2- Check each system separately with all stages operating.
- 3- Use a thermometer to accurately measure the outdoor ambient temperature.

- 4- Apply the outdoor temperature to tables 10 through 16 to determine normal operating pressures. Pressures are listed for sea level applications at 80°F dry bulb and 67°F wet bulb return air.
- 5- Compare the normal operating pressures to the pressures obtained from the gauges. Minor variations in these pressures may be expected due to differences in installations. Significant differences could mean that the system is not properly charged or that a problem exists with some component in the system. **Correct any system problems before proceeding.**
- 6- If discharge pressure is high, remove refrigerant from the system. If discharge pressure is low, add refrigerant to the system.
  - Add or remove charge in increments.
  - Allow the system to stabilize each time refrigerant is added or removed.
- 7- Use the following approach method along with the normal operating pressures to confirm readings.

**TABLE 10 - 581144-01**  
KGC/KCC180S Fin/Tube No Reheat

Outdoor Coil Entering Air Temp	Circuit 1		Circuit 2		Circuit 3	
	Dis. ±10 psig	Suc. ±5 psig	Dis. ±10 psig	Suc. ±5 psig	Dis. ±10 psig	Suc. ±5 psig
65°F	271	143	272	142	287	141
75°F	310	146	310	145	326	144
85°F	353	149	353	147	369	146
95°F	400	151	399	150	417	149
105°F	451	153	448	152	467	151
115°F	508	157	501	155	522	155

**TABLE 11 - 581173-01**  
KGC/KCC180S Fin/Tube With Reheat

Outdoor Coil Entering Air Temp	Circuit 1		Circuit 2		Circuit 3	
	Dis. ±10 psig	Suc. ±5 psig	Dis. ±10 psig	Suc. ±5 psig	Dis. ±10 psig	Suc. ±5 psig
65°F	289	143	291	142	286	140
75°F	329	145	331	145	325	143
85°F	373	148	375	147	367	145
95°F	422	150	424	150	414	148
105°F	477	153	478	152	464	151
115°F	537	156	537	155	518	154

**TABLE 12 - 581145-01**  
KGC/KCC210S Fin/Tube No Reheat

Outdoor Coil Entering Air Temp	Circuit 1		Circuit 2		Circuit 3	
	Dis. ±10 psig	Suc. ±5 psig	Dis. ±10 psig	Suc. ±5 psig	Dis. ±10 psig	Suc. ±5 psig
65°F	282	133	291	138	307	136
75°F	322	137	331	140	347	138
85°F	368	140	374	142	391	140
95°F	418	143	422	145	440	142
105°F	472	146	475	148	493	145
115°F	532	149	530	151	549	148

**TABLE 13 - 581172-01**  
KGC/KCC210S Fin/Tube With Reheat

Outdoor Coil Entering Air Temp	Circuit 1		Circuit 2		Circuit 3	
	Dis. ±10 psig	Suc. ±5 psig	Dis. ±10 psig	Suc. ±5 psig	Dis. ±10 psig	Suc. ±5 psig
65°F	301	134	305	137	308	136
75°F	340	138	344	140	348	138
85°F	386	140	387	143	393	140
95°F	438	143	433	146	442	143
105°F	492	146	485	148	494	145
115°F	554	150	539	151	551	149

**TABLE 14 - 581146-01**  
KGC/KCC240S Fin/Tube No Reheat

Outdoor Coil Entering Air Temp	Circuit 1		Circuit 2		Circuit 3	
	Dis. ±10 psig	Suc. ±5 psig	Dis. ±10 psig	Suc. ±5 psig	Dis. ±10 psig	Suc. ±5 psig
65°F	279	135	288	135	301	133
75°F	317	138	331	138	341	135
85°F	357	141	373	141	385	138
95°F	405	143	427	143	432	140
105°F	461	145	477	146	482	143
115°F	514	148	533	149	534	146

**TABLE 15 - 581171-01**  
KGC/KCC240S Fin/Tube With Reheat

Outdoor Coil Entering Air Temp	Circuit 1		Circuit 2		Circuit 3	
	Dis. ±10 psig	Suc. ±5 psig	Dis. ±10 psig	Suc. ±5 psig	Dis. ±10 psig	Suc. ±5 psig
65°F	293	135	305	136	300	133
75°F	332	138	340	138	335	135
85°F	369	139	382	140	377	137
95°F	423	142	433	143	429	140
105°F	464	144	488	146	472	143
115°F	528	148	549	150	540	147

**TABLE 16 581147-01a**  
KGC/KCC 300S Fin/Tube No Reheat

Outdoor Coil Entering Air Temp	Circuit 1		Circuit 2		Circuit 3		Circuit 4	
	Dis. ±10 psig	Suc. ±5 psig						
75 °F	274	124	262	124	277	113	276	114
75 °F	316	132	305	133	322	119	319	121
85 °F	361	137	351	141	366	122	365	125
95 °F	407	140	397	144	415	125	412	128
105 °F	461	143	455	147	469	128	465	131
115 °F	517	146	513	149	528	132	522	134

**E-Charge Verification - Approach Method - AHRI Testing (Fin/Tube Coil)**

- Using the same thermometer, compare liquid temperature to outdoor ambient temperature.  
Approach Temperature = Liquid temperature (at condenser outlet) minus ambient temperature.
- Approach temperature should match values in table 17. An approach temperature greater than value shown indicates an undercharge. An approach temperature less than value shown indicates an overcharge.
- The approach method is not valid for grossly over or undercharged systems. Use tables 10 through 16 as a guide for typical operating pressures.

**TABLE 17**  
**Approach Temperatures - Fin/Tube Coil**

KG/KB Unit	Liquid Temp. Minus Ambient Temp.			
	1st Stage	2nd Stage	3rd Stage	4th Stage
180S	6.7°F ± 1 (3.7°C ±0.5)	7.2°F ± 1 (4.0°C ±0.5)	11.5°F ± 1 (6.4°C ±0.5)	NA
180S Reheat	4.6°F ± 1 (2.5°C ±0.5)	4.5°F ± 1 (2.5°C ±0.5)	12.0°F ± 1 (6.7°C ±0.5)	NA
210S	6.3°F ± 1 (3.5°C ±0.5)	6.1°F ± 1 (3.4°C ±0.5)	9.8°F ± 1 (5.4°C ±0.5)	NA
210S Reheat	5.5°F ± 1 (3.1°C ±0.5)	6.2°F ± 1 (3.4°C ±0.5)	10.2°F ± 1 (5.7°C ±0.5)	NA
240S	7.6°F ± 1 (4.2°C ±0.5)	4.9°F ± 1 (2.7°C ±0.5)	8.5°F ± 1 (4.7°C ±0.5)	NA
240S Reheat	5.0°F ± 1 (2.8°C ±0.5)	3.5°F ± 1 (1.9°C ±0.5)	7.1°F ± 1 (3.9°C ±0.5)	NA
300S	6.0°F ± 1 (3.3°C ±0.5)	4.0°F ± 1 (2.2°C ±0.5)	9.0°F ± 1 (5.0°C ±0.5)	8.0°F ± 1 (4.4°C ±0.5)

**F-Compressor Controls**

See unit wiring diagram to determine which controls are used on each unit. Optional controls are identified on wiring diagrams by arrows at junction points.

- 1- Freezestats (S49, S50, S53, S95)  
Switches de-energize compressors when evaporator coil temperature falls below 29°F (-2°C) to prevent evaporator freeze-up. Switches reset when evaporator coil temperature reaches 58°F (15°C).
- 2- High Pressure Switches (S4, S7, S28, S96)  
Switches open to de-energize appropriate compressor at 640 psig ± 20 psig (4413kPa ± 138kPa). Switch must be manually reset.
- 3- Thermal Protector (S5, S8, S31, S180)  
The compressors used on 180S/H, 210S/H, 240S/H and 300S units are each protected by an internal thermal protector switch.
- 4- Crankcase Heater (HR1, HR2, HR5, HR11)  
Units have compressors which contain a belly band compressor oil heater which must be on 24 hours before running compressors. Energize by setting thermostat so that there is no cooling demand, to prevent compressor from cycling, and apply power to unit.

**Gas Heat Start-Up (Gas Units)**

**FOR YOUR SAFETY READ BEFORE LIGHTING**

**⚠ WARNING**



**Electric shock hazard. Can cause injury or death. Do not use this unit if any part has been under water. Immediately call a qualified service technician to inspect the unit and to replace any part of the control system and any gas control which has been under water.**

**⚠ WARNING**



**Danger of explosion. Can cause injury or product or property damage. If overheating occurs or if gas supply fails to shut off, shut off the manual gas valve to the appliance before shutting off electrical supply.**

**⚠ WARNING**



**Electric shock hazard. Can cause injury or death. Before attempting to perform any service or maintenance, turn the electrical power to unit OFF at disconnect switch(es). Unit may have multiple power supplies.**

**⚠ WARNING**

**SMOKE POTENTIAL**

**The heat exchanger in this unit could be a source of smoke on initial firing. Take precautions with respect to building occupants and property. Vent initial supply air outside when possible.**

BEFORE LIGHTING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, do not try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.

**⚠ WARNING**



**Danger of explosion. Can cause injury or death. Do not attempt to light manually. Unit has a direct spark ignition system.**

This unit is equipped with an automatic spark ignition system. There is no pilot. In case of a safety shutdown, move thermostat switch to **OFF** and return the thermostat switch to **HEAT** to reset ignition control.

## A-Placing Unit In Operation


### **⚠ WARNING**




**Danger of explosion and fire. Can cause injury or product or property damage. You must follow these instructions exactly.**

### Gas Valve Operation Honeywell VR8205Q/VR8305Q and White Rodgers 36H54 (figure 18 and 19)

- 1- Set thermostat to lowest setting.
- 2- Turn off all electrical power to appliance.
- 3- This appliance is equipped with an ignition device which automatically lights the burner. Do **not** try to light the burner by hand.
- 4- Open or remove the heat section access panel.



**FIGURE 18**



**FIGURE 19**

5- Turn gas valve switch to **OFF**. See figure 18. On Honeywell VR8305Q gas valves, turn the knob on the gas valve clockwise  to "**OFF**". Do not force. See figure 19.

6- Wait five (5) minutes to clear out any gas. If you then smell gas, **STOP!** Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions. If you do not smell gas, go to the next step.

7- Turn gas valve switch to **ON**. See figure 18. On Honeywell VR8305Q gas valves, turn the knob on the gas valve counterclockwise  to "**ON**". Do not force. See figure 19.

8- Close or replace the heat section access panel.

9- Turn on all electrical power to appliance.

10- Set thermostat to desired setting.

11- The ignition sequence will start.

12- If the appliance does not light the first time (gas line not fully purged), it will attempt up to two more ignitions before locking out.

13- If lockout occurs, repeat steps 1 through 10.

14- If the appliance will not operate, follow the instructions "Turning Off Gas to Appliance" and call your service technician or gas supplier.

### Turning Off Gas to Unit

1- If using an electromechanical thermostat, set to the lowest setting.

2- Before performing any service, turn off all electrical power to the appliance.

3- Open or remove the heat section access panel.

4- Turn gas valve switch to **OFF**. On Honeywell VR8305Q gas valves, turn the knob on the gas valve clockwise  to "**OFF**". Do not force.

5- Close or replace the heat section access panel.

### **⚠ WARNING**



**Danger of explosion. Can cause injury or death. Do not attempt to light manually. Unit has a direct spark ignition system.**

## Heating Operation and Adjustments

### (Gas Units)

#### First Stage Heat:

- 1- The thermostat initiates W1 heating demand.
- 2- 24VAC is routed from TB1 to ignition control A3 through P117. A3 proves N.C. primary limit S10 and N.C. rollout switch S47.
- 3- Combustion air inducer blower B6 is energized.
- 4- After the combustion air inducer B6 has reached full speed, the combustion air proving switch S18 contacts close.
- 5- After a 30 second delay A3 energizes the ignitor and LO terminal (low fire) of gas valve GV1.

#### Second Stage Heat:

- 6- With first stage heat operating, an additional heating demand from the thermostat initiates W2.
- 7- The second stage heat signal passes from TB1 to A3.
- 8- A3 energizes HI terminal (high fire) of gas valve GV1.

#### End of Second Stage Heat:

- 9- Heating demand is satisfied. Terminal W2 (high fire) is de-energized.
- 10- Terminal HI of GV1 is de-energized by A3 control module.

#### End of First Stage Heat:

- 11- Heating demand is satisfied. Terminal W1 (low fire) is de-energized.
- 12- Ignition A3 is de-energized by TB1 in turn de-energizing terminal LO of GV1.

#### Optional Low Ambient Kit:

##### (CSA -50°C Low Ambient Kit)

- 13- Line voltage (or transformer T20 in 460V and 575V only) is routed through the low ambient kit fuses F20 and N.C. low ambient kit thermostats S60 and S61, to energize low ambient kit heater HR6.

## B-Ignition Control Diagnostic LED's

TABLE 18  
IGNITION CONTROL HEARTBEAT LED STATUS

LED Flashes	Indicates
Slow	Normal operation. No call for heat.
Fast	Normal operation. Call for heat.
Steady Off	Internal control fault OR no power to control OR Gas Valve Relay Fault.
Steady On	Control internal failure.
2	Lockout. Failed to detect or sustain flame.
3	Prove switch open or closed or rollout switch open.
4	Limit switch is open and/or limit has opened three times.
5	Flame sensed but gas valve solenoid not energized.

## C-Limit Controls

Limit controls are factory-set and are not adjustable. The primary limit is located on the blower deck to the left side of the the blower housing.

## D-Heating Adjustment

Main burners are factory-set and do not require adjustment.

The following manifold pressures are listed on the gas valve.

Natural Gas Units - Low Fire - 1.6" w.c. (not adjustable)

Natural Gas Units - High Fire - 3.7" w.c.

LP Gas Units - Low Fire - 5.5" w.c. (not adjustable)

LP Gas Units - High Fire - 10.5" w.c.

## Electric Heat Start-Up (KC Unit)

Electric heat will stage on and cycle with thermostat demand. Number of stages of electric heat will vary depending on electric heat assembly. See electric heat wiring diagram on unit for sequence of operation.

## Inverter Start-Up

### A-General

Units provide two blower speeds. The blower will operate at lower speeds when cooling demand is low and higher speeds when cooling demand is high. This results in lower energy consumption.

Supply air inverter units will operate at high speed during ventilation (blower "G" only signal) but can be adjusted to operate at low speed.

Low speed is approximately 2/3 of the full speed RPM.

### B-Set Maximum Blower CFM

- 1- Initiate a blower (G) only signal from the room thermostat or control system.
- 2- Adjust the blower pulley to deliver the full (high speed) CFM in the typical manner. See *Determining Unit CFM* in the Blower Operation and Adjustment section.

### C-Set Blower Speed During Ventilation

To save energy during ventilation, the blower speed can be set to low. This is accomplished by changing the ventilation speed switch on the VFD control board to "LO". See figure 20.

*Note - On units equipped with an economizer, set damper minimum position as shown in the next section. After adjusting the low speed minimum position, the ventilation speed switch will be in the "LO" position.*




FIGURE 20

### D-Set Damper Minimum Position (Units W/ Economizer)

To maintain required minimum ventilation air volumes when the unit is in the occupied mode, two minimum damper positions must be set. A high and a low speed potentiometer are provided on the VFD control board to adjust minimum damper position. See figure 20.

#### Set High Speed Minimum Position

- 1- Initiate a blower (G) only AND occupied demand from the room thermostat or control system.
- 2- Set the ventilation speed switch on the VFD control board to "HI".
- 3- Rotate the high speed potentiometer on the VFD control board to set the high speed minimum damper position.
- 4- Measure the intake air CFM. If the CFM is lower than the design specified CFM for ventilation air, use the potentiometer to increase the damper percent open. If the CFM is higher than specified, decrease the damper percent open.

*Note - Intake air CFM can also be determined using the outdoor air temperature, return air temperature and mixed air temperature. Refer to the economizer or outdoor air damper installation instructions.*

#### Set Low Speed Minimum Position

- 1- Initiate a blower (G) only AND occupied demand from the room thermostat or control system.
- 2- Set the ventilation speed switch on the VFD control board to "LO".
- 3- Rotate the low speed potentiometer on the VFD control board to set the low speed minimum damper position.
- 4- Measure the intake air CFM. If the CFM is lower than the design specified CFM for ventilation air, use the potentiometer to increase the damper percent open. If the CFM is higher than specified, decrease the damper percent open.

*Note - Intake air CFM can also be determined using the outdoor air temperature, return air temperature and mixed air temperature. Refer to the economizer or outdoor air damper installation instructions.*

#### Troubleshoot LVC2 Board (A183)

Refer to wiring diagram sections B (unit), C (control) and D (economizer) located on inside of unit panels.

- 1- Inspect the LVC2 for damaged components. Replace the LVC2 if damaged components are found.
- 2- Check all wire connections to LVC2; secure if loose.

3- Check for 24VAC signal at the thermostat blower input (G to GND terminal). See figure 21.




FIGURE 21

- 4- If there is no thermostat signal, troubleshoot back toward the thermostat.
- 5- Check the power LED on the board. See figure 20.
- 6- If the power LED is not on, check voltage between LVC2 terminals PC (H2-1) and SD (H2-5). Voltage should read 24VDC.
- 7- If voltage does not read 24VDC, disconnect the H2 header from the LVC2 VFD terminal block (to make sure the LVC2 is not shorting 24VDC supply from the inverter). Measure the voltage between the end

terminals on the H2 header. If 24VDC is present, replace the LVC2 board. If no voltage is read, troubleshoot the VFD.

8- When LVC2 24VAC thermostat blower (G) input and 24VDC power are present, check the LVC2 low and high speed outputs. The LVC2 uses inverse logic to enable the blower; 1VDC will be read at the enabled blower speed terminal. See table 19.

9- If all inputs are correct and the unit still does not operate as intended, replace LVC2 board.

TABLE 19  
LVC2 BOARD BLOWER OUTPUTS

Output Terminals	Voltage	Blower Operation
RL-SD	1VDC	Low Speed
RH-SD	24VDC	
RL-SD	24VDC	High Speed
RH-SD	1VDC	
RL-SD	1VDC	Illegal State (replace board)
RH-SD	1VDC	
RL-SD	24VDC	Blower Off (replace board)
RH-SD	24VDC	

## Hot Gas Reheat Start-Up And Operation

**General**

Hot gas reheat units provide a dehumidifying mode of operation. These units contain a reheat coil adjacent to and downstream of the evaporator coil. Reheat coil solenoid valves, L14 and L30, route hot discharge gas from the compressor to the reheat coil. Return air pulled across the evaporator coil is cooled and dehumidified; the reheat coil adds heat to supply air.

See figure 22 for 180S, 210S, and 240S reheat refrigerant routing and figure 23 for 180S, 210S, and 240S normal cooling refrigerant routing. See figure 24 for 300S reheat refrigerant routing and figure 25 for 300S normal cooling refrigerant routing.

**L14 and L30 Reheat Coil Solenoid Valves**

When room conditions close the dehumidistat switch, L14 and L30 reheat valves are energized and refrigerant is routed to the reheat coil.

**Check-Out**

Test hot gas reheat operation using the following procedure.

- 1- Make sure reheat is wired as shown in wiring section.
- 2- Initiate a dehumidification demand by adjusting dehumidistat setpoint knob **BELOW** indoor relative humidity. The blower, compressor 1 and compressor 2 should be operating.
- 3- End a dehumidification demand by adjusting setpoint knob **ABOVE** indoor relative humidity. The blower, compressor 1, and compressor 2 should de-energize.

*Note - When a reheat demand is present, the blower will operate on high speed.*

**Default Reheat Operation**

Reheat will operate as shown in table 20 once three conditions are met:

- 1- Blower must be operating.
- 2- System must be in occupied mode.
- 3- System must NOT be operating in heating mode.

**IMPORTANT - Free cooling does not operate during reheat.**

**TABLE 20  
REHEAT OPERATION**


Two-Stage Thermostat		
T'stat and Humidity Demands	Operation	
	180S, 210S, 240S (3-Compressors)	300S (4-Compressors)
Reheat Only	Compressor 1 & 2 Reheat	Compressor 1 & 2 Reheat
Reheat & Y1	Compressor 1 & 2 Reheat and Compressor 3 Cooling <sup>1</sup>	Compressor 1 & 2 Reheat and Compressor 3 & 4 Cooling <sup>1</sup>
Reheat & Y1 & Y2	Compressor 1, 2, & 3 Cooling <sup>2</sup>	Compressor 1, 2, 3 & 4 Cooling <sup>2</sup>

\*Cooling stage is initiated when zone temperature is higher than the cooling setpoint plus the appropriate stage differential.


\*\*Reheat demand is initiated when relative humidity is higher than relative humidity setpoint.

<sup>1</sup>If there is no reheat demand and outdoor air is suitable, free cooling will operate.


<sup>2</sup>If there is no reheat demand and outdoor air is suitable, free cooling and compressor 1 and 2 will operate.




**FIGURE 22**



**FIGURE 23**



**FIGURE 24**



**FIGURE 25**

## Service

The unit should be inspected once a year by a qualified service technician.

## ⚠ CAUTION

**Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.**

### A-Filters

Units are equipped with six 24 X 24 X 2" filters. Filters should be checked and replaced when necessary with filters of like kind and size. Take note of air flow direction marking on filter frame when reinstalling filters. See figure 26.

*NOTE-Filters must be U.L.C. certified or equivalent for use in Canada.*




FIGURE 26

### B-Lubrication

All motors are lubricated at the factory. No further lubrication is required.

Blower shaft bearings are prelubricated. For extended bearing life, relubricate at least once every two years with a lithium base grease such as Alvania 3 (Shell Oil), Chevron BRB2 (Standard Oil) or Regal AFB2 (Texas Oil). Use a hand grease gun for lubrication. Add only enough grease to purge through the bearings so that a bead of grease appears at the seal lip contacts.

### C-Burners (Gas Units)

Periodically examine burner flames for proper appearance during the heating season. Before each heating season examine the burners for any deposits or blockage which may have occurred.

Clean burners as follows:

- 1- Turn off both electrical power and gas supply to unit.
- 2- Remove burner compartment access panel.
- 3- Remove screws securing burners to burner support and lift the individual burners or the entire burner assembly from the orifices. See figure 27. Clean as necessary.




FIGURE 27

- 4- Locate the ignitor under the left burners. Check ignitor spark gap with appropriately sized twist drills or feeler gauges. See figure 28.
- 5- Check the alignment of the ignitor and the sensor as shown in figure 29 and table 21.
- 6- Replace burners and screws securing burner.




FIGURE 28

TABLE 21  
IGNITOR AND SENSOR POSITION

Dimension	Unit Btuh Input	Length - in. (mm)	
		Ignitor	Sensor
A	260K	7-3/4 (197)	11 (279)
B	360K	5 (127)	5-1/2 (140)
C	480K	2-1/4 (57)	2-3/4 (70)

**⚠ WARNING**

**Danger of explosion. Can cause injury or death. Do not overtighten main burner mounting screws. Snug tighten only.**

7- Replace access panel.

8- Restore electrical power and gas supply. Follow lighting instructions attached to unit and use inspection port in access panel to check flame.

**D-Combustion Air Inducer (Gas Units)**

A combustion air proving switch checks combustion air inducer operation before allowing power to the gas controller. Gas controller will not operate if inducer is obstructed.

Under normal operating conditions, the combustion air inducer wheel should be checked and cleaned prior to the heating season. However, it should be examined periodically during the heating season to establish an ideal cleaning schedule. With power supply disconnected, the condition of the inducer wheel can be determined by looking through the vent opening.

Clean combustion air inducer as follows:

- 1- Shut off power supply and gas to unit.
- 2- Disconnect pressure switch air tubing from combustion air inducer port.
- 3- Remove and retain screws securing combustion air inducer to flue box. Remove and retain two screws from bracket supporting vent connector. See figure 30.





FIGURE 29



**FIGURE 30**

- 4- Clean inducer wheel blades with a small brush and wipe off any dust from housing. Clean accumulated dust from front of flue box cover.
- 5- Return combustion air inducer motor and vent connector to original location and secure with retained screws. It is recommended that the combustion air inducer gasket be replaced during reassembly.
- 6- Clean combustion air inlet louvers on heat access panel using a small brush.

**E-Flue Passageway and Flue Box (Gas Units)**

- 1- Remove combustion air inducer assembly as described in section D.
- 2- Remove flue box cover. Clean with a wire brush as required.
- 3- Clean tubes with a wire brush.
- 4- Reassemble the unit. The flue box cover gasket and combustion air inducer gasket should also be replaced during reassembly.

**F-Evaporator Coil**

Inspect and clean coil at beginning of each cooling season. Clean using mild detergent or commercial coil cleaner. Flush coil and condensate drain with water taking care not to get insulation, filters and return air ducts wet.

**G-Condenser Coil**

Clean condenser coil annually with water and inspect monthly during the cooling season.

Clean the coil by spraying the coil steadily and uniformly from top to bottom. Do not exceed 900 psi or a 45° angle; nozzle must be at least 12 inches from the coil face. Take care not to fracture the braze between the fins and refrigerant tubes. Reduce pressure and work cautiously to prevent damage.

**H-Supply Air Blower Wheel**

Annually inspect supply air blower wheel for accumulated dirt or dust. Turn off power before attempting to remove access panel or to clean blower wheel.

## START-UP REPORT

Job Name: \_\_\_\_\_  
 Store No. \_\_\_\_\_ Start-Up Date: \_\_\_\_\_  
 Address: \_\_\_\_\_  
 City: \_\_\_\_\_ State: \_\_\_\_\_  
 Start-Up Contractor: \_\_\_\_\_  
 Technician: \_\_\_\_\_  
 Model No.: \_\_\_\_\_  
 Serial No.: \_\_\_\_\_  
 RTU No.: \_\_\_\_\_ Catalog No.: \_\_\_\_\_

Inspections and Checks			
Damage?	Yes	No	R22 <input type="checkbox"/> R410A <input type="checkbox"/>
If yes, reported to: _____			
Verify factory and field-installed accessories.			
Check electrical connections. Tighten if necessary.			
Supply voltage: L1-L2 _____ L1-L3 _____ L2-L3 _____			
If unit contains a 208-230/240 volt transformer:			
Check primary transformer tap <input type="checkbox"/>			
Transformer secondary voltage: _____			

Cooling Checks												
Compressor Rotation <input type="checkbox"/> Ambient Temp. _____ Return Air Temp. _____ Supply Air Temp. _____												
	Compressor Amps			Compressor Volts			Pressures		Condenser Fan Amps			CC Heater Amps
	L1	L2	L3	L1-L2	L1-L3	L2-L3	Disch.	Suct.	L1	L2	L3	L1
1												
2												
3												
4												

Blower Checks			
Pulley/Belt Alignment	<input type="checkbox"/>	Blower Rotation	<input type="checkbox"/>
Set Screws Tight	<input type="checkbox"/>	Belt Tension	<input type="checkbox"/>
Nameplate Amps: _____		Volts: _____	
Motor	Amps	Volts	
	L1 _____	L1-L2 _____	
	L2 _____	L1-L3 _____	
	L3 _____	L2-L3 _____	

Heating Checks - Electric							
Return Air Temp.: _____				Supply Air Temp.: _____			
Limits Operate: <input type="checkbox"/>							
	Amps						
	L1	L2	L3		L1	L2	L3
1				10			
2				11			
3				12			
4				13			
5				14			
6				15			
7				16			
8				17			
9				18			

Heating Checks - Gas		
Fuel type: Nat. <input type="checkbox"/> LP <input type="checkbox"/> Inlet Pressure: _____ in. w.c.		
Return Air Temp.: _____ Supply Air Temp.: _____		
Altitude: _____ Primary Limits Operate: <input type="checkbox"/>		
CO <sub>2</sub> %: _____		
Gas Valve	Manifold Pressure	
	Low Fire	High Fire
GV1		
GV2		

Control Type

Accessory Checks	
Power Exhaust Amps	
1 _____	2 _____ None <input type="checkbox"/>
Economizer Operation	
Min. Pos. <input type="checkbox"/>	Motor travel full open/close <input type="checkbox"/>