



508800-01 07/2025

Addendum to Installation Instructions For EL297UHVK

Wiring diagrams 538497-01 and 538498-01 in Installation Instruction 508581-01 are supplemented with 538497-02 and 537498-02. Please refer to these diagrams for furnace installation.

Wiring Diagram 538498-02 \triangleright LINE VOLTAGE FIELD INSTALLED CLASS II VOLTAGE FIELD WIRING DENOTES OPTIONAL COMPONENTS **⊘** ² BLUE O GAS GAS EL297UH045XV36BK EL297UH070XV36BK EL297UH090XV36CK EL297UH090XV48CK EL297UH090XV60CK EL297UH110XV48CK EL297UH110XV60CK Form No. 538498-02 \triangleright \triangleright 프 Þ L13 USED ON 3/4 AND 1 HP ONLY 0000



Wiring Diagram 538497-02

