



538675-01

01

02

03

04

05

06

07

08

09

10

AA

BB

CC

DD

EE

FF

GG

HH

JJ

KK

LL

OPTIONAL IONIZER
WIRING. SEE IAQ
WIRING DIAGRAM

WB-033
WB-032

A55
MAIN CTRL

J395
P395

J394
P394

T1
TRANSFORMER

T18
TRANSFORMER

TO F10 LINE L1

TO F10 LINE L2

TB13
TERMINAL STRIP

SEE POWER ENTRY
DIAGRAM IN DISCONNECT
BOX FOR DETAILS

A133
A55 AUX CARD

A178
AUX CTRL

384 385 386 387 388 389 390 391 392 393 394

396 397 398



















441 442 443 444 445 446 447 448 449 450 451 452 453 454 455 456 457 458 459 460 461 462

405 404 403

405 404 403

405 404 403

405 404 403



J395
P395

J394
P394

T1
TRANSFORMER

T18
TRANSFORMER

TO F10 LINE L1

TO F10 LINE L2

TB13
TERMINAL STRIP

SEE POWER ENTRY
DIAGRAM IN DISCONNECT
BOX FOR DETAILS

A133
A55 AUX CARD

A178
AUX CTRL

384 385 386 387 388 389 390 391 392 393 394

396 397 398

441 442 443 444 445 446 447 448 449 450 451 452 453 454 455 456 457 458 459 460 461 462



















405 404 403

405 404 403

405 404 403

405 404 403

405 404 403



J395
P395

J394
P394

T1
TRANSFORMER

T18
TRANSFORMER

TO F10 LINE L1

TO F10 LINE L2

TB13
TERMINAL STRIP

SEE POWER ENTRY
DIAGRAM IN DISCONNECT
BOX FOR DETAILS

A133
A55 AUX CARD

A178
AUX CTRL

384 385 386 387 388 389 390 391 392 393 394

396 397 398

441 442 443 444 445 446 447 448 449 450 451 452 453 454 455 456 457 458 459 460 461 462



















405 404 403

405 404 403

405 404 403

405 404 403

405 404 403



J395
P395

J394
P394

T1
TRANSFORMER

T18
TRANSFORMER

TO F10 LINE L1

TO F10 LINE L2

TB13
TERMINAL STRIP

SEE POWER ENTRY
DIAGRAM IN DISCONNECT
BOX FOR DETAILS

A133
A55 AUX CARD

A178
AUX CTRL

384 385 386 387 388 389 390 391 392 393 394

396 397 398

441 442 443 444 445 446 447 448 449 450 451 452 453 454 455 456 457 458 459 460 461 462



















405 404 403

405 404 403

405 404 403

405 404 403

405 404 403



J395
P395

J394
P394

T1
TRANSFORMER

T18
TRANSFORMER

TO F10 LINE L1

TO F10 LINE L2

TB13
TERMINAL STRIP

SEE POWER ENTRY
DIAGRAM IN DISCONNECT
BOX FOR DETAILS

A133
A55 AUX CARD

A178
AUX CTRL

384 385 386 387 388 389 390 391 392 393 394

396 397 398

441 442 443 444 445 446 447 448 449 450 451 452 453 454 455 456 457 458 459 460 461 462



















405 404 403

405 404 403

405 404 403

405 404 403

405 404 403



J395
P395

J394
P394

T1
TRANSFORMER

T18
TRANSFORMER

TO F10 LINE L1

TO F10 LINE L2

TB13
TERMINAL STRIP

SEE POWER ENTRY
DIAGRAM IN DISCONNECT
BOX FOR DETAILS

A133
A55 AUX CARD

A178
AUX CTRL

384 385 386 387 388 389 390 391 392 393 394

396 397 398

441 442 443 444 445 446 447 448 449 450 451 452 453 454 455 456 457 458 459 460 461 462

405 4



538675-01

01

02

03

04

05

06

07

08

09

10

AA

BB

CC

DD

EE

FF

GG

HH

JJ

KK

LL

OPTIONAL IONIZER
WIRING. SEE IAO
WIRING DIAGRAM

WB-033
WB-032

WB-033
WB-032

A55
MAIN CTRL

J395
P395

J394
P394

J393
P393

J392
P392

J391
P391

J390
P390

J389
P389

J388
P388

J387
P387

J386
P386

J385
P385

J384
P384

J383
P383

J382
P382

J381
P381

J380
P380

J379
P379

J378
P378

J377
P377

J376
P376

J375
P375

J374
P374

J373
P373

J372
P372

J371
P371

J370
P370

J369
P369

J368
P368

J367
P367

J366
P366

J365
P365

J364
P364

J363
P363

J362
P362

J361
P361

J360
P360

J359
P359

J358
P358

J357
P357

J356
P356

J355
P355

J354
P354

J353
P353

J352
P352

J351
P351

J350
P350

J349
P349

J348
P348

J347
P347

J346
P346

J345
P345

J344
P344

J343
P343

J342
P342

J341
P341

J340
P340

J339
P339

J338
P338

J337
P337

J336
P336

J335
P335

J334
P334

J333
P333

J332
P332

J331
P331

J330
P330

J329
P329

J328
P328

J327
P327

J326
P326

J325
P325

J324
P324

J323
P323

J322
P322

J321
P321

J320
P320

J319
P319

J318
P318

J317
P317

J316
P316

J315
P315

J314
P314

J313
P313

J312
P312

J311
P311

J310
P310

J309
P309

J308
P308

J307
P307

J306
P306

J305
P305

J304
P304

J303
P303

J302
P302

J301
P301

J300
P300

J299
P299

J298
P298

J297
P297

J296
P296

J295
P295

J294
P294

J293
P293

J292
P292

J291
P291

J290
P290

J289
P289

J288
P288

J287
P287

J286
P286

J285
P285

J284
P284

J283
P283

J282
P282

J281
P281

J280
P280

J279
P279

J278
P278

J277
P277

J276
P276

J275
P275

J274
P274

J273
P273

J272
P272

J271
P271

J270
P270

J269
P269

J268
P268

J267
P267

J266
P266

J265
P265

J264
P264

J263
P263

J262
P262

J261
P261

J260
P260

J259
P259

J258
P258

J257
P257

J256
P256

J255
P255

J254
P254

J253
P253

J252
P252

J251
P251

J250
P250

J249
P249

J248
P248

J247
P247

J246
P246

J245
P245

J244
P244

J243
P243

J242
P242

J241
P241

J240
P240

J239
P239

J238
P238

J237
P237

J236
P236

J235
P235

J234
P234

J233
P233

J232
P232

J231
P231

J230
P230

J229
P229

J228
P228

J227
P227

J226
P226

J225
P225

J224
P224

J223
P223

J222
P222

J221
P221

J220
P220

J219
P219

J218
P218

J217
P217

J216
P216

J215
P215

J214
P214

J213
P213

J212
P212

J211
P211

J210
P210

J209
P209

J208
P208

J207
P207

J206
P206

J205
P205

J204
P204

J203
P203

J202
P202

J201
P201

J200
P200

J199
P199

J198
P198

J197
P197

J196
P196

J195
P195

J194
P194

J193
P193

J192
P192

J191
P191

J190
P190

J189
P189

J188
P188

J187
P187

J186
P186

J185
P185

J184
P184

J183
P183

J182
P182

J181
P181

J180
P180

J179
P179

J178
P178

J177
P177

J176
P176

J175
P175

J174
P174

J173
P173

J172
P172

J171
P171

J170
P170

J169
P169

J168
P168

J167
P167

J166
P166

J165
P165

J164
P164

J163
P163

J162
P162

J161
P161

J160
P160

J159
P159

J158
P158

J157
P157

J156
P156

J155
P155

J154
P154

J153
P153

J152
P152

J151
P151

J150
P150

J149
P149

J148
P148

J147
P147

J146
P146

J145
P145

J144
P144

J143
P143

J142
P142

J141
P141

J140
P140

J139
P139

J138
P138

J137
P137

J136
P136

J135
P135

J134
P134

J133
P133

J132
P132

J131
P131

J130
P130

J129
P129

J128
P128

J127
P127

J126
P126

J125
P125

J124
P124