



ADDENDUM

507974-01
06/2019

Addendum to Installation Instructions For SL280UHNV, SL280UHV & SL280DFV

The DOE issued new requirements for indoor blowers in gas furnaces. This requirement was put in place to reduce energy consumption and is effective July 3, 2019. The tables per model must be applied during installation in order to meet the new fan energy rating. These tables supersede any heating speed and circulation speed tables found in the instructions.

Allowable Heating Speeds SL280UHNV

Model	-18%	-12%	-6%	Default	+6%	+12%	+18%	+24%
060NV36A	Allowed	Allowed	Allowed	Factory Setting	Allowed	Allowed	Allowed	Allowed
080NV48B				Factory Setting				
080NV60C				Factory Setting				
100NV60C				Factory Setting				Not Allowed

Allowable Circulation Speeds SL280UHNV

Model Number	28% (second stage cool)	38% (second stage cool)
All Models	Allowed	Factory Setting

Allowable Heating Speeds SL280UHV

Model	-18%	-12%	-6%	Default	+6%	+12%	+18%	+24%
070V36A	Allowed	Allowed	Allowed	Factory Setting	Allowed	Allowed	Allowed	Allowed
090V36B							Not Allowed	Not Allowed
090V48B							Allowed	Allowed
090V60C								
110V60C								
135V60D							Not Allowed	

Allowable Circulation Speeds SL280UHV

Model Number	28% (second stage cool)	38% (second stage cool)
All Models	Allowed	Factory Setting

Allowable Heating Speeds SL280DFV

Model Number	-18%	-12%	-6%	Default	+6%	+12%	+18%	+24%
All Models	Allowed	Allowed	Allowed	Factory Setting	Allowed	Allowed	Allowed	Allowed

Allowable Circulation Speeds SL280DFV

Model Number	28% (second stage cool)	38% (second stage cool)
All Models	Allowed	Factory Setting

