Receiver & Display Unit User & installation manual

VCTRL10P-1

- Thank you for purchasing this Lennox Product.
- Before operating this unit, please read this manual carefully and retain it for future reference.



Safety Information

California Proposition 65 Warning (US)



WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov.

- Before using the receiver & display unit, read carefully this instructions.
- After reading the instructions, keep this owner's instructions and the installation manual in a handy and safe place. If a user is changed, you must hand over the manuals.
- Never attempt to install the air conditioning system or to move the receiver & display unit by yourself.




- Do not attempt to install or repair this receiver & display unit by yourself.
- This receiver & display unit contains no userserviceable parts. Always consult authorized service
 personnel for repairs.
- When moving, consult authorized service personnel for disconnection and installation of the receiver & display unit.
- Ensure that the wall is strong enough to support the weight of the receiver & display unit.
- In the event of a malfunction (burning smell, etc.), immediately stop operation, turn off the electrical breaker, and consult authorized service personnel.
- Read carefully this installation manual before installation and check whether the receiver & display unit is installed correctly after installation.
- Must install the receiver & display unit with the wire kit which is supplied with the unit.
- The receiver & display unit must be installed according to the national electrical rules by an installation specialist.
- When you want to disuse the receiver & display unit, consult authorized installation center.

Ŵ

- Do not use inflammable gases near the receiver & display unit.
- Do not spill water into the wired receiver & display unit.
- Do not operate the receiver & display unit with wet hands.
- Do not install the receiver & display unit in a location where it will come into contact with the combustible gases, machine oil, sulphide gas, etc.
- Do not press buttons with a pointed thing.
- Do not pull or bend the receiver & display unit cable excessively.
- Do not use this receiver & display unit for other purpose.
- Do not spray an insecticide or other combustible things on the receiver & display unit.
- Do not clean the receiver & display unit with benzene, solvents or other chemicals.
- Do not give a shock to the receiver & display unit or disassemble it by yourself.
- Avoid a location where acid/alkali solution or special spray is used.
- Choose a location that is dry and sunny, but not exposed to direct sunlight. Available temperature is between $32 \sim 102$ °F (0 ~ 39 °C).
- Do not give tensile strength to the cable to avoid disconnection.
- If the receiver & display unit is installed in a hospital or other special places, it should not affect other
 electronic devices.

View of the Receiver & Display Unit

Function description




Accessories

Receiver & display unit (1)	PH, +, 2, M2, L10 tapped screw (4)	TH, +, 1, M4, L20 tapped screw (2)
	Ommmo	€mmm>
User & Installation Manual (1)	Wire kit [Length: 32.80 ft (10 m)]	

Receiver & Display Unit Installation


Installation



- 1 Remove the receiver & display unit cover by using the tab on its bottom.
- 2 Open the receiver & display unit.
- **3** Connect the end of the connector wire to the receiver & display unit and connect the other end of the wire to the DISPLAY connector of Indoor PCB as shown in figure.



 Do NOT keep the receiver & display unit cable with a 220V cable because the remote controller cables have low voltage.



- 4 Secure the receiver & display unit on the wall with two screws.
- **5** Reassemble the receiver & display unit cover.



/ CAUTION

- The receiver & display unit must be installed by an installation specialist.
- Before installing the receiver & display unit, ensure that you have turned off the main power.
- All receiver & display unit cables should be installed according to the national wiring rules and you must install it in the wall not to be touched by users.

