



508811-01 08/2025

## Addendum to Installation Instructions For SL280UHVK

Wiring diagram 538484-01 in Installation Instruction 508553-01 is supplemented with 538484-02. Please refer to this diagram for furnace installation.

## Wiring Diagram 538484-02 A92 INTEGRATED CONTROL DENOTES OPTIONAL COMPONENTS LINE VOLTAGE FIELD INSTALLED CLASS II VOLTAGE FIELD WIRING ğ **Ο** α 0 0 ₽ ELECTRIC SHOCK HAZARD,CAN CAUSE INJURY OR DEATH JUNIT MUST BE GROUNDED IN ACCORDANCE WITH NATIONAL AND LOCAL CODES. PACTORY 00000 00000