

INSTALLATION INSTRUCTIONS FOR BACnet® MODULE (38B35) USED WITH COMPATIBLE ROOFTOP UNITS

⚠ CAUTION

Electrostatic discharge can affect electronic components. Take precautions during unit installation and service to protect the unit's electronic controls. Precautions will help to avoid control exposure to electrostatic discharge by putting the unit, the control and the technician at the same electrostatic potential. Neutralize electrostatic charge by touching hand and all tools on an unpainted unit surface before performing any service procedure.

⚠ IMPORTANT

Improper installation, adjustment, alteration, service or maintenance can cause personal injury, loss of life, or damage to property.

Installation and service must be performed by a licensed professional installer (or equivalent) or a service agency.

⚠ IMPORTANT

When adding this module to an existing CORE LITE Unit Controller, the CORE LITE firmware must be v7.12 or higher.

Look on LennoxPros.com for the latest firmware, or call Lennox technical support at 800-453-6669 for firmware update information.

General

The intent of this instruction is primarily for new BACnet® module installation when purchasing the module using repair part catalog number 38B35. This instruction is not included with the reference repair part. Typically if 38B35 was purchased simply as a replacement module, no additional setup steps would be required. Refer to the Replacement Installation section. If this is a new installation, then refer to the New Installation section. The CORE LITE Unit Controller BACnet® Module (BP1) allows communication between the Lennox CORE LITE Unit Controller and a BACnet® MS/TP network. This module is mounted directly to the CORE LITE Unit Controller and is not compatible with M1-8 IMC and earlier versions.

The BACnet® Module has been developed to communicate with building automation systems that support the BACnet Application Specific Controller (B-ASC) device profile.

A Lennox room sensor, or a network value, may be used to send the room temperature value to the CORE Lite Unit Controller.

TECHNICAL ASSISTANCE

For assistance, contact Lennox Technical Support at 800-453-6669.

Network Cable

The BACnet® Module is compatible with MS/TP EIA-485 daisy-chain networks communicating up to 76.8 kbps.

Connect the BACnet® MS/TP network cable to the BACnet® module. The module operates at up to 76.8K baud rate. It is compatible with twisted pair, shielded 22AWG minimum cable such as Belden 8761 or 88761.

A maximum of 32 CORE LITE BACnet® modules can be included per network segment. Up to 127 CORE LITE modules on the same network segment can be connected using repeaters.

The network cable should be routed using best practices to avoid induced noise. Do not route alongside high voltage wiring or in proximity to high-voltage or high-frequency devices, such as ignition controls and variable frequency drives.

The BACnet® MS/TP maximum total bus length (without repeater) of 4000 feet (1219 meters) applies to this device. Daisy-chain each module to the network and connect the network cable shield to the earth ground at the control panel, and at the G terminal of each BACnet® module in the chain.

Network Bus Termination

When the BACnet® module is at the end of a daisy chain, connect a 120 ohm resistor across the '+' and '-' terminals for bus termination. Every BACnet® MS/TP chain should have a termination at each end of the chain (exactly two terminations).

⚠ IMPORTANT

Look on LennoxPros.com for the latest firmware, or call Lennox technical support at 800-453-6669 for firmware update information.

A qualified systems integrator with adequate training and experience is required to integrate and commission the CORE LITE BACnet® Module into a third party BACnet building automation system. A BACnet configuration software tool is required to commission the BACnet network.

IMPORTANT

A small flat-head screw driver is required to connect the communication wire to the SmartWire connector.

Replacement Installation

1. Remove power to the unit.
2. Open the compressor access doors.
3. Plug the BACnet® module onto the CORE LITE Unit Controller. Guide pins will align the module with the CORE LITE Unit Controller connector.
4. Connect the BACnet® SmartWire connector.
5. No adjustment is necessary to the BACnet module unless the module is at the end of a daisy-chained configuration. In that case, it is recommended to place a 120 ohm resistor across the '+' and '-' terminals.
6. Upon powering up the unit controller, the following is applicable:

New Installation

CORE LITE UNIT CONTROLLER

This controller will automatically recognize the BACnet module and begin communications provided the network as been correctly configured.

CONFIGURING BACNET

To **configure** the BACnet® Network, go to:

SETTINGS > CONTROL = BACNET > MAC ADDRESS = > BAUD RATE =

NOTE: *Additional settings will be required to complete after entering the baud rate.*

ENABLING BACNET

To **enable** the BACnet module, go to:

SETUP > INSTALL and run the setup wizard.

When Configuration ID 1 appears on the screen, configure position 5 as B. This will enable the BACnet® module.

To **configure** the BACnet Network, go to:

RTU Menu > Network Integration > Network Setup Wizard > select BACnet MS/TP > Next >

NOTE: *Additional settings will be required to complete after entering the baud rate.*

NOTE: *Refer to CORE LITE BACnet module service literature for BACnet PICS (Protocol Implementation Conformance Statement), application details, recommendations, etc.*