VRF (Variable Refrigerant Flow) **User manual**

VMDC***S4-4P; VHIC***S4-4P

- Thank you for purchasing this Lennox Product.
- Before operating this unit, please read this manual carefully and retain it for future reference.





Contents

Safety Information	
Safety Information	3
At a Glance	10
Indoor Unit Overview	10
Main parts	10
Operation Features	11
Operating temperature and humidity • Pairing an indoor unit with a remote control	11
Cleaning and Maintenance	12
Periodical maintenance	12
Troubleshooting	13

California Proposition 65 Warning (US)

WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov Before using your new product, please read this manual thoroughly to ensure that you know how to safely and efficiently operate the extensive features and functions of your new appliance.

Because the following operating instructions cover various models, the characteristics of your product may differ slightly from those described in this manual. If you have any questions, call your nearest contact center or find help and information online at www.lennox.com for homeowners and www.lennoxpros.com for dealer/contractor.

⚠ WARNING

Hazards or unsafe practices that may result in severe personal injury or death.

! CAUTION

Hazards or unsafe practices that may result in minor personal injury or property damage.

- Follow directions.
- O Do NOT attempt.
- Make sure the machine is grounded to prevent electric shock.
- Cut-off the power supply.
- Do NOT disassemble.

FOR INSTALLATION

↑ WARNING

- Use the power line with the power specifications of the product or higher and use the power line for this appliance only. In addition, do not use an extension line.
 - Extending the power line may result in electric shock or fire.
 - Do not use an electric transformer. This may result in electric shock or fire.
 - If the voltage/frequency/rated current condition is different, it may cause fire.

- The installation of this appliance must be performed by a qualified technician or service company.
 - Failing to do so may result in electric shock, fire, explosion, problems with the product, or injury.

Install a switch and circuit breaker dedicated to the product.

• Failing to do so may result in electric shock or fire.

Fix the outdoor unit firmly so that the electric part of the outdoor unit is not exposed.

- Failing to do so may result in electric shock or fire.
- On not install this appliance near a heater, inflammable material. Do not install this appliance in a humid, oily or dusty location, in a location exposed to direct sunlight and water (rain drops). Do not install this appliance in a location where gas may leak.
 - This may result in electric shock or fire.

Never install the outdoor unit in a location such as on a high external wall where it could fall.

- If the outdoor unit falls, it may result in injury, death or property damage.
- This appliance must be properly grounded. Do not ground the appliance to a gas pipe, plastic water pipe, or telephone line.
 - Failure to do so may result in electric shock, fire, an explosion, or other problems with the product.
 - Make sure that it is in accordance with local and national codes.

! CAUTION

- Install your appliance on a level and hard floor that can support its weight.
 - Failing to do so may result in abnormal vibrations, noise, or problems with the product.

Install the drain hose properly so that water is drained correctly.

• Failing to do so may result in water overflowing and property damage. Avoid adding drain to waste pipes as odors may arise in the future.

- When installing the outdoor unit, make sure to connect the drain hose so that draining is performed correctly.
 - The water generated during the heating operation in the outdoor unit may overflow and result in property damage.
 In particular, in winter, if a block of ice falls, it may result in injury, death or property damage.

FOR POWER SUPPLY



- When the circuit breaker is damaged, contact your nearest service center.
- On not pull or excessively bend the power line. Do not twist or tie the power line. Do not hook the power line over a metal object, place a heavy object on the power line, insert the power line between objects, or push the power line into the space behind the appliance.
 - This may result in electric shock or fire.

∴ CAUTION

- When not using the product for a long period of time or during a thunder/lightning storm, cut the power at the circuit breaker.
 - Failing to do so may result in electric shock or fire.

FOR USING

⚠ WARNING

- If the appliance is flooded, please contact your nearest service center.
 - Failing to do so may result in electric shock or fire.

If the appliance generates a strange noise, a burning smell or smoke, cutoff the power supply immediately and contact the nearest service center.

• Failing to do so may result in electric shock or fire.

- In the event of a gas leak (such as propane gas, LP gas, etc.), ventilate immediately without touching the power line. Do not touch the appliance or power line.
 - Do not use a ventilating fan.
 - A spark may result in an explosion or fire.

To reinstall the product, please contact your nearest service center.

- Failing to do so may result in problems with the product, water leakage, electric shock, or fire.
- A delivery service for the product is not provided. If you reinstall the product in another location, additional construction expenses and an installation fee will be charged.
- Especially, when you wish to install the product in an unusual location such as in an industrial area or near the seaside where it is exposed to salt in the air, please contact your nearest service center.
- O Do not touch the circuit breaker with wet hands.
 - This may result in electric shock.

Do not strike or pull the product with excessive force.

• This may result in fire, injury, or problems with the product.

Do not place an object near the outdoor unit that allows children to climb onto the machine.

• This may result in children seriously injuring themselves.

Do not turn the product off with the circuit breaker while it is operating.

• Turning the product off and then on again with the circuit breaker may cause a spark and result in electric shock or fire.

After unpacking the product, keep all packaging materials well out of the reach of children, as packaging materials can be dangerous to children.

• If a child places a bag over its head, it may result in suffocation.

Do not touch the front panel with your hands or fingers during the heating operation.

• This may result in electric shock or burns.

Do not insert your fingers or foreign substances into the outlet when the product is operating or the front panel is closing.

• Take special care that children do not injure themselves by inserting their fingers into the product.

- O not insert your fingers or foreign substances into the air inlet/outlet of the product.
 - Take special care that children do not injure themselves by inserting their fingers into the product.

Do not use this product for long periods of time in badly ventilated locations or near infirm people.

- Since this may be dangerous due to a lack of oxygen, open a window at least once an hour
- If any foreign substance such as water has entered the appliance, cut-off the power supply and contact the nearest service center.
 - Failing to do so may result in electric shock or fire.
- Do not attempt to repair, disassemble, or modify the appliance yourself.
 - Do not use any fuse (such as copper, steel wire, etc.)other than the standard fuse.
 - Failing to do so may result in electric shock, fire, problems with the product, or injury.

↑ CAUTION

- **①** Do not place objects or devices under the indoor unit.
 - Water dripping from the indoor unit may result in fire or property damage.

Check that the installation frame of the outdoor unit is not broken at least once a year.

• Failing to do so may result in injury, death or property damage.

- On not stand on top of the appliance or place objects (such as laundry, lighted candles, lighted cigarettes, dishes, chemicals, metal objects, etc.) on the appliance.
 - This may result in electric shock, fire, problems with the product, or injury.

Do not operate the appliance with wet hands.

This may result in electric shock. Do not spray volatile material such as insecticide onto the surface of the appliance.

• As well as being harmful to humans, it may also result in electric shock, fire or problems with the product.

Do not drink the water from the product.

• The water may be harmful to humans.

Do not apply a strong impact to the remote controller and do not disassemble the remote controller.

Do not touch the pipes connected with the product.

• This may result in burns or injury.

Do not use this product to preserve precision equipment, food, animals, plants or cosmetics, or for any other unusual purposes.

• This may result in property damage.

Avoid directly exposing humans, animals or plants to the air flow from the product for long periods of time.

• This may result in harm to humans, animals or plants.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

FOR CLEANING

∴ WARNING

- On not clean the appliance by spraying water directly onto it. Do not use benzene, thinner, alcohol or acetone to clean the appliance.
 - This may result in discoloration, deformation, damage, electric shock or fire.

Before cleaning or performing maintenance, cut-off the power supply and wait until the fan stops.

• Failing to do so may result in electric shock or fire.


A CAUTION

- Take care when cleaning the surface of the heat exchanger of the outdoor unit since it has sharp edges.
 - To avoid cutting your fingers, wear thick cotton gloves when cleaning it.
 - This should be done by a qualified technician please contact your installer or service center.
- O not clean the inside of the product by yourself.
 - For cleaning inside the appliance, contact your nearest service center.
 - When cleaning the internal filter, refer to the descriptions in the 'Cleaning and Maintaining' section.
 - Failure to do may result in damage, electric shock or fire.
 - Make sure to prevent any injury from sharp edges of the surface when handling the heat exchanger.

Indoor Unit Overview

Main parts

The indoor unit and its display may look slightly different from the illustration shown below, depending on the model and the panel type.



Operation Features

Operating temperature and humidity

When using the product follow the operating temperature and humidity ranges.

Mode	Outdoor temperature	Indoor temperature	Indoor humidity
Cool mode	Depending on the outdoor unit specifications	18°C to 32°C (64°F to 90°F)	80% or less
Heat mode		30°C (86°F) or less	-
Dry mode		18°C to 32°C (64°F to 90°F)	-

↑ CAUTION

- If you use the product at a relative humidity above 80%, it may cause a formation of condensation and a leakage of water on the floor.
- The rated heating capacity is based on an outdoor temperature of 7°C (45°F). If the outdoor temperature goes down below 0°C (32°F), heating efficiencies may decrease depending on the temperature conditions.
- If the indoor unit is out of the operating temperature and humidity range, the safety device may operate and the product may stop.

Cleaning and Maintaining

Periodical maintenance

Unit	Maintenance item	Interval	Requires qualified technicians
	Clean the air filter.	At least once a month	
Indoor unit	Clean the condensate drain pan.	Once a year	Required
	Clean up the heat exchange.	Once a year	Required
	Clean the condensate drain pipe.	Once every 4 months	Required
	Replace the remote control batteries.	At least once a year	
Outdoor unit	Clean the heat exchanger on the outside of the unit.	Once every 4 months	Required
	Clean the heat exchanger on the inside of the unit.	Once a year	Required
	Clean the electric components with jets of air.	Once a year	Required
	Verify that all the electric components are firmly tightened.	Once a year	Required
	Clean the fan.	Once a year	Required
	Verify that the fan assemblies are firmly tightened.	Once a year	Required
	Clean the condensate drain pan.	Once a year	Required

Troubleshooting

Refer to the following chart if the product operates abnormally. This may save time and unnecessary expense.

Problem	Solution	
The product does not operate immediately after it has been restarted.	Because of the protective mechanism, the appliance does not start operating immediately to keep the unit from overloading. The product will start in 3 minutes.	
The product does not operate at all.	 Check whether the power is turned on, and then operate the product again. Check whether the auxiliary power switch (MCCB, ELB) is turned on. If the auxiliary power switch (MCCB, ELB) is turned off, the product does not work although you press the (1) (Power) button. When you clean the product or do not use it for an extended period of time, turn off the auxiliary power switch (MCCB, ELB). After the product is not used for an extended period of time, be sure to turn on the auxiliary power switch (MCCB, ELB) 6 hours before starting operation. NOTE The auxiliary power switch (MCCB, ELB) is sold separately. Make sure that auxiliary power switch (MCCB, ELB) is installed in the distribution box inside the building. If the product is turned off by the Timed off function, turn on the product again by pressing the (0) (Power) button. 	
The temperature does not change.	Check whether the Fan mode is running. In the Fan mode, the product controls the set temperature automatically, and you cannot change the set temperature.	
Warm air does not come out of the product.	 Check whether the outdoor unit is designed for cooling only. In this case, warm air does not come out although you select the Heat mode. Check whether the remote control is designed only for cooling only. Use a remote control that supports both cooling and heating. 	
The fan speed does not change.	Check whether the Auto or Dry mode is running. In these modes, the product controls the fan speed automatically, and you cannot change the fan speed.	
The programmable Wired Controller does not operate.	Check whether the ① indicator is displayed at the bottom right of the remote control display. In this case, turn off both the product and the auxiliary power switch, and then contact a service center.	

Cleaning and Maintaining

Problem	Solution	
The product is not turned on or off immediately with the programmable Wired Controller.	Check whether the programmable Wired Controller is set for group control. In this case, the products connected to the programmable Wired Controller are turned on or off sequentially. This operation takes up to 32 seconds.	
The Timed on/off function does not operate.	Check whether you pressed the (SET) button on the remote control after setting the on/off time. Set the on/off time.	
The indoor unit display blinks continuously.	 Turn on the product again by pressing the (b) (Power) button. Turn off and then turn on the auxiliary power switch, and then turn on the conditioner. If the indoor unit display is still blinking, contact a service center. 	
I want to get cooler air.	Operate the product with an electric fan to save energy and enhance the cooling efficiency.	
The air is not cool or warm enough.	 In the Cool mode, cool air does not come out if the set temperature is higher than the current temperature. Remote control: Press the Temperature button repeatedly until the set temperature [minimum: 18°C (64°F)] is set to lower than the current temperature. In the Heat mode, warm air does not come out if the set temperature is lower than the current temperature. Remote control: Press the Temperature button repeatedly until the set temperature [maximum: 30°C (86°F)] is set to higher than the current temperature. Both cooling and heating do not operate in the Fan mode. Select the Cool, Heat, Auto, or Dry mode. Check whether the air filter is blocked with dirt. A dusty filter may decrease the cooling and heating efficiencies. Clean the air filter frequently. If a cover is on the outdoor unit or any obstacle is present near the outdoor unit, remove them. Install the outdoor unit in a well-ventilated place. Avoiding places exposed to direct sunlight or close to a heating appliance. Place a sunscreen over the outdoor unit to protect it from direct sunlight. If the indoor unit is installed in a place exposed to direct sunlight, pull the curtains on the windows. 	

Problem	Solution	
The air is not cool or warm enough.	 Close the windows and doors to maximize the cooling and heating efficiencies. If the Cool mode is stopped and then started immediately, cool air comes out after about 3 minutes to protect the compressor of the outdoor unit. When the Heat mode is started, warm air does not come out immediately to prevent cool air from coming out at the beginning. If the refrigerant pipe is too long, the cooling and heating efficiencies may be decreased. Avoid exceeding the maximum pipe length. 	
The product makes strange noises.	 In certain conditions [especially, when the outdoor temperature is lower than 20°C (68°F)], a hissing, rumbling, or splashing sound may be heard while the refrigerant is circulating through the product. This is a normal operation. When you press the (b) (Power) button on the remote control, noise may be heard from the drain pump inside the product. This noise is a normal sound. 	
Unpleasant odors permeate the room.	 If the product is running in a smoky area or if there is a smell entering from outside, ventilate the room properly. If both indoor temperature and indoor humidity are high, operate the product in the Clean or Fan mode for 1 to 2 hours. If the product has not been operated for an extended period of time, clean the indoor unit and then operate the product in the Fan mode for 3 to 4 hours to dry the inside of the indoor unit for removal of unpleasant odors. If the air filter blocked with dirt, clean the air filter. 	
Steam is produced on the indoor unit.	In winter, if the indoor humidity is high, steam may be produced around the air outlet while the defrost function is running. This is a normal operation.	
The outdoor unit fan continues to operate when the product is turned off.	When the product is turned off, the outdoor unit fan may continue to operate to reduce noise of the refrigerant gas. This is a normal operation.	
Water drops from the piping connections of the outdoor unit.	Condensation may develop due to the difference in temperature. This is a normal condition.	
Steam is produced on the outdoor unit.	In winter, when the product runs in the Heat mode, the frost on the heat exchanger melts and steam may be produced. This is a normal operation, neither product malfunction nor a fire.	



Register Product to Receive enhance warranty and view product documentation : https://www.warrantyyourway.com/

COUNTRY	CALL	OR VISIT US ONLINE AT
AMERICA	800-953-6669	www.lennox.com for homeowners, www.lennoxpros.com for dealer/contractor