



KEY	DESCRIPTION
CB1	CIRCUIT BREAKER-ELECT HEAT
CB2	CIRCUIT BREAKER-ELECT HEAT
HE1	ELEMENT-ELECTRIC HEAT 1
HE2	ELEMENT-ELECTRIC HEAT 2
HE3	ELEMENT-ELECTRIC HEAT 3
K32	RELAY-ELECTRIC HEAT
K33	RELAY-ELECTRIC HEAT
K34	RELAY-ELECTRIC HEAT
P2	PLUG-ELECTRIC HEAT
S15	SWITCH-LIMIT,PRIMARY,ELECT HEAT
S20	SWITCH-LIMIT,SECONDARY,ELECT HEAT




REFER TO UNIT NAMEPLATE FOR MINIMUM
CIRCUIT AMPACITY AND MAXIMUM
OVERCURRENT PROTECTION SIZE.
— LINE VOLTAGE FIELD INSTALLED
← DENOTES OPTIONAL COMPONENTS


NOTE: USE COPPER CONDUCTORS ONLY



HEATING UNITS-ELECTRIC	
ECB47-12.5CB-P ECB47-15CB-P	
Supersedes	
03/24	Form No. 538456-01




KEY	DESCRIPTION
CB1	CIRCUIT BREAKER-ELECT HEAT
CB2	CIRCUIT BREAKER-ELECT HEAT
HE1	ELEMENT-ELECTRIC HEAT 1
HE2	ELEMENT-ELECTRIC HEAT 2
HE3	ELEMENT-ELECTRIC HEAT 3
K32	RELAY-ELECTRIC HEAT
K33	RELAY-ELECTRIC HEAT
K34	RELAY-ELECTRIC HEAT
P2	PLUG-ELECTRIC HEAT
S15	SWITCH-LIMIT,PRIMARY,ELECT HEAT
S20	SWITCH-LIMIT,SECONDARY,ELECT HEAT



REFER TO UNIT NAMEPLATE FOR MINIMUM
CIRCUIT AMPACITY AND MAXIMUM
OVERCURRENT PROTECTION SIZE.
— LINE VOLTAGE FIELD INSTALLED
← DENOTES OPTIONAL COMPONENTS

NOTE: USE COPPER CONDUCTORS ONLY



HEATING UNITS-ELECTRIC	
ECB47-12.5CB-P ECB47-15CB-P	
Supersedes	
03/24	Form No. 538456-01